

PUBLIC




KONGSBERG

Reference Manual

M3 Sonar[®]

Multibeam sonar





KONGSBERG

M3 Sonar
Multibeam sonar
Reference Manual
Release 1.9

This manual provides you with reference information required to operate and fully understand the commands, menus, modes and options provided by the Kongsberg M3 Sonar Multibeam sonar.

Document information

- **Product:** Kongsberg M3 Sonar
- **Document:** Reference Manual
- **Document number:** 922-10017001
- **Revision:** 1.9
- **Date of issue:** 19 April 2024

Copyright

The information contained in this document remains the sole property of Kongsberg Discovery Canada Limited. No part of this document may be copied or reproduced in any form or by any means, and the information contained within it is not to be communicated to a third party, without the prior written consent of Kongsberg Discovery Canada Limited.

Warning

The equipment to which this manual applies must only be used for the purpose for which it was designed. Improper use or maintenance may cause damage to the equipment and/or injury to personnel. You must be familiar with the contents of the appropriate manuals before attempting to operate or work on the equipment.

Kongsberg Discovery disclaims any responsibility for damage or injury caused by improper installation, use or maintenance of the equipment.

Disclaimer

Kongsberg Discovery Canada Limited endeavours to ensure that all information in this document is correct and fairly stated, but does not accept liability for any errors or omissions.

Support information

If you require maintenance or repair, contact your local dealer. You can contact us by phone at +1 604 464 8144, or by email at: support.vancouver@kd.kongsberg.com. If you need information about our other products, visit <https://www.kongsberg.com/discovery/>. On our website you will also find a list of our dealers and distributors.

Table of contents

ABOUT THIS MANUAL	7
M3 SONAR	9
System description.....	10
System diagram.....	11
System units.....	12
Sonar Processor.....	13
Power supply.....	13
Sonar Head.....	14
Support information.....	15
GETTING STARTED	16
Turning the M3 Sonar system on and off.....	17
Turning on the M3 Sonar system.....	17
Turning off the M3 Sonar system.....	18
Starting normal operation.....	19
Introduction to the basic procedures.....	19
Setting the Sonar Processor to High Performance.....	20
Restoring USB Driver Functionality in Windows 10.....	21
Installing the M3 software.....	22
Defining the IP address on the computer's network adapter.....	23
Changing the frequency.....	24
Testing operation of the Sonar Head.....	24
Testing the Sonar Head telemetry.....	27
Testing 1PPS Time Sync Mode.....	30
OPERATING PROCEDURES	32
Setting up and running the sonar.....	33
Starting operation of the Sonar Head.....	34
Configuring your preferences.....	35
Choosing the sonar range.....	36
Choosing a sonar application.....	37
Adjusting the sonar view.....	38
Applying filters.....	42
Adjusting the TVG (Time Variable Gain) setting.....	42
Setting up external sensors.....	43
Defining a custom sensor.....	46

Controlling the rotator.....	49
Setting up dual M3 Sonars	54
Saving and recalling screen captures	65
Saving and retrieving images	66
Recording sonar data.....	66
Playing back a recording.....	68
Converting your recording format.....	69
Converting your recordings to video.....	70
Saving GeoTiff files.....	72
Using sonar view overlays.....	75
Measuring distances	76
Measuring angles.....	77
Defining an area.....	78
Placing text labels.....	78
Placing reference cursors.....	79
Placing target markers	80
Configuring the Sonar Head.....	82
Upgrading the Sonar Head	83
Changing the Sonar Head IP Address	85
USER INTERFACE.....	88
Presentation overview.....	89
The M3 software menu system.....	91
Sonar view	92
Interpreting the sonar view.....	93
Noise and interference.....	94
3D Point Cloud	95
Tool bar description	97
Status bar.....	99
MENU SYSTEM	101
File menu	102
Display menu	103
Setup menu	106
Sonar Applications menu.....	108
Advanced menu	112
Help menu.....	113
FUNCTIONS AND DIALOG BOXES.....	114

File menu	115
Recording Format	116
Exporting Format	117
Convert to Video Format dialog box	117
Display menu	123
Target Marker Export dialog box	125
Playback Console	127
Profiling Settings dialog box	128
Setup menu	132
Define Custom Sensor dialog box	133
Geo Projection dialog box	136
Preferences dialog	138
Head Network Setup dialog box	142
Head Firmware Configuration dialog box	145
System Configuration dialog box - Sonar Setup page	146
System Configuration dialog box - Sensors Setup page	150
System Configuration dialog box - Rotators Setup page	153
System Configuration dialog box - Master Reference page	160
System Configuration dialog box - Mounting Offsets page	163
Sonar Applications menu	168
Enhanced Image Quality (EIQ)	172
Imaging	172
Profiling	173
ROV Navigation	174
Advanced menu	176
Power User Settings dialog box	177
Program Head dialog box - Production Config page	180
Program Head dialog box - Head Corrections page	182
Program Head dialog box - TX Pulse page	184
Profile Batch Conversion dialog box	185
Raw Data Spectrum window	187
Power User Settings XML file	188
Help menu	191
Tool bar description	192
Arrow	194
Wiper	194
Zoom windows	195

Tape Measure.....	196
Protractor	196
String Measure	196
Text Label.....	197
Reference cursors	197
Image Quality Analysis System	198
Save image with or without overlays	199
TVG Setup dialog box.....	200
Filters.....	203
TECHNICAL SPECIFICATIONS.....	204
Introduction to technical specifications	205
Interface specifications.....	206
Performance specifications	209
Mechanical specifications	213
Power requirements	215
Environmental requirements.....	216
Minimum computer requirements.....	217

About this manual

The purpose of this publication is to provide the descriptions, procedures and detailed parameter explanations required to allow for safe and efficient use of the M3 Sonar system. The publication also provides you with a thorough understanding of the parameters and adjustments provided by the M3 Sonar system.

Target audience

This publication is intended for all users of the M3 Sonar system. Due to the nature of the descriptions and the level of detail provided by this publication, it is well suited for those who are - or wish to be - expert users.

A good understanding of system functions and controls is essential to fully take advantage of the functionality provided. A careful study of the information in this manual is highly recommended, preferably while exploring the functionality offered by the M3 Sonar system.

We assume that you are familiar with the basic acoustic principles of sound in water. We also expect that you have some experience with sonar operation.

License information

The M3 Software is included with the M3 Sonar system and updates are available free of charge.

Software version

This M3 Sonar Reference Manual complies with M3 software version 2.5.4.

Registered trademarks

Observe the registered trademarks that apply.

Windows® is a registered trademark of Microsoft Corporation in the United States and other countries.

M3 Sonar® is a registered trademark of Kongsberg Discovery Canada Limited in the United States and other countries.

We want your feedback

We always want to improve our products. We also want our end-user documentation to be comprehensive and relevant. You can help. Please provide comments, suggestions or constructive criticism to our support office. You can contact us by phone at +1 604 464 8144, or by email at: support.vancouver@kd.kongsberg.com.

M3 Sonar

Topics

[System description, page 10](#)

[System diagram, page 11](#)

[System units, page 12](#)

[Support information, page 15](#)

System description

The Kongsberg Discovery M3 Sonar is a compact, versatile multibeam sonar.

Multibeam sonars have an array of transducers that simultaneously transmits pings (sound pulses) at a specified frequency to cover a large area in less time than a single-beam transducer. To generate data, computer software assigns a colour range corresponding to the amount of sound reflected off a target. The distance to the target is determined by the length of time it took to receive the transmitted acoustic pulse.




By combining the high refresh rate of a conventional multibeam sonar with an image quality comparable to a single-beam sonar, the M3 Sonar provides high-resolution images that are easy to interpret. The M3 Sonar detects objects out to 150 metres and has a 120° to 140° field of view, allowing you to see the full underwater picture in real-time.

The M3 Sonar provides wide-angle full-range situational awareness and concurrent ultra-short range imaging with dynamic focusing. For optimized obstacle avoidance, the M3 Sonar uses variable vertical beamwidth.

System diagram

The system diagram identifies the main components of a basic M3 Sonar system. Only the main connections between the units are shown. Detailed interface capabilities and power cables are not shown.



- A *Sonar Processor*
- B *Power supply*
- C *M3 Sonar Head*

System units

Topics

[Sonar Processor, page 13](#)

[Power supply, page 13](#)

[Sonar Head, page 14](#)

Sonar Processor

In this publication, the computer can also be referred to as the *Processor Unit*, and vice versa. The Sonar Processor contains the operational software, and offers the user interface that allows you to control the M3 Sonar. It is a vital part of the M3 Sonar system.

The Sonar Processor runs the M3 software that manages communication with the Sonar Head, performs all beamforming and image processing and presents the sonar imagery. The Sonar Processor communicates with the sonar through a standard Ethernet cable.

If you purchase a computer locally, make sure that the chosen model meets the functional and technical requirements. The computer must be designed for rugged use. The construction must be able to withstand the vibrations and movements of a vessel.



Related topics

[Minimum computer requirements, page 217](#)

Power supply

The Sonar Head requires a DC power supply to run.



Normally, the DC voltage is supplied in the location where the Sonar Head is mounted, such as on a remotely operated vehicle (ROV). A small DC switching supply can be used when running the system on a surface vessel.


A test cable and power supply is available for order as an accessory. The test power supply uses a 24 VDC switching power supply.

Related topics

[Power requirements, page 215](#)

Sonar Head

When deployed underwater, the Sonar Head transmits and receives acoustic pulses.



The Sonar Head includes transmit and receive transducers and the electronics to generate the transmit pulse and digitize the received signal. The sonar data is sent to the Sonar Processor using a standard Ethernet link.

Note

The Sonar Head's black polyurethane transducer is delicate. Always keep the Guard Ring and protective cover over the transducer during installation and storage.

Several different M3 Sonar models are available – your model may differ from the one shown here. For example, there are models with different depth ratings and materials, as well as models that include an integrated sound velocity sensor or high-frequency transducer.

Related topics

[Performance specifications, page 209](#)

[Mechanical specifications, page 213](#)

Support information

If you need technical support for your M3 Sonar you must contact your local dealer, or our support department.

If you require maintenance or repair, contact your local dealer. You can contact us by phone at +1 604 464 8144, or by email at: support.vancouver@kd.kongsberg.com. If you need information about our other products, visit <https://www.kongsberg.com/discovery/>. On our website you will also find a list of our dealers and distributors.

Getting started

Topics

[Turning the M3 Sonar system on and off, page 17](#)

[Starting normal operation, page 19](#)

Turning the M3 Sonar system on and off

Topics

[Turning on the M3 Sonar system, page 17](#)

[Turning off the M3 Sonar system, page 18](#)

Turning on the M3 Sonar system

To use the M3 Sonar system, you must turn it on. You must first turn on the display and the computer. After this you can start the M3 software.

Prerequisites

- The system units have all been installed according to the instructions provided.
- All cable connections have been made and checked.
- All system units have been inspected.

Context

The program is not automatically started when the computer is turned on. On the Sonar Processor desktop, double-click the M3 Sonar icon to start the software.

Note

The M3 Sonar is not provided with an on/off switch.

Procedure

- 1 Power up the Sonar Head using the power supply.

Note

It may take up to 60 seconds for the M3 software to connect to the Sonar Head once the power is applied.

- 2 Turn on the computer.
Wait while the operating system loads.
- 3 Log in to Windows.
- 4 On the Sonar Processor desktop, double-click the M3 Sonar icon to start the software.

- 5 Once the program has started, observe that the display presentation fills the entire screen.

The software starts up using many of the same settings as the last time you used it. If these settings are acceptable, continue operation. If you wish to alter any of the settings, see the relevant procedures.

- 6 Click **Setup**→**Connect** to start the Sonar Head.

The sonar will start pinging automatically once the connection is complete. Observe that the text “Active” appears in the lower-right corner of the status bar.

Turning off the M3 Sonar system

The M3 Sonar is not provided with an on/off switch.

Context

When you do not use the M3 Sonar system, turn it off.

Procedure

- 1 If you are running the sonar, click **Setup**→**Disconnect** in the M3 software.
- 2 Switch off the Sonar Processor.
 - a Close the M3 software and any third-party software.
 - b Shut down Windows.
- 3 Disconnect the power cord leading to the power supply.

Alternatively, switch off the breaker supplying power to the M3 Sonar.
- 4 Switch off any additional items, such as a sound velocity profiler or display.

If required, refer to the instructions provided by the product’s manufacturer.

Starting normal operation

Topics

- [Introduction to the basic procedures, page 19](#)
- [Setting the Sonar Processor to High Performance, page 20](#)
- [Restoring USB Driver Functionality in Windows 10, page 21](#)
- [Installing the M3 software, page 22](#)
- [Defining the IP address on the computer's network adapter, page 23](#)
- [Changing the frequency, page 24](#)
- [Testing operation of the Sonar Head, page 24](#)
- [Testing the Sonar Head telemetry, page 27](#)
- [Testing 1PPS Time Sync Mode, page 30](#)

Introduction to the basic procedures

Once you have powered up the complete M3 Sonar system, and started the M3 Sonar program, you are ready to start the actual operation.

Observe these brief procedures to familiarize yourself with the basic operation.

When starting up, the M3 Sonar will automatically apply its previous settings. The procedures are partly provided to get you acquainted with the basic functionality offered by the M3 Sonar, and partly to set up the M3 Sonar for normal use. If you already know the current operational settings are acceptable, you may not need to do any of these procedures.

Setting the Sonar Processor to High Performance

To avoid slowdowns or disruptions while running the sonar, ensure your Sonar Processor is using all of its processing power and does not go to sleep.

Prerequisites

This procedure is made for the Microsoft® 64-bit Windows 10 operating system.

Procedure

- 1 In the bottom-left corner of your desktop, select the Windows® **Start** button.
- 2 On the menu, select **Settings**.
Observe that the **Settings** window opens.
- 3 Select **System**.
- 4 In the menu on the left, select **Power & sleep**.
- 5 Make sure that the Sonar Processor will never go to sleep when plugged in.
 - a Click the **Additional power settings** link on the right side of the window.
Observe that the **Power Options** dialog box opens.
 - b In the menu on the left, select **Create a power plan**.
 - c Select the **High performance** radio button.
 - d Give your new custom plan a name, then click **Next**.
 - e Select *Never* for both **Turn off the display** and **Put the computer to sleep** when plugged in.
 - f Click **Create**.

Tip

*Once you have created a custom plan, you can adjust some more advanced settings. You may, for example, wish to keep any secondary displays on when the laptop lid is closed. Click **Change plan settings** next to your custom plan. Click the **Change advanced power settings** link. Observe that the **Power Options** dialog box opens. Click the “+” to expand the submenus, then select the desired options from the drop-down lists. At the bottom of the dialog box, select **Apply** to save your settings.*

Restoring USB Driver Functionality in Windows 10

If you are using Windows 10, a new security feature may cause your system installation to fail, especially if you are using a USB port in your system. For example, a USB port is used to interface with a security key inserted into the USB port, or an Interface Unit connected via the USB port.

Context

In the original release of Windows 10, virtualization-based security (VBS) features were only available on Enterprise editions of Windows 10 (as part of “Device Guard”). However, starting with the April 2018 Update, Core Isolation brings some virtualization-based security features to all editions of Windows 10.


Enabling this feature causes conflicts for the installation of our USB drivers. To restore functionality, the **Memory Integrity** function needs to be set as disabled, as shown below.

Note

This issue only affects KML USB driver and SafeNet dongle driver installation. It does not affect software function.

Procedure

- 1 Select the Windows® search function, which you can usually find on the bottom Taskbar.
- 2 In the search box, type “Core Isolation”, and open the **Windows Security** dialog box.
- 3 If enabled, select the switch to disable **Memory integrity**.



- 4 Select [X] in the upper-right corner to close the dialog box.

Installing the M3 software

If your system is provided with a Sonar Processor, the M3 software has already been installed. If you intend to use your own computer, you must install the software yourself. We recommended installing the latest M3 software on your Sonar Processor.

Prerequisites

- You can find the software on the Kongsberg USB drive included with the system, or you can contact your local dealer or distributor to have the latest software version installed.
- If you are installing a new software version, uninstall the previous version of the M3 software before proceeding.

Note

When running the M3 software for the first time, a Windows Firewall dialog box may appear. Allow access for all networks.

Procedure

- 1 Launch the installer **M3_V0254 Setup.exe**.
- 2 Follow the installation wizard's instructions and select *Standard Installation*.

Note

Use the Dual-M3 on Same PC option only if you are using two M3 Sonars. Selecting this option will install two separate copies of the software, with each copy having its own settings. You can identify which copy you are using by observing the top header of the software presentation. The header will read either "M3 - Master Head" or "M3 - Slave Head".

- 3 Use the default folder location and check **Create a desktop icon**, then click **Next**.
- 4 Click **Yes** to install the **KML USB Converter** when prompted and follow the instructions to finish the installation process.
- 5 Pin the M3 software icon to the Windows Taskbar.
 - a Right click on the M3 software icon.
 - b Click **Pin to taskbar**.
- 6 Test the M3 software startup.
 - a Double click the M3 icon on the desktop to run the M3 software.
 - b Confirm the software finishes launching without any error windows appearing.

Defining the IP address on the computer's network adapter

The communication between the Sonar Processor and the Sonar Head is made using a high-speed Ethernet cable. If a Sonar Processor is not configured to connect to the sonar, you must define which IP Address and Subnet mask the Ethernet adapter in the Sonar Processor shall use for this communication.

Prerequisites

This procedure is made for the Microsoft® 64-bit Windows 10 operating system. It is assumed that you are familiar with the Windows® operating systems, computer technology, and interface principles.

Context

As long as you do not change the Sonar Processor to another computer, or replace the serial adapter in your Sonar Processor, you will only need to do this once.

Procedure

- 1 On the computer, close the M3 software.
- 2 Open the **Network Connections** dialog box.
 - a In the bottom-left corner of your desktop, select the Windows® search function.
 - b In the search box, type "Network Connections", and open the **Network Connections** dialog box.
 - c Right-click the network adapter you are going to use and select **Properties** on the shortcut menu.
 - d On the list of connections, select **Internet Protocol 4 (TCP/IPv4)**, and then **Properties**.
- 3 Select **Use the following IP address**, and type the IP address and network mask.

IP Address: **192.168.1.N** ("*N*" can be any number from 1 to 254, except 234, which is the Sonar Head default.)

Subnet mask: **255.255.255.0**

You can leave **Default Gateway** blank.
- 4 Select **OK** to save the settings, then close all the dialog boxes.

Changing the frequency

If you have a high-frequency M3 Sonar transducer, you can change the frequency using the **Display Widget**.

Context

Note


The frequency buttons will not appear if you are using a 500 kHz transducer. In addition, these buttons will not appear in playback mode.

Procedure

- 1 Click **Setup**→**Connect** to start the Sonar Head.
- 2 Click the **Display Widget** icon.
This icon is located in the lower-right corner of the sonar view.
- 3 Click one of the buttons to select a frequency (in kHz).
- 4 Click the **Display Widget** icon to hide the widget.

Note

*The selection of sonar applications presented in the **Sonar Applications** menu depends on the current Sonar Head frequency.*



Testing operation of the Sonar Head

You can test the operation of the Sonar Head by confirming that sonar data is being correctly displayed in the **Information Widget**, sonar view, and **3D Point Cloud** window. In addition, any errors will be displayed in the **Output Messages** or **Head Status** windows.

Prerequisites

The M3 software must be running.


Tip

Make sure there is sufficient disk space available to complete the survey.

Procedure

- 1 Click **Setup**→**Connect** to start the Sonar Head.

Make sure that a sonar image appears in the sonar view window.




- 2 Click the “i” icon in the top-left corner of the sonar view to open the **Information Widget**.
Make sure that the sensor data is updating in the **Information Widget**.

- 3 Select *Profiling* from the **Sonar Apps** menu.


Note _____

*The selection of sonar applications presented in the **Sonar Applications** menu depends on the current Sonar Head frequency.*



- 4 If the profiling settings are not visible, click **Display**→**Profiling Settings** to open the **Profiling Settings** dialog box.
- 5 Check the **Depth Tracking** box to automatically adjust the range according to the current depth.
- 6 Make sure that data is displayed and being updated in the **3D Point Cloud** window.
- 7 Make sure that no errors are displayed in the **Output Messages** window.
 - a Click **Display**→**Output Messages Window**.
 - b Make sure there are no errors shown in the **Output Messages** window under the **Host Messages** or **Head Messages** tab.
- 8 Make sure there are no errors in the **Connection Status** and **Head Status** windows.
 - a Click on the text “Active” located in the lower-right corner of the status bar.
Observe that the **Connection Status** window opens.
 - b Make sure that all items listed under the M3 Sonar show check marks.
If any items are shown with an “X” in a red circle, it usually means the device has failed to connect. Disconnect and make sure that no sensors have failed.
 - c Click on the top line in the **Connection Status** window.
Observe that the **Head Status** window opens.
 - d Make sure that all parameters in the list are shown with a check mark inside a green circle.

- 9 Make sure there is no acoustic or electrical interference in the sonar view.



- A** Make sure that no concentric rings appear. These rings could be caused by other acoustic devices or power-line noise. Rings with black gaps between them could also be due to excess Ethernet traffic when using a shared network.
- B** Make sure that there isn't a bright radial line originating from the Sonar Head. This line could be caused by thruster noise. If the radial line appears with the Sonar Head out of water, it could indicate noise in the power line or a fault in the Sonar Head.
- C** Make sure that the bottom appears across the entire width of the sonar view. If the edges appear weak, and profile points are not detected at the edges, make sure there are no obstructions preventing the Sonar Head's receive. (i.e. improperly installed guard ring or proximity to the vessel hull/keel).

Related topics

[System Configuration dialog box - Sonar Setup page, page 146](#)

Testing the Sonar Head telemetry

You can run a telemetry test to make sure the link between the Sonar Head and the M3 software is working correctly.

Prerequisites

- For this test you will need the Sonar Head connected to the Sonar Processor and powered on.
- The M3 software must be running.
- This procedure is made for the Microsoft® 64-bit Windows 10 operating system. It is assumed that you are familiar with the Windows® operating systems, computer technology, and interface principles.

Context

This procedure explains how to measure the available bandwidth on a 100Base-TX (100 Mbps) Ethernet link. The same procedure can be used for 10BaseT and 1000BaseT links

by selecting the appropriate sonar application and adjusting the Ethernet adapter settings to the corresponding link speed.

Note

There are no standard sonar applications with a telemetry-link speed requirement higher than 100 Mbps.

The ping rate is normally taken from the sonar application or range setting. If the estimated available bandwidth is less than the bandwidth required by the sonar application/range, the M3 software reduces the ping rate to compensate.

Note


The update rate is the number of times the sonar view is updated per second. The displayed ping rate may be different from the update rate because the system might be impacted by other processes.

The **Override Network Link Speed** function allows you to use the telemetry bandwidth value (in Mbps) entered into the box instead of the default speed. If the applied override telemetry bandwidth is less than the telemetry bandwidth required by the sonar application/range, the ping rate is reduced.

Procedure

- 1 Click **Setup**→**Connect** to start the Sonar Head.
- 2 Add the Ethernet Test application to your list of favourite applications.
 - a Open the **Sonar Apps** menu on the top bar, then select **Customize Apps**.
 - b Double click on *Ethernet Test - 100Mbps* shown under **Other Apps**.
 - c Click **OK**.
- 3 Open the **Sonar Apps** menu on the top bar, then select **Ethernet Test - 100Mbps**.
- 4 Click **Setup**→**Connect** to start the Sonar Head.
- 5 Open the **Task Manager** and find your Local Area Connection.
 - a Press the **<CTRL> + <ALT> + ** keys.
 - b Click **Task Manager**.
 - c Click on the **Performance** tab.
 - d Click on the Ethernet connection for the Sonar Head.
- 6 Make sure the activity on your local network is as expected.
 - a Allow the system to run for a few minutes to plot the *Throughput* graph.

- b Observe the graph to determine the average network link speed.



An average link speed of at least 80 Mbps is required by most sonar applications (some applications and range scales will use less). A link speed of less than 80 Mbps may result in a slower than expected ping rate.

- c Right-click in the *Throughput* graph and select **View network details**.

Observe that the **Network Details** window opens.

- d Confirm that the *Network utilization* is at least 80%.

Note _____

If the Network utilization is less than 80%, disconnect the sonar, close all other programs, then reconnect the sonar. In general, make sure that your network environment supports the required link speed.

- e In the M3 software, look for any messages in the **Output Messages** window.

Make sure there are no lost packets.

Tip _____

*The contents of the **Output Messages** window are also saved to a file in the folder C:\KML\M3_V0254\LOGS.*

- f If you see missing pings, try reduce the value in the **Override Network Link Speed** box to improve the performance.

Testing 1PPS Time Sync Mode

If you have an M3 Sonar Head with a 1PPS connector, you can synchronize the Sonar Head clock with an external 1PPS source. After you have enabled the 1PPS Time Sync Mode, you can make sure it is working by reading through the **Output Messages** log file.

Prerequisites

- The Sonar Head must be upgraded to the latest firmware version (version 1.5 or later).
- 1PPS synchronization requires ZDA input over UDP to the Sonar Head (not to the M3 software) on UDP port 31100 at 1Hz.
- The 1PPS signal must be sent to the Sonar Head using the 1PPS input on one of the following cables.
 - 10-pin SEA CON® MINK-10-CCPL cable used with M3 Sonar model 922-20220000.
 - 4-pin SEA CON® MIND-4-FCR cable used with M3 Sonar model 922-20050000.

Procedure

- 1 Click **Setup**→**System Configuration**→**Devices**→**Sonar Setup**.
- 2 In the **Device Properties** table, select *1PPS* from the **Time Sync Mode** drop-down list.
- 3 Click **Close**.
- 4 Click **Setup**→**Connect** to start the Sonar Head.
- 5 Click **Display**→**Output Messages Window**.
Observe that the **Output Messages** window opens.
- 6 Select the **Head Messages** tab in the **Output Messages** window.
Alternatively, navigate to C:\KML\M3_V0254\LOGS. Open the latest HEAD log file in a text editor.
- 7 Read through the **Output Messages** log and look for errors.

Example

The following is an example of some 1PPS log entries, including an explanation of what each entry means.

- **INF System Time 1518282830 s 653 ms 734 us**
A response to host cmd for the sonar head's current timestamp.
- **INF 1PPS: 10 pulses received in 10s**
The number of 1PPS pulses received in ten seconds. If you are seeing less than ten pulses received, then 1PPS is not working as expected.

- **INF SNSUDP IP Addr 192.168.1.233:13685, len=39**
INF \$GPZDA,171355.432,10,02,2018,00,00*5F

The sensor data string received. The ZDA string will be displayed if valid, otherwise bytes of the received string will be displayed.

- **INF PPS preLD**
INF ZDA: 1518282835 2018/02/10/ 15:32:17.910

If valid ZDA data is being received, it will be displayed here in units of Epoch seconds GMT. This value will be rounded up to the next integer second and pre-loaded in an FPGA staging register. This register will reset the timestamp clock at the next 1PPS pulse.

- **INF PPS 1518282835.999s 20000000**

The timestamp latched at the 1PPS leading edge. This timestamp should be close to the most recent ZDA data received.

Related topics

[Upgrading the Sonar Head, page 83](#)

[Interface specifications, page 206](#)

Operating procedures

Topics

[Setting up and running the sonar, page 33](#)

[Saving and recalling screen captures, page 65](#)

[Using sonar view overlays, page 75](#)

[Configuring the Sonar Head, page 82](#)

Setting up and running the sonar

Topics

[Starting operation of the Sonar Head, page 34](#)

[Configuring your preferences, page 35](#)

[Choosing the sonar range, page 36](#)

[Choosing a sonar application, page 37](#)

[Adjusting the sonar view, page 38](#)

[Applying filters, page 42](#)

[Adjusting the TVG \(Time Variable Gain\) setting, page 42](#)

[Setting up external sensors, page 43](#)

[Defining a custom sensor, page 46](#)

[Controlling the rotator, page 49](#)

[Setting up dual M3 Sonars, page 54](#)

Starting operation of the Sonar Head

To start operation of the M3 Sonar sonar, you may need to make sure that the Sonar Head has been discovered.

Prerequisites

- The M3 software must be running.
- The sound speed has been configured in **Setup**→**System Configuration**→**Deployment**→**Master Reference**.

Procedure


- 1 Click **Setup**→**Connect** to start the Sonar Head.

Wait for “Sync OK” to appear on the status bar before collecting data. It takes two minutes to synchronize the Sonar Head clock.

Tip

*By default, the M3 software uses the computer’s time to set the Sonar Head clock (Host mode). You can change the time synchronization settings by clicking **Setup**→**System Configuration**→**Sonar Setup**→**Time Sync Mode**.*

- 2 If you see an error in the **Output Messages** window, make sure that the Sonar Head has been discovered.
 - a Click **Setup**→**System Configuration**→**Devices**→**Sonar Setup**.
 - b Click **Discover Sonar Heads** to search for the sonar on the network.



- c If the Sonar Head is found, select it, then click **Use Discovered Head**.
A discovered Sonar Head appears in the **Online Sonar Heads** list. If the Sonar Head does not appear, the Ethernet connection between the Sonar Processor and Sonar Head has not been established.
- d Click **Close**.

Related topics

[Status bar, page 99](#)

[System Configuration dialog box - Sonar Setup page, page 146](#)

Configuring your preferences

You may wish to set up the system preferences to use measurement units appropriate to your location, or to choose a preferred save location for your recorded sonar data.

Context

The **Preferences** dialog box is used to set up system preferences such as units of measure, time format, etc. This dialog box also allows you to select the save location for screenshot images and recorded sonar data files.

Procedure

- 1 Click **Setup**→**Preferences**.
- 2 Choose the unit of measurement for all the readouts related to range and distances in the M3 Sonar system user interface.
- 3 Choose whether you would like to display the range and bearing or X and Y coordinates of your mouse cursor position.
- 4 Fill out the **Overlay Text** boxes if you wish to display information on your screenshots and data recordings.
- 5 Choose your desired **File Saving** settings.
- 6 Select **Close** to save the chosen settings and close the dialog box.

Related topics

[Preferences dialog, page 138](#)

Choosing the sonar range

The **Range** function allows you to specify the maximum theoretical vertical depth and horizontal distance covered by the M3 Sonar.

Context

The M3 Sonar Sonar Head can operate at different predefined near and far ranges. The range values you can select vary depending on the current frequency and selected sonar application.

The range value is defined from the Sonar Head.


Note

You cannot change the range until the Sonar Head is connected. Right-clicking in the sonar view and the range slider bar will both be disabled until the sonar is running.

Even though you can choose a high range value, that does not mean that you can detect your targets in the same range. The range value only defines the range shown in the views. Actual target detection will always depend on the operating environment, such as water temperature, salinity, interference and layers in the water column.

Procedure

- 1 Click **Setup**→**Connect** to start the Sonar Head.
- 2 Right-click inside the sonar view to display the range menu.



- 3 Select the desired near and far range from the menu.

Note

*You can change the units of measurement in the **Preferences** dialog box.*



- 4 You can increase or decrease the range using the range slider bar to the left of the sonar view.

Click the top arrows to increase or decrease the far range.

Note

*To change the depth range settings in the **3D Point Cloud** window, click **Depth**, uncheck the **Adaptive Palette** box, enter the top and bottom depth, then click **Apply**.*

Result

The range is displayed with measured intervals in the sonar view. The current range will be updated when the Sonar Head is running.

Tip

*Enabling **Depth Tracking** will automatically adjust the range according to the current depth when the head is running. To enable this feature, select the **Depth Tracking** checkbox in the **Profiling Settings** dialog box.*

Choosing a sonar application

Choosing an appropriate sonar application can improve the quality of your data. As the M3 Sonar has both imaging and profiling capabilities, you will also need to choose either a Profiling, or an Imaging application.

Context

Note

*You cannot select a sonar application until the Sonar Head is connected. All **Sonar Applications** menu items will be greyed out until the sonar is running.*

*The selection of sonar applications presented in the **Sonar Applications** menu depends on the current Sonar Head frequency.*

The **Sonar Applications** menu lists various operating modes used for different applications. Each mode has its own pre-defined characteristics, such as differing ranges, angular resolutions, and pulse types.

If you don't see the sonar application that you need in the menu, you may need to add it to the list. You can configure which applications will appear by opening the **Customize Apps** dialog box, which is the last item in this list.

Tip

Each sonar application has its own TVG profile. Before changing the TVG settings, select the sonar application you want to configure from the **Sonar applications list**. Click the **TVG** button. This button is located on the tool bar.

Procedure

- 1 Click **Setup**→**Connect** to start the Sonar Head.
- 2 Select **Sonar Apps** from the menu on the top bar.
- 3 Select an appropriate sonar application from the list.
 - a If you wish to gather imaging data, select an imaging sonar application from the list.

We recommend a maximum vessel speed of five knots for imaging applications.

Tip

For high-quality images at a short range, use one of the *EIQ* modes (500-kHz transducer only) or *Imaging Enhanced* (available on frequencies from 700-kHz to 1400-kHz). We recommend a maximum vessel speed of two knots for *EIQ* mode and 0.5 knots for *EIQ - Fine* mode.

- b If you wish to gather profiling data, select a profiling sonar application from the list.

Use this sonar application for the automated point extraction of the sea bottom or structures to create a real-time 3D Point Cloud.
 - c Select one of the test apps to troubleshoot performance issues.

Related topics

[Sonar Applications menu, page 108](#)

Adjusting the sonar view

All echo information offered by the M3 Sonar is shown in the sonar view.

Context

The **Display Widget** allows you to adjust the filter strength, change the display gain, and choose your echo colours. You can drag sliders with the mouse to increase or decrease parameter values. For fine adjustments, use the mouse scroll wheel to move the slider by one increment.

Note

*If you have a high-frequency M3 Sonar transducer, you can change the frequency using the **Display Widget**.*

The **Display** menu allows you to configure a number of options in the sonar view, including making the sonar view full screen and adjusting the annotations, palette, or sector orientation. Functions to improve image quality, such as a speckle filter and automatic sidelobe reduction, are also available in the **Display** menu.

Tip


*You can change the physical size of the sonar view by clicking on the left view border, then dragging it to create a smaller or larger window. You can also make the sonar view full screen by clicking **Display**→**Full Screen** or by clicking the **Show Full Screen** button in the tool bar.*

Procedure

1 Use the **Display Widget** to adjust the sonar view according to your preferences.

- a Click the **Display Widget** icon. This icon is located in the lower-right corner of the sonar view.
- b If you have a high-frequency transducer, click one of the buttons to select a frequency (in kHz).

The frequency buttons will not appear if you are using a 500 kHz transducer.
- c To adjust the strength of an enabled filter in the sonar view (such as Average Filter or Edge Enhancement), drag the **Filter** slider to increase or decrease the filter effect.



Note

*The **Filter** slider will not appear if no filters are enabled. Note that filter settings will not be saved when the software is closed.*

- d To adjust the display gain manually, check the box and drag the **Gain** slider to increase or decrease the gain.

Display Gain controls the "amount" of echo that is displayed, in other words the "strength" or "intensity" of the echo presentation. Uncheck the box if you want the software to adjust the gain automatically.

Note

*Adjusting the display gain manually will disable the **Sidelobe Reduction** function (found in the **Display** menu).*

- e Drag the **Contrast** slider to increase or decrease the sonar view display contrast.
- f To choose your echo colours, right-click on the **Palette** bar to cycle through the colour scale options.

Which colour scale to use is mainly a personal preference based on ambient light conditions, the nature of the echoes and your own experience.

- g Click the **Display Widget** icon to hide the widget.

2 Use the **Display** menu to control the visual aspects of the system, and to show or hide various elements in the presentation.

a Click **Full Screen** to make the sonar view full screen.

Press the **Esc** key to exit full-screen mode.

b Click **Annotations** to enable or disable the bearing and range annotations in the sonar view.

c Select **Font Size** to increase or decrease the size of the annotations in the sonar view.


d Select **Palette** to choose your preferred echo colours. Which colour scale to use is mainly a personal preference based on ambient light conditions, the nature of the echoes and your own experience.

e Select **Sector Orientation** to choose a different angle of orientation for the sonar view. Enter an angle (in degrees) into the **Orientation** dialog box, then click **Apply** to rotate the sonar view to your chosen angle.

f If your Sonar Head is forward looking, click **Heading Overlay** to enable or disable this feature. When this feature is enabled, the degree annotations in the sonar view will change to reflect the current sonar heading.

g Click **Speckle Filter** to enable or disable this function. This filter reduces noise (the grainy “salt-and-pepper” pattern) in uniform areas of the sonar view. Distinguishable details in features and targets will be retained.

h Click **Sidelobe Reduction** to enable or disable automatic sidelobe reduction. This function improves overall image quality by reducing the sidelobes of strong targets.



Tip

*To change the colour scale of the 3D Point Cloud, click **Depth**, check the **Adaptive Palette** box, then click **Apply**.*

Applying filters

You can apply an averaging, background removal, or an edge enhancement filter to the sonar view.

Context

These buttons are located on the tool bar.



Procedure

- 1 Click one of the filter buttons.
Observe the changes in the sonar view.
- 2 Increase or decrease the filter effect.
 - a Click the **Display Widget** icon.
This icon is located in the lower-right corner of the sonar view.
 - b Drag the **Filter** slider to adjust the strength of the filter.
- 3 Click the **No Filter** button to turn off all filters.

Related topics

[Filters, page 203](#)

Adjusting the TVG (Time Variable Gain) setting

You can adjust the time variable gain for each sonar application in the **TVG Setup** dialog box.

Context

TVG (Time Variable Gain) compensates for the loss of acoustic energy due to geometric spreading and absorption.

Procedure

- 1 Click **Setup** → **Connect** to start the Sonar Head.
- 2 Select the sonar application you wish to configure from the **Sonar applications list** on the top bar.

Note _____

Each sonar application has its own TVG profile.

- 3 Click the **TVG** button.

This button is located on the tool bar.



- 4 Drag the sliders to adjust the A, B, C, and L Factors.
Click the arrow buttons to make small adjustments.
- 5 Click **Apply** to save the settings.

Note

If you are using a high-frequency M3 Sonar, the TVG profiles will not be saved when closing the software — default values will apply when switching to a new frequency or when starting up the M3 software.

Related topics

[TVG Setup dialog box, page 200](#)

Setting up external sensors

If you wish to add external sensors (such as a GPS to provide navigation information) to your system, you will need to add them on the **Sensors Setup** page. You will also need to set the sensor properties so that the M3 software communicates properly with your sensor.

Prerequisites

Make sure that your external sensors are installed and physically connected to the M3 Sonar system with the proper cables.

Procedure


- 1 On the Sonar Processor desktop, double-click the M3 Sonar icon to start the software.
- 2 Click **Setup**→**System Configuration**→**Devices**→**Sensors Setup**.
- 3 Configure your external sensors in the dialog box.

- a Click **Add Device**.
- b Select the type of sensor you are using from the **Protocol** drop-down list.

Note _____

In most cases, you can select a standard NMEA datagram for your sensor type. For example, select HDT for your vessel heading sensor, or GGA for your GPS position sensor.

- c Click in the **Name** field and enter a label for the sensor (for example, *Hemisphere VS330*).
 - d Configure the serial port settings for the sensor by selecting the correct values from the drop-down lists.
- 4 Test each sensor to make sure that the NMEA string is being received by the M3 software.
 - a Select each sensor device and click the **Test Device** button.
 - b Make sure that the NMEA sensor string is being displayed in the **Port Monitor** box.




- c Click **Stop Test** when done.
- 5 Make your external sensors a Master Reference.
 - a Select the **Deployment**→**Master Reference** tab.

On the **Master Reference** page, you can assign any external sensors you have set up as the primary source for various types of navigational data.

- b Select the sensor that you set up earlier from the drop-down list beside the appropriate Master Reference parameter.

You should see the name in the drop-down list that you assigned earlier (in the **Name** field on the **Sensors Setup** page).




Tip

*When using the M3 Sonar for imaging, set up sensors for **Position** and **Heading** if you want to create GeoTiff files or create a real-time mosaic. When using the M3 Sonar for Bathymetry or Profiling, set up sensors for **Position**, **Heading**, **Pitch/Roll**, and **Heave** as a minimum.*

- 6 If necessary, configure the Mounting Offsets.

Note

You will only need to configure the Mounting Offsets if you set up a position sensor (such as a GPS antenna) in the previous steps. Inaccurate mounting offsets will display your sonar data incorrectly in the 3D Point Cloud and sonar view.



- a Select the **Deployment**→**Mounting Offsets** tab.
- b Measure and record the position and angle of the Sonar Head transducer (centre of the face) relative to your position sensor.
- c Enter the X, Y, and Z offsets, as well as the Pitch Roll, and Yaw angles that you measured earlier into the **Value** fields.

- d Select the correct **Orientation** from the drop-down list.

Match the orientation to the physical installation of your Sonar Head. For example, if the transducer face is pointing down towards the sea bottom for a bathymetry application, select *Downward*.

Defining a custom sensor

You will find many supported sensor formats in the **Protocol** drop-down list found on the **Sensors Setup** page in the **System Configuration** dialog box. However, if a particular third-party sensor format is not listed there, you can create it (using the third-party sensor specification as your guide).

Context

The **Define Custom Sensor** dialog box allows you to import sensor strings from third-party sensors or ROV systems. The configuration wizard in this dialog box will guide you through the process.

This dialog box is opened from the **Setup** menu.

Procedure

- 1 Click **Setup**→**Define Custom Sensor**.
Observe that the **Define Custom Sensor** dialog box opens.

Define Sensor Format

Message ID:

Delimiter(s): Space ' ' Comma ',' Semicolon ';' Star '*'

Termination CR LF CR+LF

Sensor Format:

Message ID: Enter one or more characters for the start of the sensor sentence. The Message ID is pre-defined in the sensor specification. For example, ":" or "\$GPRMC". Do not enter any strings into this field that are used in the rest of the sensor sentence.

Delimiter(s): Select one or more characters used to separate each string in the sentence. Each character selected is used as one delimiter and is pre-defined in the sensor specification.

Termination: Select the ending ASCII character defined in the sensor specification – carriage return, line feed, or both.

Sensor Format: To define the sensor format, enter the Message ID again, along with one or more of the three-letter strings from the list on the right that matches the transmitted data type in the sensor specification. Separate each string with your chosen delimiters. If any part of the sensor sentence in the specification cannot be found on the right-side list, use the "Ignored field" string.

For example: ":" ALT DEP HDG ROL PIT" defines a sensor sentence with the Message ID ":" and five fields for Altitude, Depth, Heading, Roll, and Pitch separated by space delimiters.

ALT: Altitude
DEP: Depth
HDG: Heading
HEA: Heave
PIT: Pitch
ROL: Roll
LAT: Latitude
LON: Longitude
SSP: SoundSpeed
III: Ignored field

< Back Next > Cancel

- 2 Enter in the Message ID.

The start (prefix) of the sensor sentence. Refer to the manufacturer's sensor specification to determine what to use. For example, ":" or "\$GPRMC".

- 3 Select one or more delimiters.

The character used to separate each string in the sentence. You can select more than one if necessary - each character will be treated as one delimiter. Refer to the manufacturer's sensor specification to determine what to use.

- 4 Select the correct termination character.

The ASCII character that tells the software where the sensor string ends. Options include a carriage return (CR), line feed (LF), or both. Refer to the manufacturer's sensor specification to determine what to use.

- 5 Enter in the sensor format.

For example: ":" ALT DEP HDG ROL PIT" defines a sensor sentence with the Message ID ":" and five fields for Altitude, Depth, Heading, Roll, and Pitch separated by space delimiters.

- a Enter the Message ID, followed by the chosen delimiter.
- b Enter in one or more of the three-letter definition strings from the list on the right side of the dialog box.

Match each three-letter string with the data type in the sensor specification. For example, enter "ALT" for the part of the sensor sentence corresponding to Altitude, and so on.

- c Separate each string with the chosen delimiters.
- d If you can't find any part of the sensor sentence on the right-side list, then enter the "Ignored field" string (III).

This will tell the software to skip over this part of the sensor sentence when parsing the string.

- 6 Select **Next** to continue.

- 7 Provide specifications for each three-letter definition string you entered into the **Sensor Format** field.

- a If applicable, select a data type.

If the data type in the sensor sentence is an integer (for example, 1002), then select *Whole number*. If the data type in the sensor sentence is a float (for example, 10.02), then select *Decimal number*. Refer to the manufacturer's sensor specification to determine what to use.

- b If applicable, select a Latitude/Longitude Format.

Choose whether to display the latitude/longitude format in degrees, degrees and minutes, or degrees, minutes, and seconds.

- c If necessary, enter in a unit scale factor.

The dialog box will tell you what unit scale the software expects (meters, degrees, meters per second, and so on). If the data type in the specification does not match the required unit scale, you must enter an appropriate scaling factor. For example, if the Depth data type is in feet, then you must enter 0.3048 to scale the depth value to meters.

- 8 Select **Next** to continue.

- 9 Enter in a unique name for your custom sensor.
This name will appear in the **Protocol** drop-down list found on the **Sensors Setup** page in the **System Configuration** dialog box.
- 10 Select **Finish** to close the wizard.
- 11 Set up the custom sensor in the software to start using it.
- Click **Setup**→**System Configuration**→**Devices**→**Sensors Setup**.
 - Click **Add Device**.
 - Give the sensor a name, then select the custom sensor from the **Protocol** drop-down list.
 - Select the **Deployment**→**Master Reference** tab.
 - Select the sensor that you set up earlier from the drop-down list beside the appropriate Master Reference parameter.

Tip

To change or remove the custom sensor, edit or delete the custom sensor XML file. You can find the custom sensor XML file in C:\KML\M3_V0254\BIN\DefinedSensors.

Related topics

[Define Custom Sensor dialog box, page 133](#)

Controlling the rotator

You can control your rotator(s) with the **Rotator Control** dialog box.

Prerequisites

- You must set up your rotator(s) by clicking **Setup**→**System Configuration**→**Devices**→**Rotators Setup**.


- If you have a single-axis rotator, choose the type of control you would like in the **Rotator Test** dialog box. On the **Rotators Setup** page, select your single-axis rotator in the **Rotators** table, click the **Test Device** button, then select either *3D Scan* or *Pan/Tilt Control* from the **Rotator Control Dialog Type** drop-down list.
- If necessary, configure your rotator axis offsets relative to the sonar by clicking **Setup**→**System Configuration**→**Deployment**→**Mounting Offsets**.
- This dialog box will only appear if the sonar is running.

Context


If you have more than one rotator installed, then one dialog box for each rotator will appear.

The controls you see will depend on the type of rotator you have and which control type you have selected.


Single-axis rotator with Pan/Tilt controls:



Single-axis rotator with 3D Scan controls:



Dual-axes rotator:



Procedure

- 1 Click **Setup**→**Connect** to start the Sonar Head.
Observe that the **Rotator Control** dialog box opens.
- 2 Click **Connect** to enable the rotator controls or **Disconnect** to disable the rotator controls.
- 3 If you have a Kongsberg 806-00480000 rotator, click the **Calibrate** button.
- 4 If you are using Pan and Tilt controls, click the arrow buttons to move the Sonar Head.

If you have a single-axis rotator, the arrow buttons will either pan or tilt, depending on the orientation of the rotator installation.

Tip _____
 Drag the slider to control the rotator speed.

- 5 If you are performing a 3D scan, then set up the scan sector before starting the scan.

Note _____
 The green wedge in the dialog box graphic represents the sector to be scanned.

- a Drag the **Width** slider to define the scan coverage.

- b Drag the **Center** slider to define the centre of the scan coverage.
- c Drag the **Speed** slider to set the rotator speed. Slower speeds will result in higher angular resolutions.
- d Check the **Record** box to record data during the scan.
- e Click **Start Scan**.

The rotator will move to one side of the sector, start the scan, then stop the scan at the other side of the sector.

Tip

*To export the 3D scan into third-party software, ensure either **Image and Profile** or **Profile Only** is selected in the **Profiling Settings** dialog box. Click the circular icon in the top-right corner of the sonar view to open the **Menu Widget**. Click **Export Data**.*

Related topics

[Rotator Test dialog box, page 156](#)

[System Configuration dialog box - Mounting Offsets page, page 163](#)

[System Configuration dialog box - Rotators Setup page, page 153](#)

Setting up dual M3 Sonars


You can run two sonars simultaneously, either on the same computer or on separate computers. The two sonars must be synchronized so that they do not interfere with each other.

Context


When running two M3 Sonars simultaneously, they must be connected to each other with a sync cable (Part Number 436-02810000). The M3 Sonar models you use must therefore have a sync connector. M3 Sonar models without a sync connector cannot be used in a dual-sonar installation.

The following system diagrams show examples of different dual-sonar installations:

Dual M3 Sonar setup using QINSy (third-party software)




Dual M3 Sonar Setup using the ROV survey MUX and exporting data to the EIVA NaviSuite computer




Procedure

- 1 Install the M3 Sonar software.
 - a If you are running two sonars on separate computers, perform a normal installation of the M3 software on each computer.

Select the **Standard Installation** option when going through the software installation wizard.



- b If you are running two sonars on the same computer, run the software installation wizard and select the **Dual-M3 on Same PC** option.



The installation wizard will create two icons on the computer desktop: **M3 2.5.4 Master** and **M3 2.5.4 Slave**.

Note

Each sonar will be running on its own instance of software with separate settings, even when selecting the dual M3 Sonar option. You must configure each instance ("Master" and "Slave") separately. If you are exporting data to a third party, then you will need to export it on different ports for "Master" and "Slave".


- 2 If you are running two sonars on the same network, then assign each sonar a different IP address.

Refer to the following procedure: [Changing the Sonar Head IP Address, page 85](#)

If necessary, perform this procedure for both the "Master" and the "Slave" sonars. For example, if the "Master" sonar uses the factory default 192.168.1.234 address, then you could change the "Slave" sonar's IP address to 192.168.1.236.

- 3 Configure the "Master" sonar.

- a Double click **M3 2.5.4 Master** to run the software for the “Master” sonar.
If you are running two sonars on separate computers, run the M3 software on the computer where you wish to run the “Master” sonar.
- b Click **Setup**→**System Configuration**→**Devices**→**Sonar Setup**.
- c Click **Discover Sonar Heads** to search for the sonar on the network.



Observe that two sonar heads appear in the **Online Sonar Heads** list with each sonar displaying a different Serial Number and IP Address.

- d Select the sonar to use as the “Master”, then select the **Use Discovered Head** button.

Note _____

After you have made your selection, the next time you run the software, it will remember which sonar head is the “Master”.

- e Under **Device Properties**, select *Master - Immediate Start* from the **Trigger Mode** drop-down list.

This mode will trigger the “Slave” sonar by sending it a sync pulse.

- f Under **Device Properties**, select *1PPS* from the **Time Sync Mode** drop-down list.

Important _____

In order for 1PPS to work, you must send NMEA ZDA to both sonars on UDP port 31100 at 1 Hz.


- g Enter a value of *125* Mbps into the **Override Network Link Speed** text box.
Setting the link rate will prevent the M3 software from reducing the ping rate when detecting a marginal link.
- h Select **Close** to save the chosen settings and close the dialog box.
- i If you have external sensors, follow the procedure “Setting up external sensors” so that the “Master” sonar can communicate with them. If you do not have a Sound Speed Sensor, you must enter the closest-known sound speed manually.

- j If you wish to export the sonar data to third-party software, you must make sure the “Master” sonar exports data on a different port than the “Slave” sonar.
 - a Select **File**→**Exporting Format**→**Profile Point (.all)**.
The default “.all” format is the Kongsberg EM datagram standard and can be processed by third-party software.
 - b Click **Setup**→**Preferences**.
 - c In the **UDP Data Export** section, enter the “Master” UDP port into the **Port for .ALL format** field. This port must also be configured in the third-party software to receive the data.

Important

The “Master” UDP port must be different from the “Slave” UDP port. For example, set the “Master” UDP port to 20002 and the “Slave” UDP port to 20003.

- d Enter the IP Address of the computer running the third-party software into the **Remote IP Address** field.
To use the local computer, enter *127.0.0.1* (for example, if your third-party software is installed on the same computer as the M3 software).
 - e Make sure that the **Export to File** box is unchecked.
 - f Select **Close** to save the chosen settings and close the dialog box.
- 4 Configure the “Slave” sonar.
- a Double click **M3 2.5.4 Slave** to run the software for the “Slave” sonar.
If you are running two sonars on separate computers, run the M3 software on the computer where you wish to run the “Slave” sonar.
 - b Click **Setup**→**System Configuration**→**Devices**→**Sonar Setup**.
 - c Click **Discover Sonar Heads** to search for the sonar on the network.



Observe that two sonar heads appear in the **Online Sonar Heads** list with each sonar displaying a different Serial Number and IP Address.

- d Select the sonar to use as the “Slave”, then select the **Use Discovered Head** button.

Note _____

After you have made your selection, the next time you run the software, it will remember which sonar head is the “Slave”.

- e Under **Device Properties**, select *Slave - External Pulse Triggered* from the **Trigger Mode** drop-down list.

In this mode, the "Slave" sonar will wait for a sync pulse from the "Master". The “Slave” software will only update the sonar view when the “Master” sonar is running. If the “Master” sonar is off or paused, the “Slave” software will not update the sonar view or export data.

- f Under **Device Properties**, select *1PPS* from the **Time Sync Mode** drop-down list.

Important _____

In order for 1PPS to work, you must send NMEA ZDA to both sonars on UDP port 31100 at 1 Hz.

- g Enter a value of *125* Mbps into the **Override Network Link Speed** text box.

Setting the link rate will prevent the M3 software from reducing the ping rate when detecting a marginal link.

- h Select **Close** to save the chosen settings and close the dialog box.

- i If you have external sensors, follow the procedure “Setting up external sensors” so that the “Slave” sonar can communicate with them. If you do not have a Sound Speed Sensor, you must enter the closest-known sound speed manually.

- j If you wish to export the sonar data to third-party software, you must make sure the “Master” sonar exports data on a different port than the “Slave” sonar.

- a Select **File**→**Exporting Format**→**Profile Point (.all)**.

The default “.all” format is the Kongsberg EM datagram standard and can be processed by third-party software.


- b Click **Setup**→**Preferences**.

- c In the **UDP Data Export** section, enter the “Slave” UDP port into the **Port for .ALL format** field. This port must also be configured in the third-party software to receive the data.

Important

The “Master” UDP port must be different from the “Slave” UDP port. For example, set the “Master” UDP port to 20002 and the “Slave” UDP port to 20003.


- d Enter the IP Address of the computer running the third-party software into the **Remote IP Address** field.
To use the local computer, enter *127.0.0.1* (for example, if your third-party software is installed on the same computer as the M3 software).
 - e Make sure that the **Export to File** box is unchecked.
 - f Select **Close** to save the chosen settings and close the dialog box.
- 5 Start operation of “Master” sonar.
- a Double click **M3 2.5.4 Master** to run the software for the “Master” sonar.
 - b Click **Setup**→**Connect** to start the Sonar Head.
 - c Select **Sonar Apps** from the menu on the top bar.
 - d To avoid interference or a duplicate bottom return, select *Profiling - Dual Head Master* from the list. You can also select *Profiling*, depending on your application.



Tip

*If you can't find the sonar application you are looking for in the **Sonar Apps** menu, select **Customize Apps** to add it.*

- e In the **Display Mode** section of the **Profiling Settings** dialog box, select *Image and Profile* or *Profile Only* to display profile points in the **3D Point Cloud** window.



Tip _____
 If the profiling settings are not visible, click **Display**→**Profiling Settings** to open the **Profiling Settings** dialog box.

- f For the best profiling results, select *Split Beam* from the **Algorithm** drop-down list and select *Strongest* from the **Point Selection** drop-down list.


Make sure that the **Depth Tracking** box is checked.

- g If necessary, change the sector orientation to match the orientation of the sonar. For example, 0° sector orientation is best when the sonar is pointing forwards, and 180° sector orientation is suitable for when the sonar is pointing down.

Select **Display**→**Sector Orientation**.

- h If you wish to export the sonar data to third-party software, click the circular icon in the top-right corner of the sonar view to open the **Menu Widget**.

Click **Export Data**.




- i Click **Display**→**Output Messages Window**.
 Make sure there are no errors shown in the **Output Messages** window under the **Host Messages** or **Head Messages** tab.

Note

When power is disconnected to the sonars, a “Failed to connect to 192.168.1.xxx:30” message will appear. The software will continue attempting to reconnect until the sonar is powered back on or the cables have been reconnected.


- 6 Start operation of “Slave” sonar.
 - a Double click **M3 2.5.4 Slave** to run the software for the “Slave” sonar.
 - b Click **Setup**→**Connect** to start the Sonar Head.
 - c Select **Sonar Apps** from the menu on the top bar.
 - d To avoid interference or a duplicate bottom return, select *Profiling - Dual Head Master* from the list. You can also select *Profiling*, depending on your application.



Tip

*If you can't find the sonar application you are looking for in the **Sonar Apps** menu, select **Customize Apps** to add it.*

- e In the **Display Mode** section of the **Profiling Settings** dialog box, select *Image and Profile* or *Profile Only* to display profile points in the **3D Point Cloud** window.



Tip

If the profiling settings are not visible, click **Display**→**Profiling Settings** to open the **Profiling Settings dialog box**.

- f For the best profiling results, select *Split Beam* from the **Algorithm** drop-down list and select *Strongest* from the **Point Selection** drop-down list.


Make sure that the **Depth Tracking** box is checked.

- g If necessary, change the sector orientation to match the orientation of the sonar. For example, 0° sector orientation is best when the sonar is pointing forwards, and 180° sector orientation is suitable for when the sonar is pointing down.

Select **Display**→**Sector Orientation**.

- h If you wish to export the sonar data to third-party software, click the circular icon in the top-right corner of the sonar view to open the **Menu Widget**.

Click **Export Data**.



- i Click **Display**→**Output Messages Window**.

Make sure there are no errors shown in the **Output Messages** window under the **Host Messages** or **Head Messages** tab.

Note

When power is disconnected to the sonars, a “Failed to connect to 192.168.1.xxx:30” message will appear. The software will continue attempting to reconnect until the sonar is powered back on or the cables have been reconnected.

Saving and recalling screen captures

Topics

[Saving and retrieving images, page 66](#)

[Recording sonar data, page 66](#)

[Playing back a recording, page 68](#)

[Converting your recording format, page 69](#)

[Converting your recordings to video, page 70](#)

[Saving GeoTiff files, page 72](#)

Saving and retrieving images

With one click, you can capture an image of the sonar view — either with overlays or without overlays.

Prerequisites

Open the **Preferences** dialog box to change the default save location, choose your own filename, and add overlay text.

Procedure

- 1 Click the **Save image with overlay** button.

If you want to save the sonar view without overlays, click the **Save image without overlay** button instead.



These buttons are located on the tool bar.

Note

*A “Save As” dialog box will appear if you have checked the **Prompt User for Filename** box in the **Preferences** dialog box.*

- 2 Retrieve your images and view them.
 - a On the Windows Taskbar, click the **File Explorer** shortcut.
Alternatively, press **Win + E** to open the **File Explorer**.
 - b Click **This PC**.
 - c Navigate to C:\KML\M3_V0254\Images.
Alternatively, navigate to where you saved your images earlier.
 - d Open the images with your preferred image viewer..

Recording sonar data

You can record a sonar data sequence and save it in a time-stamped digital format. You can also re-record data during playback to capture a smaller clip of the data set.

Prerequisites

- Open the **Preferences** dialog box to change the default save location, choose your own filename, and add overlay text.
- Click **File**→**Recording Format** to choose between recording raw sonar data (to a “.mmb” file) or recording beamformed sonar data (to a “.imb” file).

Context

Running the sonar and recording simultaneously (real-time recording) requires significant processing power, especially if trying to save beamformed data (an “.imb” file).


For real-time recording, we recommend using the “.mmb” recording format.

If you prefer an “.imb” file, we recommend either using the **Convert to Video Format** dialog box to convert the file from “.mmb” to “.imb”, or re-recording the data during playback instead of real-time recording.

Procedure

- 1 Click the circular icon in the top-right corner of the sonar view to open the **Menu Widget**.
- 2 Click **Record Data** or press **F4** to start recording.

When recording is in progress, a flashing recording icon will appear in the top-right corner of the sonar view. The recording filename will also appear here. Observe the percentage of disk space free for recording on the far right of status bar.



Note

*A “Save As” dialog box will appear if you have checked the **Prompt User for Filename** box in the **Preferences** dialog box.*

- 3 Click **Stop Recording** or press **F4** when you are done.

Your recording will be saved under the folder “C:\KML\M3_V0254\Recordings” by default. You can change this save location in the **Preferences** dialog box.

Related topics

[Recording Format, page 116](#)

Playing back a recording

You can play back a previously recorded data file to view the sonar image sequence captured during operation of the Sonar Head.

Prerequisites

Open the **Preferences** dialog box to change the default save location, choose your own filename, and add overlay text.

Tip

When the M3 software isn't running, double-click on a recording file to open the software and begin playback automatically.

Procedure

- 1 Click **File**→**Playback**.

A file browser dialog box opens to let you choose which file to play back.

- 2 Select the file you want to play back and click **Open**.

Playback will begin. The **Playback Console** will automatically open to offer you additional functionality.

- 3 Control playback using the **Playback Console**.

You can stop, pause, fast forward, or advance through the recording one ping at a time. You can also repeat playback of the file on a never-ending loop.

Tip

You can also apply filters to the playback, such as the Average or Edge Enhancement filters.

- 4 When you are done, click the **Stop** button on the Playback Console, then close the console.

Alternatively, click **File**→**Stop Playback**.

Related topics

[Convert to Video Format dialog box, page 117](#)

[Playback Console, page 127](#)

Converting your recording format

If you want to keep your recordings in .mmb format but process your data in .imb format, you can convert .mmb files to .imb files using a batch conversion utility.

Context


The M3 software records sonar data in two formats — raw element data (.mmb) or beamformed data (.imb).

If you wish to convert a selected clip of data, you can play back an .mmb file and record the clip as an .imb file. However, if you wish to batch convert many files, a conversion utility is provided with the M3 software.

Note

If files are recorded in .imb format, they cannot be converted to .mmb.

You can find the conversion utility in the folder C:\KML\M3_V0254\bin\M3Converter.exe.



Procedure

- 1 Select *Recording File* to convert a single .mmb recording.
Alternatively, select *Recording Folder* and *Include Subdirectories* to convert all your .mmb files.
- 2 Click the **Browse** button beside **Source** to select your .mmb file or folder.
- 3 Click the **Browse** button beside **Destination** to select where you want to save the converted files.

If you are saving a single recording, then you must give the file a name.

Tip

When converting the contents of a folder, the files will automatically be renamed. However, we recommend selecting different source and destination folders to avoid filename duplications.

- 4 Click **Convert**.

A dialog box will notify you when the file conversion is complete. Click **OK** to dismiss it.

Related topics

[Recording Format, page 116](#)


Converting your recordings to video

As data files can only be opened by the M3 software, converting data files to video allows you to share them more easily with others.

Context

The **Convert to Video Format** dialog box allows you to convert an MMB or IMB file to a video file (MP4 format only).

Use this dialog box if you want to export a recording to a format that is playable by any media player. This function is useful if you wish to share recordings with others who do not have the M3 software installed on their computers, or if you wish to upload your recording to an online service.



Procedure

- 1 Click **File**→**Convert To Video**.
Observe that the **Convert To Video Format** dialog box opens.
- 2 Select the desired video conversion settings.

- 3 To convert a single data file, select the **Source File** button and use the browser window to select the file.

To batch convert all sonar recordings in a selected folder, select the **Folder Conversion** checkbox, then select the **Source Folder** button to select the folder in the browser window.

Note

*If you select this option, you will not be able to change the name of the converted files. Auto Name will be selected under the **Target file naming convention** drop-down list and the other options will not be available.*

- 4 Click the **Convert** button to start the conversion.
- 5 Wait until the progress bar is complete before viewing the videos.

If you are performing a batch conversion, an additional progress bar will appear at the bottom of the dialog box to show you how many files are being converted.

Related topics

[Convert to Video Format dialog box, page 117](#)

Saving GeoTiff files

GeoTiff files are TIFF files which have geographic data embedded within them. The geographic data can then be used to position the image in the correct location and geometry on the screen.

Prerequisites

- You must have a position and heading sensor connected to your system and sending data to the M3 software. To add sensors, click **Setup**→**System Configuration**→**Devices**→**Sensors Setup**.
- Your Master Reference must be set up to use the sensor inputs or to use a fixed location by entering Latitude, Longitude, and Heading. To set up the Master Reference, click **Setup**→**System Configuration**→**Deployment**→**Master Reference**.
- Your mounting offsets must be configured correctly. To configure your mounting offsets, click **Setup**→**System Configuration**→**Deployment**→**Mounting Offsets**.
- You must be using the appropriate coordinate system for your current location. To choose your coordinate system, click **Setup**→**Geo Projection**.

Context

GeoTiff files contain georeferencing information and can be opened in third-party software, such as Google Earth Pro.



Procedure

- 1 Click **Setup**→**Preferences**.
- 2 Fill out the fields in the **GeoTiff Auto Save** section.
 - a To automatically save a GeoTiff file every set number of meters, select **Distance** and enter a value. To automatically save a GeoTiff file every set number of seconds, select **Time** and enter a value.
 - b To save a cropped GeoTiff image for mosaicking purposes, enter the percentage to crop.

- 3 Press F11 to enable or disable GeoTiff auto save. The status bar will display “GeoTiff” in green when auto save is enabled.

When GeoTiff autosave is enabled, GeoTiff files will be saved automatically and continuously based on travel distance or time.

Alternatively, press **F10** to save a single GeoTiff file to your images folder. Your images will be saved under the folder “C:\KML\M3_V0254\Images” by default. You can change this save location through the **Preferences** dialog box.

Related topics

[System Configuration dialog box - Sensors Setup page, page 150](#)

[System Configuration dialog box - Master Reference page, page 160](#)

[System Configuration dialog box - Mounting Offsets page, page 163](#)

[Geo Projection dialog box, page 136](#)

[Preferences dialog, page 138](#)

Using sonar view overlays

Topics

[Measuring distances, page 76](#)

[Measuring angles, page 77](#)

[Defining an area, page 78](#)

[Placing text labels, page 78](#)

[Placing reference cursors, page 79](#)

[Placing target markers, page 80](#)

Measuring distances

You can use the tape measure tool to draw a line in the sonar view and measure the distance between two points.

Context

Measures distances on the sonar view. Also allows you to place a measurement overlay on the sonar view.

Procedure

- 1 Click the **Tape Measure** button.

This button is located on the tool bar.



- 2 Click and hold the left mouse button on your first target, then drag the mouse to your second target.

The length and bearing between the targets is displayed dynamically.

Note

The measurement line will not remain on the display when you release the mouse button.

- 3 To keep the measurement line on the display, place a measurement overlay.

- a Click and hold the right mouse button on your first target.
- b Drag the mouse to your second target and release the mouse button.
- c Move the mouse to a place on the screen where you would like to place the overlay length and bearing label.

Note

Once the measurement overlay is placed, you can use the default arrow cursor to drag the length and bearing label to a position on the screen where it is more legible.

- d Click the left mouse button to place the overlay.

Tip

*To remove this overlay, click the **Wiper** button, then click the overlay.*

Related topics

[Tape Measure, page 196](#)


Measuring angles

You can use the protractor to measure the angle between two lines, then place the resulting overlay in the sonar view.

Context

The protractor tool measures the angle between a baseline and a second line that intersects the baseline.

Procedure

- 1 Click the **Protractor** button.
This button is located on the tool bar. 
- 2 In the sonar view, click the point where you want to start the baseline.
- 3 Click the point where you want to end the baseline.
The second line will appear.
- 4 Lock one end of the second line to the baseline.
 - a Choose where you want the second line to intersect the baseline by moving the mouse along the length of the baseline.
 - b When ready, click the left mouse button.
- 5 Choose where you want the second line to end.
 - a Move the mouse to any point on either side of the baseline to adjust both the length and angle of the second line.
 - b Click the left mouse button to place the overlay.

Tip _____

*To remove this overlay, click the **Wiper** button, then click the overlay.*

Related topics

[Protractor, page 196](#)

Defining an area

You can use the string measure tool to define an area. The size and perimeter of the area will be calculated for you.

Context

Defines and measures perimeters and areas. Allows you to place an area overlay on the sonar view.

Procedure

- 1 Click the **String Measure** button.
This button is located on the tool bar.
- 2 Click anywhere in the sonar view to start a point.
- 3 Move to the second point, then click again.
- 4 Click as many times as necessary to create the required area.
- 5 Double-click on the last point to finish.



The area will automatically be closed, and a rectangular label will appear providing information about the area and perimeter.

- 6 Move the label to a position on the screen where it is most legible, then click the left mouse button to place it.

Tip

*To remove this overlay, click the **Wiper** button, then click the overlay.*

Related topics

[String Measure, page 196](#)


Placing text labels

The text label tool allows you to place comments on the screen.

Prerequisites

Text labels will not appear on sonar data recordings. To place a text overlay on a recording, click **Setup**→**Preferences** and fill out the **Overlay Text** boxes.

Procedure

- 1 Click the **Text Label** button.
This button is located on the tool bar. 
- 2 In the sonar view, click the area of interest that you want to label.
- 3 Click and hold the left mouse button on the label overlay and drag it to a place on the screen where the text is legible.
- 4 Label the area of interest.
 - a Double-click on the label overlay to open an **Edit Text Box** dialog box.
 - b Enter the desired text into the dialog box.
 - c Click **OK** when done.
- 5 If the text you entered does not fit within the text label overlay, you can resize the label by clicking on the label border, then dragging it to create a larger label.

Tip _____

*To remove this overlay, click the **Wiper** button, then click the overlay.*


Related topics

[Text Label, page 197](#)

Placing reference cursors

You can place one or two reference cursors as overlays on the sonar view. When you place two cursors, an additional overlay will appear with information about the cursors.

Context

The Reference Cursor buttons are used to mark points of interest and to determine the range and bearing of these points (relative to the Sonar Head). 

These buttons are located on the tool bar.

Procedure

- 1 Click the **Reference Cursor 1** button.

- 2 Move the mouse to where you want to place the cursor.

Tip _____

To make fine adjustments to the cursor position, drop a reference cursor into a Zoom window.

- 3 Click the left mouse button to place the cursor as an overlay in the sonar view.

The range and bearing of the cursor's position — relative to the Sonar Head — is shown in the bottom-left corner of the view.

- 4 Click the **Reference Cursor 2** button.

- 5 Move the mouse to where you want to place the cursor.

- 6 Click the left mouse button to place the cursor as an overlay in the sonar view.

The range and bearing of the cursor's position — relative to the Sonar Head — is shown in the bottom-left corner of the view. "Delta" shows the range and bearing from cursor 1 to cursor 2.

Tip _____

*To remove this overlay, click the **Wiper** button, then click the overlay.*

Related topics

[Reference cursors, page 197](#)

Placing target markers

The Target Marker function is primarily used for remotely operated vehicle (ROV) navigation. Third-party ROV software can use the time and location information to steer the ROV toward the target.

Context

You can press 0–9 to place a marker in the sonar view that is stamped with time and location information. In addition, you can export this information to a serial or UDP port.

Procedure

- 1 To start using target markers, click **Display**→**Enable Target Marker**.

Observe that the **Target Marker Export** dialog box opens.

- 2 Choose a serial port from the drop-down list.

Note _____

The default serial settings cannot be altered.

- 3 Click **OK** to enable serial port export.

Alternatively, click **Cancel** to use the Target Marker function without exporting to a serial port.

UDP export is always available, whether you enable serial port export or not.

- 4 Move the mouse cursor to the location in the sonar view where you wish to place a marker.
- 5 Press any number key from 0 to 9 on your keyboard to place a marker.

Note _____

Target markers cannot be moved once they are placed.

- 6 To remove all target markers from the sonar view, click **Display**→**Delete All Markers**.

Alternatively, use the wiper located on the tool bar to remove individual markers.

Related topics

[Target Marker Export dialog box, page 125](#)

Configuring the Sonar Head

Topics

[Upgrading the Sonar Head, page 83](#)

[Changing the Sonar Head IP Address, page 85](#)

Upgrading the Sonar Head

The Sonar Head has both software and firmware. You can upgrade these with the latest versions obtained from Kongsberg Discovery. You can also use this same procedure to downgrade software and firmware versions.

Prerequisites

If you are performing a full upgrade, you will need to write three files to the Sonar Head before power cycling the unit:

- The Sonar Head software file (.ASW)
- The Sonar Head transmit firmware file (.TXF)
- The Sonar Head receive firmware file (.RXF)

Contact us to obtain these files.

- support.vancouver@kd.kongsberg.com

Context

The **Head Firmware Configuration** dialog box allows you to upgrade the Sonar Head firmware. This dialog box is only available when the Sonar Head is connected and paused.

Procedure

- 1 Click **Setup**→**Connect** to start the Sonar Head.
- 2 Open the **Head Firmware Configuration** dialog box.
 - a Click the circular icon in the top-right corner of the sonar view to open the **Menu Widget**.
 - b Click **Pause**.
 - c Click **Setup**→**Head Firmware Configuration**.
Observe that the **Head Firmware Configuration** dialog box opens.
- 3 Take note of the current versions of software and firmware (Rx HW, Rx SW, Tx HW, and Tx SW).
The version numbers are listed in the **Head Firmware Configuration** dialog box.
- 4 Write the latest firmware and software to the Sonar Head.
 - a Select *Head Application Software* under **Configuration type**.

- b Click the file folder icon under **Configuration file** to browse and select the .ASW file on your local drive.

Tip _____

Use the .ASW file with the same version as the .RXF file.

- c Click **Write**.
Observe that a confirmation dialog box opens.

- d Click **Yes** to start the upgrade.

Tip _____

*If you click **Cancel** or **Stop**, the upgrade process will be aborted. The Sonar Head software and firmware will not be changed.*

- e Select *RX FPGA Configuration* (receive firmware) under **Configuration type**.

- f Click the file folder icon under **Configuration file** to browse and select the .RXF file on your local drive.

- g Click **Write**, then click **Yes** to start the upgrade.

Note _____

This file may take a few minutes to program.

- h Select *TX FPGA Configuration* (transmit firmware) under **Configuration type**.

- i Click the file folder icon under **Configuration file** to browse and select the .TXF file on your local drive.

- j Click **Write**, then click **Yes** to start the upgrade.

Note _____

This file may take a few minutes to program.

- k Close the **Head Firmware Configuration** dialog box.

- 5 Confirm the upgrade was successful.

- a Click **Setup**→**Disconnect**.

- b Disconnect the power to the Sonar Head, then power it up again.

- c Wait ten seconds for the software to discover the Sonar Head.

- d Click **Setup**→**Connect** to start the Sonar Head.

- e Click **Setup**→**Head Firmware Configuration**.
Observe that the **Head Firmware Configuration** dialog box opens.
- f Confirm that the software and firmware has been upgraded from the versions you took note of earlier.

Note

*The receive hardware (RX HW) and software (RX SW) must both be on the same version. In other words, the application software (.ASW) and FPGA RX Firmware (.RXF) files being upgraded must have the same version numbers. The Sonar Head will make sure the versions are the same. If not, the version numbers shown in the **Head Firmware Configuration** dialog box will not be updated.*

Related topics

[Head Firmware Configuration dialog box, page 145](#)

Changing the Sonar Head IP Address

If you have a unique network environment (such as an IP Address conflict between two devices on your network), or you are installing a second Sonar Head, then you will need to change the IP Address of the Sonar Head.

Context

The **Head Network Setup** dialog box allows you to change the Sonar Head network parameters, such as the IP address. This dialog box is only available when the Sonar Head is connected and paused.

You can program the IP address and the IP port of the Sonar Head for various network environments. The factory default IP address is 192.168.1.234, and the default port number is 30.

Procedure

- 1 Set up the Sonar Head and M3 software.
 - a Connect the Sonar Head directly to the computer network card. Do not connect through an intermediary device, such as a network switch or router.
 - b Power up the Sonar Head.
 - c Double click the M3 icon on the desktop to run the M3 software.
 - d Click **Setup**→**Connect** to start the Sonar Head.

- e Click the circular icon in the top-right corner of the sonar view to open the **Menu Widget**.
- f Click **Pause**.
- 2 Write the new IP Address to the Sonar Head.
 - a Click **Setup**→**Head Network Setup**.

Observe that the **Head Network Setup** dialog box opens.
 - b Click **Read from Head** to refresh the fields in the **Head Network Setup** table.
 - c Enter the new IP Address in the table.

Tip _____

Avoid setting the third octet of the IP Address to a value of 100 or more, as you may experience periodic drops in traffic. We recommend leaving the third octet set to the default value (1). For example, xxx.xxx.1.xxx.

 - d Click **Write to Head**.

Observe that a confirmation dialog box opens.
 - e Click **Yes** to confirm.

Wait for the write operation to complete.
 - f Close the **Head Network Setup** dialog box.
- 3 Click **Setup**→**Disconnect**.
- 4 Apply the new IP Address to the Sonar Head.
 - a Power off the Sonar Head for three seconds, then power it back up.
 - b If necessary, change the computer's network adapter address to place it on the same network as the Sonar Head.
 - c Click **Setup**→**System Configuration**→**Devices**→**Sonar Setup**.
 - d Click the **Discover Sonar Heads** button.

The Sonar Head with its updated IP Address should appear in the **Online Sonar Heads** table.
 - e Select the Sonar Head in the **Online Sonar Heads** table, then click the **Use Discovered Head** button.
 - f Close the **System Configuration** dialog box.
- 5 Click **Setup**→**Connect** to start the Sonar Head.

Related topics

[Defining the IP address on the computer's network adapter, page 23](#)

[Head Network Setup dialog box, page 142](#)

User interface

Topics

[Presentation overview, page 89](#)

[The M3 software menu system, page 91](#)

[Sonar view, page 92](#)

[3D Point Cloud, page 95](#)


[Tool bar description, page 97](#)

[Status bar, page 99](#)

Presentation overview

By default, the display presentation covers the entire screen.

This M3 Sonar screen capture shows you a typical data replay situation.



The presentation provides you with a lot of information. The sonar view presents sonar echo data. The 3D Point Cloud presents profile point data that can be rotated in three dimensions. The menu system on the top gives you easy access to all the functionality offered by the M3 software. The tool bar provides buttons for functions, filters, and sonar view overlays. The bottom **Output Messages** window and bottom status bar provide diagnostic messages.

You can resize a window by clicking on the window border, then dragging it to create a smaller or larger window. Click the pin icon on the window title bar to auto hide the window. To show the window, hover your mouse over the labelled tab that appears on the side of the presentation.

A Menu system

The menu system is located on the top of the presentation. To open any of the menus, click the menu title.

B 3D Point Cloud

Profiling mode allows you to view a real-time 3D point cloud of the sea bottom or structures under the water. You can zoom into or rotate the real-time 3D point cloud data, as well as switch to a project, top, or side view.

C Range slider bar

When the sonar is running, you can increase or decrease the range using the range slider bar to the left of the sonar view. Click the top arrows to increase or decrease the far range.

D Profiling Settings

In the **Profiling Settings** dialog box, you can choose to display only the sonar view, only the 3D Point Cloud, or both. The profile point data can be exported to a file so that third-party software can extract depth, distance, and volume measurements.

E Output Messages

The **Output Messages** window displays information, diagnostic, and error messages. There are two tabs in this window: one for host messages and one for head messages.

F Sonar view

All echo information offered by the M3 Sonar is shown in the sonar view.

G Tool bar

The tool bar provides access to useful functions, such as the ability to take a screenshot or change your TVG settings. In addition, several measuring tools are available.

H Information Widget

The **Information Widget** displays sonar pulse details as well as vessel speed, sound speed, heading, and latitude/longitude coordinates from external sensors.

I Menu Widget

The **Menu Widget** provides controls to record and export data, play or pause playback, and configure the grid.

J Display Widget

The **Display Widget** allows you to adjust the filter strength, change the display gain, and choose your echo colours. If you have a high-frequency M3 Sonar transducer, you can change the frequency using the **Display Widget**.

K Playback Console

Control playback using the **Playback Console**. You can stop, pause, fast forward, or advance through the recording one ping at a time. You can also repeat playback of the file on a never-ending loop.


L Status bar

The status bar is located at the bottom of the M3 Sonar presentation. It allows you to view the system status and disk space. You can also access detailed telemetry info.

The M3 software menu system

The menu system is located on the top of the presentation. To open any of the menus, click the menu title.

To select operational parameters on the M3 Sonar, use the menu system. The menus are organized in a tree structure. Some of the menu items open dialog boxes to offer additional choices.




- A** The **File** menu allows you to open a recorded file, as well as choose the recording and exporting formats of your data files. You can also load your user settings from a previous software version.
- B** Use the **Display** menu to control the visual aspects of the system, and to show or hide various elements in the presentation.
- C** You can connect to the Sonar Head using the **Setup** menu. You can also configure the system, choose your preferences, set up the coordinate system, upgrade the Sonar Head firmware, or change the Sonar Head IP Address.
- D** The **Sonar Applications** menu lists various operating modes used for different applications. Each mode has its own pre-defined characteristics, such as differing ranges, angular resolutions, and pulse types. You can configure which applications will appear by opening the **Customize Apps** dialog box, which is the last item in this list. All **Sonar Applications** menu items will be greyed out until the sonar is running. The selection of sonar applications presented in the **Sonar Applications** menu depends on the current Sonar Head frequency.
- E** The **Advanced** menu is intended for experienced users or for testing purposes and is not required for normal operation of the M3 Sonar. This menu requires a software license key, and will not appear if you do not have one.
- F** The **Help** menu allows you to view hardware and software information in the **About M3** dialog box. You can also open the M3 Sonar *Reference Manual* from this menu.

Sonar view

All echo information offered by the M3 Sonar is shown in the sonar view.

Description



The range and bearing or X/Y coordinates of the current mouse cursor position is shown at the bottom of the sonar view.

Click the icon in the top-left corner of the sonar view to open the **Information Widget**. The **Information Widget** displays sonar pulse details as well as vessel speed, sound speed, heading, and latitude/longitude coordinates from external sensors.


Click the icon in the bottom-right corner of the sonar view to open the **Display Widget**. The **Display Widget** allows you to adjust the filter strength, change the display gain, and choose your echo colours.

Right-click inside the sonar view to display the range menu. You can increase or decrease the range using the range slider bar to the left of the sonar view. Enabling Depth Tracking will automatically adjust the range according to the current depth when the head is running.

To enable this feature, select the **Depth Tracking** checkbox in the **Profiling Settings** dialog box.

Tip

*You can change the shape of the grid (range rings), or turn it off. Click the icon in the top-right corner of the sonar view to open the **Menu Widget**, then click **Grid** to cycle through the options.*



You can change the physical size of the sonar view by clicking on the left view border, then dragging it to create a smaller or larger window. You can also make the sonar view full screen by clicking **Display**→**Full Screen** or by clicking the **Show Full Screen** button in the tool bar.

Interpreting the sonar view

The sonar view is a map of the echo returns over the scanned area.

A sequence of colours is used to show the relative strengths of the echo returns. Several colour scale options are available. Most of them use darker colours to indicate weak returns, and brighter colours to indicate stronger returns.

Bright spots in the image indicate strong sonar targets. Generally, bright spots indicate a hard, highly reflective surface. Dark spots in the image indicate either areas of low reflectivity (soft areas), or possibly an acoustic shadow zone behind a target.

Most targets will block the transmission of sound — either by reflecting it, or absorbing it. This will leave a shadowed area behind the target that is not ensonified and therefore

will not generate any echoes. This is very similar to the shadow formed when an object is illuminated with a single light source. The shadow behind a target can often yield more information about the target than the reflections from the target itself. The shadow will often reveal the shape of the target, but you must remember that the shape will usually be distorted according to the position of the Sonar Head relative to the target and the bottom, and according to the slope of the bottom. It is often possible to estimate the height of a bottom target based on the length of the shadow and the known height of the Sonar Head.

Noise and interference

Acoustic noise and bubble interference can affect the quality of the sonar view image.


It is usually easy to recognize interference from other acoustic sources such as echo sounders, pingers, and other sonars. These sources all produce pulses at regularly timed intervals and will therefore tend to create a regular or symmetrical pattern of blips on the screen. Mechanical noise sources such as propellers, hydraulic pumps, and thrusters, are usually more directional and tend to show up only when the sonar is pointed directly at them.

In addition, sonar signals are easily blocked by air or gas bubbles in the water or on the transducer face. As an example, the aeration present in the wake of a vessel will often last for ten to twenty minutes and effectively mask out most sonar returns on the far side. The aeration partially blocks the outgoing pulses as well as any returns. Another source of gas bubbles can be found when a sea bottom containing decomposing organic matter is disturbed by dredging or ploughing.

3D Point Cloud

The 3D Point Cloud presents profile point data that can be rotated in three dimensions.

Description



Profiling mode allows you to view a real-time 3D point cloud of the sea bottom or structures under the water. The profile point data can be exported to a file so that third-party software can extract depth, distance, and volume measurements.

Tip

*In the **Profiling Settings** dialog box, you can choose to display only the sonar view, only the 3D Point Cloud, or both. If you can't see the 3D Point Cloud, ensure that either **Image and Profile** or **Profile Only** are selected. You can also change the point cloud display parameters in this dialog box.*


To change the depth range settings in the **3D Point Cloud** window, click **Depth**, uncheck the **Adaptive Palette** box, enter the top and bottom depth, then click **Apply**. To change the colour scale of the 3D Point Cloud, click **Depth**, check the **Adaptive Palette** box, then click **Apply**.

The following controls can be used in the **3D Point Cloud** window.

- Use the mouse scroll wheel to zoom in or out.
- To rotate the point cloud, press and hold the left mouse button, then move the mouse.
- To clear the point cloud, double click the right mouse button.

The following buttons, found in the top-right corner of the **3D Point Cloud** window, offer different views and measurements. The currently selected view or tool will be underlined.

- A Project view:** An isometric view where you can rotate the point cloud in three dimensions.
- B Top view:** A top-down view where you can measure distances or place target markers.
- C Side view:** You can see the elevation of the points in the side view.
- D Marker:** Click to select this tool in the Top view, then click anywhere in the **3D Point Cloud** window to place a target marker overlay. You can place as many markers as you need.



Note _____

Georeference information on each marker will be added to a “.kml” file in the folder “C:\KML\M3_V0254\Recordings”.


- E Tape Measure:** Click to select this tool in the Top view, then click and hold the left mouse button and drag the mouse to measure distances.

Related topics

[Profiling Settings dialog box, page 128](#)

Tool bar description

The tool bar provides buttons for functions, filters, and sonar view overlays.



The tool bar provides access to useful functions, such as the ability to take a screenshot or change your TVG settings. In addition, several measuring tools are available.

A Arrow

Click to use the default arrow cursor. With the default cursor you can select and manipulate objects on the screen.

B Wiper

Removes items from the sonar view. When selected, click on each overlay you wish to delete.

C Zoom windows

You can open up to four true zoom windows when running a Sonar Head.

D Tape Measure

Measures distances on the sonar view. Also allows you to place a measurement overlay on the sonar view.

E Protractor

You can use the protractor to measure the angle between two lines, then place the resulting overlay in the sonar view.

F String Measure

You can use the string measure tool to define an area. The size and perimeter of the area will be calculated for you.

G Text Label

The text label tool allows you to place comments on the screen.

H Reference Cursor 1

I Reference Cursor 2

You can place one or two reference cursors as overlays on the sonar view. When you place two cursors, an additional overlay will appear with information about the cursors.

J Image Quality Analysis System

The Image Quality Analysis System (IQAS) analyzes the image quality of a point target, or can be used to measure a known point target against a specification.

K Y1

Horizontal line overlay that can be used to mark the depth of the natural seabed (for use when excavating).

L Y2

Horizontal line overlay that can be used to mark the depth of a trenching target (for use when excavating).

M Show Full Screen

Click **Full Screen** to make the sonar view full screen. Press the **Esc** key to exit full-screen mode.

N Save image with overlays

Click this button to save sonar view images, including any overlays you've placed in the sonar views.

O Save image without overlays

Click this button to save sonar view images, excluding any overlays you've placed in the sonar views.

P TVG Setup dialog box

TVG (Time Variable Gain) compensates for the loss of acoustic energy due to geometric spreading and absorption.

Q Average Filter

Clicking the "A" button will enable the Average Filter. This filter reduces noise. Slow-moving features persist on-screen.

R Background Removal

Clicking the "B" button will enable the Background Removal filter. This filter removes stationary parts of the background to enhance moving objects (such as fish, for example).

S Edge Enhancement


Clicking the "E" button will enable Edge Enhancement. This filter enhances the edge of moving features.

T No Filter

Disables any filters. The sonar view will display an unfiltered sonar image.

Status bar

The status bar is located at the bottom of the M3 Sonar presentation. It allows you to view the system status and disk space. If network logging is enabled, you can view the sonar connection performance. You can also access detailed telemetry info.



A Recording information

Displays the filename when you are recording data.

B Depth Tracking

If Depth Tracking is enabled, then this text will appear when the head is running.

C Time synchronization status

Displays the status of the time synchronization process if *Host* Time Sync Mode is enabled. “Syncing” displays during time synchronization (which takes approximately two minutes). “Sync OK” displays when time synchronization is complete. “Sync Error” displays if the computer clock is irregular (for example, due to interference from the time source). In this case, restart the synchronization process by disconnecting, then reconnecting, the Sonar Head.

D Sound Speed

The sound speed is displayed in green (after filtering and thresholding). This text will display in blue during playback if **Override Sound Speed** is enabled.

E GeoTiff

If GeoTiffs are automatically being created, then this text will display in green.

F Disk space monitor

Displays the percentage of hard drive space you have available for data recordings.

G System status

Shows the system status, such as “Active” when the system is connected to a Sonar Head, “Inactive” when not connected, or “Playback” when replaying a recorded file. Clicking the system status text will open a **Connection Status** window. You can click on **M3 Sonar** in the **Connection Status** window to open a **Head Status** window showing telemetry information.

H Sonar connection performance

If network logging is enabled in the **System Configuration** dialog box, then the ping loss, packet loss, and the last ping data rate will be displayed.

I Offsets

If Mounting Offsets Override is enabled then this text will appear during playback.

Tip

Right-click on the status bar to configure it. You can show or hide any of the information displayed here.

Related topics

[Recording sonar data, page 66](#)

[System Configuration dialog box - Master Reference page, page 160](#)

[System Configuration dialog box - Mounting Offsets page, page 163](#)

[Saving GeoTiff files, page 72](#)

[System Configuration dialog box - Sonar Setup page, page 146](#)

[Starting operation of the Sonar Head, page 34](#)

Menu system

Topics

[File menu, page 102](#)

[Display menu, page 103](#)

[Setup menu, page 106](#)

[Sonar Applications menu, page 108](#)

[Advanced menu, page 112](#)

[Help menu, page 113](#)

File menu

The **File** menu allows you to open a recorded file, as well as choose the recording and exporting formats of your data files. You can also load your user settings from a previous software version.

How to open

To open this menu, click the menu title.

Description

- **Playback**

The *Playback* mode allows you to choose the echo data file(s) you wish to play back.

- **Stop Playback**

Clicking *Stop Playback* will stop the playback of a recording. You can also use the **Playback Console** to control playback.

- **Recording Format**

Click *Recording Format* to choose between recording raw sonar data (to a “.mmb” file) or recording beamformed sonar data (to a “.imb” file).

- **Exporting Format**

You can choose the exporting format for sonar data. The default “.all” format is the Kongsberg EM datagram standard and can be processed by third-party software.

- **Load User Settings**


Click to browse for a “UsersInfo.xml” file (in the folder **C:\KML\M3_V0254\bin\Settings**) from a previous software version. You can import your previous settings to a new version of the M3 software.

- **Convert to Video**

The **Convert to Video Format** dialog box allows you to convert an MMB or IMB file to a video file (MP4 format only).

- **Exit**

Select **Exit** to close the M3 software.



Display menu

Use the **Display** menu to control the visual aspects of the system, and to show or hide various elements in the presentation.

How to open

To open this menu, click the menu title.

Description

- **Enable Target Marker**

Click to enable the Target Marker function. You can press 0–9 to place a marker in the sonar view that is stamped with time and location information. In addition, you can export this information to a serial or UDP port.

- **Delete All Markers**

Click to remove all target markers from the sonar view.

- **Full Screen**

Click **Full Screen** to make the sonar view full screen. Press the **Esc** key to exit full-screen mode.

- **Output Messages window**

Click to show or hide the **Output Messages** window. The **Output Messages** window displays information, diagnostic, and error messages.

- **Playback Console**

Click to show or hide the **Playback Console**. Control playback using the **Playback Console**. You can stop, pause, fast forward, or advance through the recording one ping at a time. You can also repeat playback of the file on a never-ending loop.


- **3D Point Cloud**

Click to show or hide the **3D Point Cloud** window. The 3D Point Cloud presents profile point data that can be rotated in three dimensions.

- **Profiling Settings**

Click to show or hide the **Profiling Settings** dialog box. Profiling mode allows you to view a real-time 3D point cloud of the sea bottom or structures under the water.

- **Rotator Control**



Click to show or hide the **Rotator Control** dialog box for each rotator you have installed.

- **Tool bar**

Click to show or hide the tool bar. The tool bar provides buttons for functions, filters, and sonar view overlays.

- **Annotations**

Click **Annotations** to enable or disable the bearing and range annotations in the sonar view.

- **Font Size**

You can choose between using a normal or a large font size throughout the M3 software.

- **Palette**

Select **Palette** to choose your preferred echo colours. Which colour scale to use is mainly a personal preference based on ambient light conditions, the nature of the echoes and your own experience.

- **Sector Orientation**

Enter an angle (in degrees) into the **Orientation** dialog box, then click **Apply** to rotate the sonar view to your chosen angle.

- **Heading Overlay**

If your Sonar Head is forward looking, click **Heading Overlay** to enable or disable this feature. When this feature is enabled, the degree annotations in the sonar view will change to reflect the current sonar heading.

- **Speckle Filter**

Click **Speckle Filter** to enable or disable this function. This filter reduces noise (the grainy “salt-and-pepper” pattern) in uniform areas of the sonar view. Distinguishable details in features and targets will be retained.

- **Sidelobe Reduction**

Click **Sidelobe Reduction** to enable or disable automatic sidelobe reduction. This function improves overall image quality by reducing the sidelobes of strong targets. Sidelobe reduction is especially useful at short ranges when targets are very close. In addition, the automatic adjustments work well when the sonar is constantly moving, such as on an ROV.

Tip

If you have a software license for advanced features, you can view the automatically-calculated sidelobe reduction ratio or manually adjust the ratio using a slider.

- **Reset to Default Layout**

Click to reset the presentation layout. All windows and dialog boxes will be docked in their default location. In addition, some display elements are hidden by default.

Setup menu

You can connect to the Sonar Head using the **Setup** menu. You can also configure the system, choose your preferences, set up the coordinate system, upgrade the Sonar Head firmware, or change the Sonar Head IP Address.

How to open

To open this menu, click the menu title.


Description

- **Connect**

Click *Connect* to connect to the Sonar Head and start “pinging”.

Note

When the Sonar Head is running, this menu command will change to Disconnect.



- **Define Custom Sensor**

Click to open the **Define Custom Sensor** dialog box. If the sensor protocol you want to use is not available on the **Sensors Setup** page, you can create a custom sensor format in the **Define Custom Sensor** dialog box.

- **Geo Projection**

Click to open the **Geo Projection** dialog box. You can configure the coordinate system using the **Geo Projection** dialog box.

- **Preferences**

Select to open the **Preferences** dialog box. The **Preferences** dialog box is used to set up system preferences such as units of measure, time format, etc.

- **Head Network Setup**

Click to open the **Head Network Setup** dialog box. The **Head Network Setup** dialog box allows you to change the Sonar Head network parameters, such as the IP address. This dialog box is only available when the Sonar Head is connected and paused.

- **Head Firmware Configuration**

Click to open the **Head Firmware Configuration** dialog box. The **Head Firmware Configuration** dialog box allows you to upgrade the Sonar Head firmware. This dialog box is only available when the Sonar Head is connected and paused.

- **System Configuration**

Click to open the **System Configuration** dialog box. This dialog box allows you to set up the Sonar Head, external sensors (such as a GPS or Motion Reference Unit), and rotators. In addition, you can configure the deployment of the M3 Sonar and enter mounting offsets.

Sonar Applications menu

The **Sonar Applications** menu lists various operating modes used for different applications. Each mode has its own pre-defined characteristics, such as differing ranges, angular resolutions, and pulse types.

Note

*You cannot select a sonar application until the Sonar Head is connected. All **Sonar Applications** menu items will be greyed out until the sonar is running.*

*The selection of sonar applications presented in the **Sonar Applications** menu depends on the current Sonar Head frequency. The M3 software will automatically detect the frequency of your Sonar Head and display only the applicable sonar applications.*

How to open

To open this menu, click the menu title.

The following sonar applications are available when using a 500-kHz Sonar Head transducer.

Description

- **EIQ**

This sonar application captures high-quality images. At short ranges the images are relatively insensitive to the motion of the sonar. At longer ranges the sonar should be relatively motionless.

Note

This application is less sensitive to motion than EIQ - Fine.

- **EIQ - Fine**

This sonar application captures very high-quality images. At short ranges the images are relatively insensitive to the motion of the sonar. At longer ranges the sonar should be relatively motionless.

- **EIQ - Ultra Fine**

This sonar application captures the highest quality images possible. At short ranges the images are relatively insensitive to the motion of the sonar. At longer ranges the sonar should be relatively motionless.

- **Ethernet Test - 1000Mbps**

You can test your 1000Mbps link to verify that the link throughput is available. The test uses 80 percent utilization and uses *EIQ - Ultra Fine*.

- **Ethernet Test - 100Mbps**

You can test your 100-Mbps link to make sure that the link throughput is available. The test uses 80 percent utilization and uses *EIQ*.


- **Ethernet Test - 10Mbps**

You can test your 10-Mbps link to make sure that the link throughput is available. The test uses 80 percent utilization and uses *Imaging 30*.

- **Imaging 15**

You can use this sonar application for navigation and obstacle avoidance. This application uses a 15-degree Tx vertical beamwidth.

- **Imaging 3**



Use this sonar application primarily for profiling using a 3-degree Tx vertical beamwidth. You may also use this application for shallow-water obstacle avoidance.

- **Imaging 30**

You can use this sonar application for navigation and obstacle avoidance. This application uses a 30-degree Tx vertical beamwidth.

- **Imaging 30 - Short Range**

You can use this sonar application for the support of manipulator operations, with the highest-speed short-range imaging. Speed and detail are more important than overall image quality.

- **Imaging 7**

You can use this sonar application to provide long-range obstacle avoidance and navigation into the work site. This application uses the highest pulse power. Pulse durations are used to get a reliable long-range detection. The trade-off is a reduction in the ping rate.

- **Profiling**

Use this sonar application for the automated point extraction of the sea bottom or structures to create a real-time 3D Point Cloud. The *Profiling* application has a slow ping repetition rate and is best suited for slow-moving ROVs, trenchers, and ploughs.

- **Profiling - Bathy**

This sonar application is ideal for Bathymetry Surveys.

- **Profiling - Dual Head Master**

You can use this profiling sonar application to generate an alternating sequence of pings and external trigger events. This sequence is used to implement alternate pinging in a dual-head profiling system.

- **Profiling - Dual Head Slave**

You can use this profiling sonar application to generate an alternating sequence of pings and external trigger events. This sequence is used to implement alternate pinging in a dual-head profiling system.

- **Profiling - Fast**

This sonar application performs using much higher ping rates than the normal *Profiling* application. This application is ideal for surface-vessel surveys.

- **ROV Navigation**

This sonar application automatically switches between *EIQ - Fine*, *EIQ*, and *Imaging 30* applications. *EIQ - Fine* is used to provide the highest-resolution images with a

good image update rate at short ranges. *EIQ* is used for medium ranges. *Imaging 30* is used for long ranges.

- **Rub Test**

Use this sonar application as part of a system test to make sure that the transducer is receiving a signal. Rub the transducer and make sure that bright streaks or rings appear in the sonar view.

- **Customize Apps**

Click to open the **Customize Apps** dialog box. You can select which sonar applications will appear in the **Sonar Apps** menu.

The following sonar applications are available only when using a high-frequency Sonar Head (such as a 700-kHz to 1400-kHz transducer, for example).

In addition, some of the sonar applications listed above are also available when using a high-frequency Sonar Head, but not all.

- **Imaging**

You can use this sonar application for navigation and obstacle avoidance. This application uses a 30-degree Tx vertical beamwidth.

- **Imaging Enhanced**

Use this sonar application for imaging or obstacle avoidance using one of the eIQ elements. This application uses a Time Delay FFT beamformer to produce a high-quality image.

- **Profiling - HiRes**

Use this sonar application if you have a high-frequency Sonar Head and require a higher horizontal beam resolution. This profiling mode uses the maximum number of beams (512) but has a slower ping rate as it uses more computational power. High-resolution profiling is ideal for applications such as pipeline inspections, fish behaviour studies, and gas plume detections.

Related topics

[Choosing a sonar application, page 37](#)

Advanced menu

The **Advanced** menu is intended for experienced users or for testing purposes and is not required for normal operation of the M3 Sonar. This menu requires a software license key, and will not appear if you do not have one.

How to open

To open this menu, click the menu title.

Description

- **Power User Settings**

Click to open the **Power User Settings** dialog box. The **Power User Settings** dialog box allows you to configure advanced controls. You can also override the beamlist or processing type during playback. The Ping Rate, Update Rate, and Mode ID are displayed for your information.

- **Program Head**

Click to open the **Program Head** dialog box. You can perform advanced tasks in the **Program Head** dialog box, such as configuring production settings, making head corrections, or changing transmit pulse definitions. This dialog box is only available when the Sonar Head is connected and paused.

- **Convert to Profile**

Click to open the **Profile Batch Conversion** dialog box. The **Profile Batch Conversion** dialog box allows you to convert many data files at once into another format. You can convert “.mmb”, “.imb”, and “.pmb” files.

- **Raw Data Frequency Spectrum**


Click to open the **Raw Data Spectrum** window. The **Raw Data Spectrum** window allows you to find and observe any noise in the data.

- **Enable Network Sniffer**

Click to open the **Network Sniffer** window. The **Network Sniffer** window allows you to monitor network traffic in real-time. When this feature is enabled, the menu option will change to **Disable Network Sniffer**.

Note

*To use this feature, you must run the M3 software as an administrator (right-click on the icon and select **Run as administrator**).*



Help menu

The **Help** menu allows you to view hardware and software information in the **About M3** dialog box. You can also open the M3 Sonar *Reference Manual* from this menu.


How to open

To open this menu, click the menu title.

Description

About M3

The **About** dialog box identifies the current software version. The version described in this publication is 2.5.4.



User Manual

Click **User Manual** to open the M3 Sonar *Reference Manual* in PDF format. This manual is only applicable to the software version you are using. If you are using an older version of software, it will not be the latest version.

Tip

Contact your local dealer or distributor for the latest software versions, and download the latest manuals from <https://www.kongsbergdiscovery.net/>.

Functions and dialog boxes

Topics

[File menu, page 115](#)

[Display menu, page 103](#)

[Setup menu, page 106](#)

[Sonar Applications menu, page 108](#)

[Advanced menu, page 112](#)

[Help menu, page 113](#)

[Tool bar description, page 97](#)

File menu

The **File** menu allows you to open a recorded file, as well as choose the recording and exporting formats of your data files. You can also load your user settings from a previous software version.

How to open

To open this menu, click the menu title.

Description

- **Playback**

The *Playback* mode allows you to choose the echo data file(s) you wish to play back.

- **Stop Playback**

Clicking *Stop Playback* will stop the playback of a recording. You can also use the **Playback Console** to control playback.

- **Recording Format**

Click *Recording Format* to choose between recording raw sonar data (to a “.mmb” file) or recording beamformed sonar data (to a “.imb” file).

- **Exporting Format**

You can choose the exporting format for sonar data. The default “.all” format is the Kongsberg EM datagram standard and can be processed by third-party software.

- **Load User Settings**


Click to browse for a “UsersInfo.xml” file (in the folder **C:\KML\M3_V0254\bin\Settings**) from a previous software version. You can import your previous settings to a new version of the M3 software.

- **Convert to Video**

The **Convert to Video Format** dialog box allows you to convert an MMB or IMB file to a video file (MP4 format only).

- **Exit**

Select **Exit** to close the M3 software.



Topics

[Recording Format, page 116](#)

[Exporting Format, page 117](#)

[Convert to Video Format dialog box, page 117](#)

Recording Format

Click *Recording Format* to choose between recording raw sonar data (to a “.mmb” file) or recording beamformed sonar data (to a “.imb” file).

The following processed data output formats are available.

.mmb

.mmb is the default recommended recording format.

This is raw element data, not beamformed, in a 16-bit fixed-point complex format. This format allows great flexibility in how the data is processed and allows you to do your own beamforming or profile-point extraction. The data body size is determined by the number of elements and the number of samples.

If you want to keep your recordings in .mmb format but process your data in .imb format, you can convert .mmb files to .imb files using a batch conversion utility.

.imb

This format consists of beamformed data.

You can choose between a 32-bit floating point complex or 8-bit integer magnitude format. Select the 8-bit format only if you are interested in imaging pixel data and want a reduced data file size. The 8-bit format takes up a quarter of the 32-bit format's size.

Data body size is determined by the number of beams and samples. Different modes may form a different number of beams. Therefore, data body size may change depending upon the mode.

.imb files are easier to work with when using the M3 Sonar MATLAB toolbox and can be used with third-party software, such as Echoview.

Note

If files are recorded in .imb format, they cannot be converted to .mmb.

Related topics

[Recording sonar data, page 66](#)

[Converting your recording format, page 69](#)

Exporting Format

You can choose the exporting format for sonar data. The default “.all” format is the Kongsberg EM datagram standard and can be processed by third-party software.

.xyz

This is an ASCII point cloud format for M3 rotator 3D profiling data on a tripod only.

.all (recommended default)


This M3 profiling data format uses the Kongsberg EM datagram standard. The “.all” file can be processed by third-party software such as Hypack, QINSy, Caris, and EIVA.

Convert to Video Format dialog box

The **Convert to Video Format** dialog box allows you to convert an MMB or IMB file to a video file (MP4 format only).

How to open

This dialog box is opened from the **File** menu.



Description

Use this dialog box if you want to export a recording to a format that is playable by any media player. This function is useful if you wish to share recordings with others who do not have the M3 software installed on their computers, or if you wish to upload your recording to an online service.

Details

Frame Rate

- **Match Ping Rate**

Select if you want the converted video frame time to match the ping time.

- **One Frame per Ping**

Select if you want each video frame to be converted from each sonar ping.

Gain Control

- **Auto**

Select to automatically adjust the gain during the video conversion.

- **Manual**

Select to apply a fixed gain setting to the entire video. Use this setting when auto gain produces a video that is either too dark or too bright for a particular data set. Click and drag the slider to choose the gain setting.

Resolution

You can select the desired resolution for the converted video. Note that higher resolutions require longer conversion times and result in larger file sizes.

Note _____

*Due to space limitations, text overlays will not be included when converting to a resolution of 640x480p (the **Display Overlay Text** checkbox will not appear). Select a higher resolution if you wish to include text overlays.*

Quality

Select your video quality. A higher quality produces a video with a higher bit rate and less compression. The result is a better-looking video, but a larger file size. If storage space is a concern, choosing a lower quality will produce smaller files.

Palette

Select your preferred echo colours for the converted video file. Which colour scale to use is mainly a personal preference based on ambient light conditions, the nature of the echoes and your own experience.

Display Grid

You can choose whether to show the grid (range rings) in the video. You can also select the desired grid shape.

Date/Time

You can choose whether to display Coordinated Universal Time (UTC) Time or Local Time in the **Information Widget** in the sonar view.

Note

During the winter, Local Time equals standard time. During the summer, Local Time equals Daylight Saving Time (DST). Note that the offset between Local Time and UTC Time is not constant, but varies in locations where DST is used.

Display Position

You can choose whether the video will display your position coordinates in the **Information Widget** in the sonar view. You can also choose whether to display latitude and longitude coordinates (geographic system) or a Northing/Easting projection (projected coordinate system).

Display Filter

You can choose whether to apply a filter to the sonar view video. You can select which type of filter to apply. Drag the slider to increase or decrease the strength of the filter.

Display Mirror

Select this checkbox to mirror the sonar image in the converted video file (port to starboard, starboard to port).

Display Sensor Data

Select this checkbox to show sensor data in the **Information Widget** in the sonar view.

Display Overlay Text

Select this checkbox to show text overlays. To create text overlays for your video, click **Setup**→**Preferences** and fill out the **Overlay Text** boxes.

Sidelobe Suppression

Select this checkbox to enable the **Sidelobe Reduction** function for your video. This function improves overall image quality by reducing the sidelobes of strong targets. Sidelobe reduction is especially useful at short ranges when targets are very close.

Folder Conversion

Select this checkbox to perform a batch conversion of all sonar recordings in a selected folder. If you select this option, you will not be able to change the name of the converted files. *Auto Name* will be selected under the **Target file naming convention** drop-down list and the other options will not be available.

Note

*The **Source File** button will change to **Source Folder**. An additional progress bar will appear at the bottom of the dialog box to show you how many files are being converted.*

Source File/Source Folder

Click this button to select a recording or a folder for conversion (only .mmb or .imb files are supported).

Max File Size

Long data recordings will produce very large file sizes. Select the maximum file size for your video files.

If the maximum file size is reached, but the data conversion is not finished yet, a new file will be created. Each filename created for the converted recording will be given a unique filename with a sequential number.

Target Folder

Click this button to open a browser window where you can select a location for the converted video file(s).

Target file naming convention

Select a name for the converted file. Selecting *Auto name* will preserve the original filename and save the converted file in the same location as the original. Selecting *User defined* will allow you to enter your own filename into the **Target File** box. There are also some predefined filenames available.

Target File

Click this button to select a filename and location for the converted video file. This button is only available if you select *User defined* for the **Target file naming convention**.

Convert

Click this button to start the conversion.

Note

*The range annotations (metres or feet) displayed in the converted video file will be the same as currently configured in the M3 software. You can change the units of measurement in the **Preferences** dialog box.*

Related topics

[Playing back a recording, page 68](#)

[Converting your recordings to video, page 70](#)

Display menu

Use the **Display** menu to control the visual aspects of the system, and to show or hide various elements in the presentation.

How to open

To open this menu, click the menu title.

Description

- **Enable Target Marker**

Click to enable the Target Marker function. You can press 0–9 to place a marker in the sonar view that is stamped with time and location information. In addition, you can export this information to a serial or UDP port.

- **Delete All Markers**

Click to remove all target markers from the sonar view.

- **Full Screen**

Click **Full Screen** to make the sonar view full screen. Press the **Esc** key to exit full-screen mode.

- **Output Messages window**

Click to show or hide the **Output Messages** window. The **Output Messages** window displays information, diagnostic, and error messages.

- **Playback Console**

Click to show or hide the **Playback Console**. Control playback using the **Playback Console**. You can stop, pause, fast forward, or advance through the recording one ping at a time. You can also repeat playback of the file on a never-ending loop.


- **3D Point Cloud**

Click to show or hide the **3D Point Cloud** window. The 3D Point Cloud presents profile point data that can be rotated in three dimensions.

- **Profiling Settings**

Click to show or hide the **Profiling Settings** dialog box. Profiling mode allows you to view a real-time 3D point cloud of the sea bottom or structures under the water.

- **Rotator Control**



Click to show or hide the **Rotator Control** dialog box for each rotator you have installed.

- **Tool bar**

Click to show or hide the tool bar. The tool bar provides buttons for functions, filters, and sonar view overlays.

- **Annotations**

Click **Annotations** to enable or disable the bearing and range annotations in the sonar view.

- **Font Size**

You can choose between using a normal or a large font size throughout the M3 software.

- **Palette**

Select **Palette** to choose your preferred echo colours. Which colour scale to use is mainly a personal preference based on ambient light conditions, the nature of the echoes and your own experience.

- **Sector Orientation**

Enter an angle (in degrees) into the **Orientation** dialog box, then click **Apply** to rotate the sonar view to your chosen angle.

- **Heading Overlay**

If your Sonar Head is forward looking, click **Heading Overlay** to enable or disable this feature. When this feature is enabled, the degree annotations in the sonar view will change to reflect the current sonar heading.

- **Speckle Filter**

Click **Speckle Filter** to enable or disable this function. This filter reduces noise (the grainy “salt-and-pepper” pattern) in uniform areas of the sonar view. Distinguishable details in features and targets will be retained.

- **Sidelobe Reduction**

Click **Sidelobe Reduction** to enable or disable automatic sidelobe reduction. This function improves overall image quality by reducing the sidelobes of strong targets. Sidelobe reduction is especially useful at short ranges when targets are very close. In addition, the automatic adjustments work well when the sonar is constantly moving, such as on an ROV.

Tip

If you have a software license for advanced features, you can view the automatically-calculated sidelobe reduction ratio or manually adjust the ratio using a slider.

- **Reset to Default Layout**

Click to reset the presentation layout. All windows and dialog boxes will be docked in their default location. In addition, some display elements are hidden by default.

Topics

[Target Marker Export dialog box, page 125](#)

[Playback Console, page 127](#)

[Profiling Settings dialog box, page 128](#)

Target Marker Export dialog box

The Target Marker function is primarily used for remotely operated vehicle (ROV) navigation. Third-party ROV software can use the time and location information to steer the ROV toward the target.

How to open

This dialog box is opened from the **Display** menu.

Description


You can place a marker on a target of interest in the sonar view. This marker is stamped with both time and location details. You can export this time and location information to a serial port (or UDP port 20004).

To start using target markers, click **Display**→**Enable Target Marker**.

The **Target Marker Export** dialog box opens when you enable the Target Marker function.

Choose a serial port in the **Target Marker Export** dialog box, then click **OK** to enable serial port export. Click **Cancel** to use the Target Marker function without exporting to a serial port. UDP export is available in both cases.

Once the Target Marker function is enabled, pressing number keys 0 to 9 will place a marker at the location of the arrow cursor in the sonar view.



Details

Port

Select which serial port you want to export the time and location information to.

Serial port parameters

The serial port parameters are fixed and cannot be changed. Ensure that your third-party software is set to receive the data using these values.

- **Baud Rate**

9600

The speed of the serial communication.

- **Data Bits**

8

The number of data bits in each character.

- **Parity**

N

If required, a parity bit is used in a simple error detection algorithm for a serial port.

- **Stop Bits**

1

This parameter is used to indicate the end of the transmission. It is usually set to *1*.

Target Marker format

\$MSTRK,xx,hhmmss.ss,nnnnnnnn.nn,c,eeeeeeee.ee,c,U<CR><LF>

\$MSTRK	Start character and prefix.
xx	Target number, ranging from 00 to 99.
hhmmss.ss	UTC time in hours, minutes, and seconds.
nnnnnnnn.nn	Northing or Latitude depends on the “U” definition.
c	N: North; S: South
eeeeeeee.ee	Easting or Longitude depends on the “U” definition.
c	E: East; W: West

U	<p>‘f’: Northing/Easting in feet. Variable number of digits for Northing/Easting and variable number of digits for decimal-fraction of Northing/Easting.</p> <p>‘m’: Northing/Easting in metres. Variable number of digits for Northing/Easting and variable number of digits for decimal-fraction of Northing/Easting.</p> <p>‘l’: Lat/Lon in degrees. For Latitude: two fixed digits of Latitude degrees, two fixed digits of minutes, and a variable number of digits for decimal-fraction of minutes. For Longitude: three fixed digits of Longitude degrees, two fixed digits of minutes, and a variable number of digits for decimal-fraction of minutes.</p>
CRLF	Termination

Related topics

[Placing target markers, page 80](#)


Playback Console

You can play back a previously recorded data file to view the sonar image sequence captured during operation of the Sonar Head. Control playback using the **Playback Console**.

How to open

The **Playback Console** is opened from the **Display** menu. The **Playback Console** is also opened automatically when you choose a file for playback.

Description



A The name of the playback file in use and the time and date of the recording.

- B** The playback progress bar. Click and hold, then drag your mouse along the bar to search through the recording. Click anywhere in the bar to jump to a specific point.
- C** Click to stop the recording.
- D** Click to pause the recording.
- E** Click to fast forward through the recording.
- F** Click to advance through the recording one ping at a time.
- G** Click to repeat playback of the file on a never-ending loop.
- H** Click to close the **Playback Console**. Closing the Console will not stop playback.

Related topics


[Playing back a recording, page 68](#)

Profiling Settings dialog box

Profiling mode allows you to view a real-time 3D point cloud of the sea bottom or structures under the water.

How to open

This dialog box is opened from the **Display** menu.



Description

In the **Profiling Settings** dialog box, you can choose to display only the sonar view, only the 3D Point Cloud, or both. The profile point data can be exported to a file so that third-party software can extract depth, distance, and volume measurements.

Details

Display Mode

- **Image**
Select if you want to update the sonar view only.
- **Image and Profile**
Select if you want to update both the sonar view and the 3D Point Cloud.
- **Profile Only**
Select if you want to display only the profile points in the sonar view and 3D Point Cloud.

Point Size

Select the size of the displayed profile points.

Algorithm

Select the profiling algorithm. The default setting is optimal for most conditions.

The *Split Beam* algorithm will improve point detection with sub-degree accuracy at a low grazing angle (but with the compromise of a lower ping rate).

Select the *Structure* algorithm for high-resolution structure inspections at short or medium ranges. For structure inspections, your sonar is usually orientated upward or looking sideways – this algorithm takes this orientation into account and adjusts the profiling points accordingly.

Point Selection

Select which profile points to display. You can choose to display only the points closest to the sonar transducer origin, or only the points with the strongest signal returns.

Parameters

- **Max Depth**

Drag the slider to set the upper depth limit of the profile points. No profile points will be detected above this depth.

A red line overlay will appear in the sonar view to indicate the max depth (view the result in the **3D Point Cloud** window).

- **Min Depth**

Drag the slider to set the lower depth limit of the profile points. No profile points will be detected below this depth.

A green line overlay will appear in the sonar view to indicate the min depth (view the result in the **3D Point Cloud** window).

- **Clutter Suppression**

This feature removes the number of detected noise profile points. If the box is unchecked, the system will automatically adjust the clutter suppression. You can choose your own clutter suppression percentage by checking the box and dragging the slider. Setting the suppression to zero will disable this feature. Setting the suppression to 100 will suppress all noise detections.

- **Max Sector**

Drag the slider to set the upper angle limit of the profile points. No profile points will be detected above this angle.

- **Min Sector**

Drag the slider to set the lower angle limit of the profile points. No profile points will be detected below this angle.

Depth Tracking

Check this box to automatically adjust the range according to the current depth when the head is running. This feature is only available if *Image and Profile* or *Profile Only* is selected for the **Display Mode**.

Note _____

When the head is running, the estimated depth below the Sonar Head is shown in real time. During playback, the recorded depth is shown.

Related topics

[3D Point Cloud, page 95](#)

Setup menu

You can connect to the Sonar Head using the **Setup** menu. You can also configure the system, choose your preferences, set up the coordinate system, upgrade the Sonar Head firmware, or change the Sonar Head IP Address.

How to open

To open this menu, click the menu title.


Description

- **Connect**

Click *Connect* to connect to the Sonar Head and start “pinging”.

Note

When the Sonar Head is running, this menu command will change to Disconnect.



- **Define Custom Sensor**

Click to open the **Define Custom Sensor** dialog box. If the sensor protocol you want to use is not available on the **Sensors Setup** page, you can create a custom sensor format in the **Define Custom Sensor** dialog box.

- **Geo Projection**

Click to open the **Geo Projection** dialog box. You can configure the coordinate system using the **Geo Projection** dialog box.

- **Preferences**

Select to open the **Preferences** dialog box. The **Preferences** dialog box is used to set up system preferences such as units of measure, time format, etc.

- **Head Network Setup**

Click to open the **Head Network Setup** dialog box. The **Head Network Setup** dialog box allows you to change the Sonar Head network parameters, such as the IP address. This dialog box is only available when the Sonar Head is connected and paused.

- **Head Firmware Configuration**

Click to open the **Head Firmware Configuration** dialog box. The **Head Firmware Configuration** dialog box allows you to upgrade the Sonar Head firmware. This dialog box is only available when the Sonar Head is connected and paused.

- **System Configuration**

Click to open the **System Configuration** dialog box. This dialog box allows you to set up the Sonar Head, external sensors (such as a GPS or Motion Reference Unit), and rotators. In addition, you can configure the deployment of the M3 Sonar and enter mounting offsets.

Topics

[Define Custom Sensor dialog box, page 133](#)

[Geo Projection dialog box, page 136](#)

[Preferences dialog, page 138](#)

[Head Network Setup dialog box, page 142](#)

[Head Firmware Configuration dialog box, page 145](#)

[System Configuration dialog box - Sonar Setup page, page 146](#)

[System Configuration dialog box - Sensors Setup page, page 150](#)

[System Configuration dialog box - Rotators Setup page, page 153](#)

[System Configuration dialog box - Master Reference page, page 160](#)

[System Configuration dialog box - Mounting Offsets page, page 163](#)

Define Custom Sensor dialog box

If the sensor protocol you want to use is not available on the **Sensors Setup** page, you can create a custom sensor format in the **Define Custom Sensor** dialog box.

How to open

This dialog box is opened from the **Setup** menu.

Define Sensor Format
✕

Message ID:

Delimiter(s): Space ' ' Comma ',' Semicolon ';' Star '*'

Termination CR LF CR+LF

Sensor Format:

Message ID: Enter one or more characters for the start of the sensor sentence. The Message ID is pre-defined in the sensor specification. For example, ":" or "\$GPRMC". Do not enter any strings into this field that are used in the rest of the sensor sentence.

Delimiter(s): Select one or more characters used to separate each string in the sentence. Each character selected is used as one delimiter and is pre-defined in the sensor specification.

Termination: Select the ending ASCII character defined in the sensor specification – carriage return, line feed, or both.

Sensor Format: To define the sensor format, enter the Message ID again, along with one or more of the three-letter strings from the list on the right that matches the transmitted data type in the sensor specification. Separate each string with your chosen delimiters. If any part of the sensor sentence in the specification cannot be found on the right-side list, use the "Ignored field" string.

For example: ":" ALT DEP HDG ROL PIT" defines a sensor sentence with the Message ID ":" and five fields for Altitude, Depth, Heading, Roll, and Pitch separated by space delimiters.

ALT: Altitude
DEP: Depth
HDG: Heading
HEA: Heave
PIT: Pitch
ROL: Roll
LAT: Latitude
LON: Longitude
SSP: SoundSpeed
III: Ignored field

Description

Many third-party sensors or ROV systems export sensor strings through a UDP or serial connection. These sensor strings include various data types such as position, heading, depth, pressure, altitude, pitch, roll, and water temperature. The third-party sensor string may not conform to the universal NMEA standard and will change depending on the sensor or ROV manufacturer.

You will find many supported sensor formats in the **Protocol** drop-down list found on the **Sensors Setup** page in the **System Configuration** dialog box. However, if a particular third-party sensor format is not listed there, you can create it (using the third-party sensor specification as your guide).

Note

*After you are done creating the custom sensor format, it will appear in the **Protocol** drop-down list on the **Sensors Setup** page.*

The sensor string is comprised of a sentence with defined parts: Message ID + Sensor Format and Delimiters + Termination.

Details

Message ID

The start (prefix) of the sensor sentence. Refer to the manufacturer's sensor specification to determine what to use. For example, “:” or “\$GPRMC”.

Delimiter(s)

The character used to separate each string in the sentence. You can select more than one if necessary - each character will be treated as one delimiter. Refer to the manufacturer's sensor specification to determine what to use.

Termination

The ASCII character that tells the software where the sensor string ends. Options include a carriage return (CR), line feed (LF), or both. Refer to the manufacturer's sensor specification to determine what to use.

Sensor Format

Define the entire sensor string in this field.

Enter the Message ID, followed by the chosen delimiter. Enter in one or more of the three-letter definition strings from the list on the right side of the dialog box. Match each three-letter string with the data type in the sensor specification. For example, enter "ALT" for the part of the sensor sentence corresponding to Altitude, and so on. Separate each string with the chosen delimiters. If you can't find any part of the sensor sentence on the right-side list, then enter the "Ignored field" string (III). This will tell the software to skip over this part of the sensor sentence when parsing the string.

For example: “: ALT DEP HDG ROL PIT” defines a sensor sentence with the Message ID “:” and five fields for Altitude, Depth, Heading, Roll, and Pitch separated by space delimiters.

Data Type

If the data type in the sensor sentence is an integer (for example, 1002), then select *Whole number*. If the data type in the sensor sentence is a float (for example, 10.02), then select *Decimal number*. Refer to the manufacturer's sensor specification to determine what to use.

Latitude / Longitude Format

Choose whether to display the latitude/longitude format in degrees, degrees and minutes, or degrees, minutes, and seconds.

Unit Scale Factor

The dialog box will tell you what unit scale the software expects (meters, degrees, meters per second, and so on). If the data type in the specification does not match the required unit scale, you must enter an appropriate scaling factor. For example, if the Depth data type is in feet, then you must enter 0.3048 to scale the depth value to meters.

Sensor Name

This name will appear in the **Protocol** drop-down list found on the **Sensors Setup** page in the **System Configuration** dialog box.

Related topics


[Defining a custom sensor, page 46](#)

Geo Projection dialog box

You can configure the coordinate system using the **Geo Projection** dialog box.

How to open

This dialog box is opened from the **Setup** menu.



Description

This dialog box allows you to convert the latitude and longitude data from your GPS into a coordinate system of your choice. For example, you may wish to match the coordinate system used in your survey maps. You can display location data as Easting and Northing coordinates measured from a horizontal datum. You can also set the zone so that accurate location data is embedded in any GeoTiff files that you create.

Details

Datum

- **Latitude / Longitude**
Select a datum for latitude and longitude coordinates (geographic system).
- **Northing / Easting**
Select a datum for a Northing/Easting projection (projected coordinate system).
- **Zone**
Select a zone for a Northing/Easting projection.
- **Display Coords In**
Choose which coordinate format you want to use in the sonar view when displaying location information.
- **Latitude / Longitude Format**
Choose whether to display the latitude/longitude format in degrees, degrees and minutes, or degrees, minutes, and seconds.
- **Datum Parameters**
The **Datum Parameters** button will become available when selecting the *BEIJING_1954* datum. Clicking the **Datum Parameters** button will open a dialog box with a number of fields specific to this datum.

Calculator


You can use the calculator as a tool to convert your location from one coordinate system to another.

Preferences dialog

The **Preferences** dialog box is used to set up system preferences such as units of measure, time format, etc. This dialog box also allows you to select the save location for screenshot images and recorded sonar data files.

How to open

This dialog box is opened from the **Setup** menu.



Description

The **Preferences** dialog box allows you to customize the software. In addition, you can configure features such as GeoTiff Auto Save and UDP Data Export. You can also configure unique file names and save locations.

Details

Units

- **Meters**
Select to display all units of measurement in meters.
- **Feet**
Select to display all units of measurement in feet.

Cursor Options

- **Range / Bearing**
Select to show the range and bearing of the current mouse position at the bottom of the sonar view.
- **X / Y**
Select to show the X and Y coordinates of the current mouse position at the bottom of the sonar view.
- **Geographic**
Check this box if you want to display the coordinates of the mouse position at the bottom of the sonar view.

Tip _____
*You can configure the coordinate system using the **Geo Projection** dialog box.*

Time System

- **Local Time**
Select to use the current time at your location.
- **UTC Time**
Select to use Coordinated Universal Time (UTC).

Note _____
During the winter, Local Time equals standard time. During the summer, Local Time equals Daylight Saving Time (DST). Note that the offset between Local Time and UTC Time is not constant, but varies in locations where DST is used.

Overlay Text

Fill out the **Overlay Text** boxes if you wish to display information on your screenshots and data recordings.

File Saving

- **Prompt User for Filename**

Check this box to open a “Save As” dialog box when you record data or save an image.

- **Export Sensor Data**

Check this box to save timestamped sensor data to a text file (in CSV format). When this feature is enabled, a text file will be created every time the sonar runs or a recording is played back. The text file is saved in the **Recordings** folder shown in this dialog box. If you export a recording to video, then the text file will be saved in the **Target Folder** shown in the **Convert to Video Format** dialog box.

Tip _____

If you need to troubleshoot sensor data logging issues, you can compare the sensor data text file to the NAV file provided by a survey or ROV on-board the vessel.

- **Name**

Type any name into the text box. The chosen name will be used as prefix in all the data file names. The time/date stamp will be used as the filename if the name field is left blank.

- **Use C:\KML\M3_V0254**

Check this box to use the default location when saving files. Disable this setting if you want to choose alternative save locations. The **Browse** buttons will become available.

GeoTiff Auto Save

- **Distance / Time**

To automatically save a GeoTiff file every set number of meters, select Distance and enter a value. To automatically save a GeoTiff file every set number of seconds, select Time and enter a value.

Tip _____

Press F11 to enable or disable GeoTiff auto save. The status bar will display “GeoTiff” in green when auto save is enabled.

- **Cropped Width**

To save a cropped GeoTiff image for mosaicking purposes, enter the percentage to crop.

UDP Data Export

- **Export to File**

Check this box to save export data to a file on the local hard drive.

- **Port for .ALL format**

Enter the UDP port for exporting .ALL data. You need to configure this port if you are interfacing with third-party software.

- **Remote IP Address**

Enter the IP Address of the computer you wish to export the profile data to.

- To disable data export, enter *0.0.0.0*.
- To broadcast, enter *255.255.255.255*.
- To use the local computer, enter *127.0.0.1* (for example, if your third-party software is installed on the same computer as the M3 software).

Related topics

[Configuring your preferences, page 35](#)

Head Network Setup dialog box


The **Head Network Setup** dialog box allows you to change the Sonar Head network parameters, such as the IP address.

How to open

This dialog box is opened from the **Setup** menu.

Note

*This dialog box is only available when the Sonar Head is connected and paused. To pause the Sonar Head, click **Setup**→**Connect**, then open the Menu Widget in the top-right corner of the sonar view. Click **Pause**.*



Description

You can program the IP address and the IP port of the Sonar Head for various network environments. The factory default IP address is 192.168.1.234, and the default port number is 30.

To change the Sonar Head IP address, click **Read from Head** to get the information from the Sonar Head. Edit the fields, then click **Write to Head**.

Details

Head Name

The name assigned to the Sonar Head. You cannot change this parameter — it is read only.

Serial Number

The unique serial number of the Sonar Head. You cannot change this parameter — it is read only.

Automatic IP address allocation

Determines whether the Sonar Head can be assigned an IP address from a DHCP Server. By default, the Sonar Head uses a static IP address. You cannot change this parameter — it is read only.

VDSL Profile

The VDSL2 standard defines various profiles that can optimize the data rate and link performance on cables of different quality and lengths. For longer cables, you may wish to use a profile with a lower bandwidth, such as profile 0 (8b) or 1 (12a).

The following profiles are available:

- **0 (8b)**: Suitable for long or low-quality cables, but has a slower data rate.
- **1 (12a)**: A good compromise for medium-length cables, or cables that are of marginal quality, and provides a medium-speed data rate.
- **2 (30a)**: Suitable for short cables. Provides a fast data rate.
- **3 (30a)**: Provides the fastest data rate but is only suitable for very short cables.

Note

The maximum achievable data rate depends on a number of factors, such as cable length, the number of junctions, and your slip ring installation. You can measure the link speed by performing the “Testing the Sonar Head telemetry” procedure.

VDSL SNR Margin

The VDSL Signal to Noise Ratio (SNR) Margin controls the amount of noise and tolerance in the cable. It is the difference between the actual SNR and the minimal SNR required to sync at a specific speed. For longer cables, use 6 dB instead of 9 dB.

IP Address, Port, Subnet Mask, and Default Gateway

These network parameters are used to identify and locate the Sonar Head on the local network. If you need to set up a unique network environment, you can change the IP Address, Port, Subnet Mask, and Default Gateway of the Sonar Head using the **Head Network Setup** dialog box.

Note

Your Sonar Processor must be on the same network as the Sonar Head.

Get Default

Click this button to populate the fields with the default network settings for the Sonar Head.

Write to Head

Click this button to re-program the Sonar Head with the parameters that you have entered.

Read from Head

Click this button to populate the fields with the current parameter values.

Related topics

[Changing the Sonar Head IP Address, page 85](#)

[Testing the Sonar Head telemetry, page 27](#)

Head Firmware Configuration dialog box


The **Head Firmware Configuration** dialog box allows you to upgrade the Sonar Head firmware.

How to open

This dialog box is opened from the **Setup** menu.

Note

*This dialog box is only available when the Sonar Head is connected and paused. To pause the Sonar Head, click **Setup**→**Connect**, then open the Menu Widget in the top-right corner of the sonar view. Click **Pause**.*



Description

In addition to head application software, the Sonar Head has receive firmware (RX FPGA) and transmit firmware (TX FPGA). You can upgrade these by selecting the configuration type, browsing for the file, then clicking the **Write** button.

Note

The receive hardware (RX HW) and software (RX SW) must both be on the same version. You can view the current version numbers in this dialog box.

Details

Head

The **Head** table shows you the serial number and IP Address of the Sonar Head.

Configuration type

Select the type of software or firmware that you are upgrading.

Configuration file

Click the folder icon to browse for the latest software or firmware file on your local drive.

Read

Enter a filename in the **Configuration file** box, then click **Read** to save the firmware or software to a file. You can create a backup of your current software or firmware with this feature.

Write

Click this button to start the upgrade process. You will be prompted to confirm the upgrade.

Related topics

[Upgrading the Sonar Head, page 83](#)

System Configuration dialog box - Sonar Setup page

You can discover and connect to the Sonar Head on the **Sonar Setup** page. You can also view the Sonar Head network properties and adjust the network link speed.


How to open

This dialog box is opened from the **Setup** menu.

Select the **Devices**→**Sonar Setup** tab.

Note

This page is not available while the Sonar Head is running.



Description

This dialog box allows you to connect to the Sonar Head. You can connect manually or automatically each time you start the software. This dialog box also provides diagnostic network tools.

Details

Device Properties

Tip _____

*You do not have to enter in the Device Properties manually. Clicking **Discover Sonar Heads**, then **Use Discovered Head** will automatically populate the Device Properties fields.*

- **Head Name**

You can enter any name to identify the Sonar Head.

- **Serial Number**

The unique serial number of the Sonar Head.

- **IP Address, Port, Subnet Mask, and Default Gateway**

These network parameters are used to identify and locate the Sonar Head on the local network. Your Sonar Processor must be on the same network as the Sonar Head.

Tip _____

*If you need to set up a unique network environment, you can change the IP Address, Port, Subnet Mask, and Default Gateway of the Sonar Head using the **Head Network Setup** dialog box.*

- **Trigger Mode**

If applicable, set the **Trigger mode** to synchronize the Sonar Head with another acoustic device (such as a second M3 Sonar Head or a sub-bottom profiler). Set the trigger mode to *Master* to send out a sync pulse so that the other acoustic device can be triggered. Set the trigger mode to *Slave* to be triggered by the sync pulse from the other device. For the M3 Sonar, the default is set to *Master*.

- **Time Sync Mode**

Time synchronization is critical for Bathymetry applications. By default, the M3 software uses the computer's time to set the Sonar Head clock (*Host* mode). Your computer can keep accurate time by using a GPS or network time server as the master time source. When connecting to the Sonar Head, it takes two minutes to synchronize the time to within five milliseconds. The M3 software will then continuously keep the Sonar Head clock in sync for the duration of the session. The status bar shows the time synchronization status.

If you have an M3 Sonar Head with a 1PPS connector, you can synchronize the Sonar Head clock with an external 1PPS source.

Get Default

Click this button to use the default network settings to connect to a Sonar Head.

Autoconnect at program start

Check this box to connect to the Sonar Head automatically the next time the software starts.

Override Network Link Speed

If telemetry quality is poor, you can limit the network link speed. By default, the network link speed is limited to 100 Mbps. There are no standard sonar applications with a telemetry-link speed requirement higher than 100 Mbps.

Note

Overriding the network link speed will provide a more stable link connection, but a slower ping rate.

Network log level

This setting outputs network-related diagnostic messages to the **Output Messages** window and a ".log" file (found in the LOGS directory) for troubleshooting purposes. You can select the amount of detail provided, ranging from none (No logging) to high (Detailed info). When logging is enabled, ping loss, packet loss and the last ping data rate will be displayed on the status bar.

Discover Sonar Heads

Click **Discover Sonar Heads** to search for the sonar on the network.

Use Discovered Head

Click **Use Discovered Head** to connect to the discovered head.

Related topics

[Starting operation of the Sonar Head, page 34](#)

[Testing operation of the Sonar Head, page 24](#)

System Configuration dialog box - Sensors Setup page

The **Sensors Setup** page allows you to configure external sensors (such as a GPS to provide navigation information).


How to open

This dialog box is opened from the **Setup** menu.

Select the **Devices**→**Sensors Setup** tab.

Note

This page is not available while the Sonar Head is running.



Description

If you have external sensors that provide speed, heading, or latitude/longitude coordinates, then this dialog box allows you to set them up. Readings from these sensors will appear in the **Information Widget** located in the sonar view.

Details

Add Device

Click this button to add a sensor for data import.

Remove Device

Click this button to remove the selected sensor from the **Sensor Devices** list.

Test Device

Click this button to start a sensor test. The sensor data will be displayed in the **Port Monitor** box.

Device Properties

- **Name**

Enter any name into this field to label the device.

- **Protocol**

This drop-down lists all supported datagram formats.

- **Port Location**

The location of the port receiving external sensor data – can be a COM port, a UDP Ethernet port, or a port on the Sonar Head.

- **Port#**

This drop-down lists the available port numbers. Select the port where the device is connected.

- **Baud Rate**

Specify the baud rate (“speed”) for the serial communication. The standard baud rate defined for NMEA communication is *4800*.

- **Data Bits**

Select the number of data bits for the serial communication.

Note _____

The standard number of data bits defined for NMEA serial line communication is 8 (eight).

- **Parity**

Specify the parity for the serial communication.

Note _____

If required, a parity bit is used in a simple error detection algorithm for a serial port. Standard parity defined for NMEA serial line communication is "None".

- **Stop Bits**

This parameter is used to indicate the end of the transmission. It is usually set to 1.

- **Interface**

This drop-down lists possible serial communication methods.

Related topics

[System Configuration dialog box - Master Reference page, page 160](#)

System Configuration dialog box - Rotators Setup page

Rotators are required if you wish to pan or tilt the M3 Sonar during operation. Use the **Rotators Setup** page to set up and test your rotators.


How to open

This dialog box is opened from the **Setup** menu.

Select the **Devices**→**Rotators Setup** tab.

Note _____

This page is not available while the Sonar Head is running.



Description

The M3 software supports the following rotators.

- Kongsberg OE 10-102: Dual-Axes Pan and Tilt unit
- Kongsberg OE10-103: Single-Axis Pan unit
- Kongsberg Discovery 806-00480000 (SS350): Single-Axis high-precision Pan unit

You must connect your rotator to a PC COM port.

Details

Add Device

Click this button to add a rotator.

Remove Device

Click this button to remove the selected rotator from the **Rotators** list.

Test Device

Click this button to open the **Rotator Test** dialog box.

Device Properties

- **Name**
Enter any name into this field to label the device.
- **Unit**
Select the rotator model you have from the list.
- **Device Axis**
Select one sonar axis if you are using a single-axis unit, or select two sonar axes for a dual-axes unit.

There are three possible sonar axes. To view the orientation of each axis, click **System Configuration**→**Deployment**→**Mounting Offsets** and select each axis in the **Rotators** section. Observe the animation to see the rotation of each axis.
- **Port Location**
Select which port the rotator is connected to — can either be a COM port or a Sonar port.
- **Port#**
This drop-down lists the available port numbers. Select the port where the device is connected.
- **Baud Rate**
Specify the baud rate (“speed”) for the serial communication.
- **Data Bits**
Select the number of data bits for the serial communication.

- **Parity**

Specify the parity for the serial communication.

Note

If required, a parity bit is used in a simple error detection algorithm for a serial port.

- **Stop Bits**

This parameter is used to indicate the end of the transmission. It is usually set to 1.

- **DeviceCommID**

The rotator manufacturer assigns this network identifier for communication between the rotator and the software. The default for newer rotator models is “3”. The default for older rotator models is “2”. If you are experiencing communication problems with your rotator, make sure that you have selected the correct ID for your model.

Related topics

[System Configuration dialog box - Mounting Offsets page, page 163](#)

[Controlling the rotator, page 49](#)

Rotator Test dialog box

Test your rotators in this dialog box by making sure you can connect to the rotator and send commands to it.

How to open

This dialog box is opened from the **Rotators Setup** page in the **System Configuration** dialog box.

Click the **Test Device** button to open this dialog box.


Description

Use this dialog box to test the rotator rotation speed, rotator movement, and pan and tilt operation (for dual-axes rotators). If you are using a single-axis rotator, you can choose the type of rotator control dialog box you will see when running the sonar (*3D Scan* or *Pan/Tilt Control*).


If you have selected a single-axis rotator, then the following dialog box is used.

Note

*This dialog box shows the options for the Kongsberg OE10-103. The Kongsberg Discovery 806-00480000 (SS350) is similar, except a **Calibrate** button appears. You must click this button to correctly align the rotator after powering down and powering up (this rotator does not keep absolute zero indexing). In addition, there is no option to set up soft stops (this rotator has fixed hard and soft stops).*



If you have selected a dual-axes rotator, then the following dialog box is used.



Details

Connect

Click this button to connect to the rotator.

Disconnect

Click this button to disconnect from the rotator.

Current Position

Shows the current rotator position in degrees.

A **Calibrate** button will appear here if you are using the Kongsberg Discovery 806-00480000 (SS350) rotator. Click this button to reset the zero index after powering down then powering up.

Directional Move

For single-axis rotators, use the **Speed** control to set the rotator rotation speed. Click and hold the **Go Up** button to move the rotator up. Click and hold the **Go Down** button to move the rotator down. Check the **Reverse Rotator Direction** box if your rotator has been installed in a reversed position.

If you have a dual-axes rotator, you will be presented with arrow icons. Click the up and down arrow icons to tilt up or down. Click the left and right arrows to pan left or right. Check the **Switch Axes** box to invert the controls so that the up/down arrows are used to pan and the left/right arrows are used to tilt. You can adjust the tilt and pan speeds by dragging the sliders. Check the **Reversed Tilt Rotator Direction** box if your rotator is installed with the tilt axis reversed. Check the **Reversed Pan Rotator Direction** box if your rotator is installed with the pan axis reversed.

Soft Stops

Check the **Use Soft Stops** box to use a software function to set the rotator stops, so that the rotator will not rotate beyond the stops during operation. To avoid hitting objects or twisting cables when rotating, hard stops (pins) are usually bolted onto the rotator mount to stop rotation at predefined positions. However, soft stops allow you to program the rotator stops in the M3 software to mitigate mechanical wear and avoid shearing the hard stops.

To set the soft stops, uncheck the **Use Soft Stops** box. Set up the soft stops by moving the rotator until it reaches the limit where the attached devices or cables still have clearance.

- Click the **Go Up** button/up arrow to move the rotator up to the desired position, then click the **Set Up Stop** button.
- Click the **Go Down** button/down arrow to move the rotator down to the desired position, then click the **Set Down Stop** button.
- Click the right arrow (dual-axes only) to move the rotator right to the desired position, then click the **Set Right Stop** button.
- Click the left arrow (dual-axes only) to move the rotator left to the desired position, then click the **Set Left Stop** button.

Re-check the **Use Soft Stops** box when you are done.

Positioning

You can use the positioning function to move the rotator to a specific position (in degrees). Use this function for precise and quick positioning instead of clicking the **Go Up** or **Go Down** buttons. Enter a degree in the **To position** field, then click **Goto** (single-axis only). You can also rotate in degree increments by entering a degree into the **Step by size** field, then clicking **Step Up** or **Step Down** to rotate to the next/previous increment.

If you have a dual-axes rotator, you can enter a degree into the **Tilt to position** or **Pan to position** fields, then click the associated button to move the Sonar Head to that position on the tilt or pan axis.

Click the **Stop Move** button to cancel the rotation.

Rotator Control Dialog Type

Set the **Rotator Control Dialog Type** before you start operation of the sonar.

Select *3D Scan* if you have installed the Sonar Head to automatically scan a sector during operation, with the rotator sweeping the Sonar Head from one side of the sector to the other. Select *Pan/Tilt Control* if you wish to manually move the Sonar Head up, down, or sideways during operation.


System Configuration dialog box - Master Reference page

On the **Master Reference** page, you can assign any external sensors you have set up as the primary source for various types of navigational data.

How to open

This dialog box is opened from the **Setup** menu.

Select the **Deployment**→**Master Reference** tab.



Description

When using the M3 Sonar for imaging, set up sensors for **Position** and **Heading** if you want to create GeoTiff files or create a real-time mosaic.

When using the M3 Sonar for Bathymetry or Profiling, set up sensors for **Position**, **Heading**, **Pitch/Roll**, and **Heave** as a minimum.

If no sensor input is required for a particular reference, you may leave the value set to *Fixed*. For example, if the Sonar Head is mounted on a tripod with a known position, heading, and pitch/roll, these references will have fixed values. Also, sensor input may not be required for the M3 software if the sensors have been set up in third-party software. When setting a value to *Fixed*, you can enter the fixed value into the adjacent text box.

Details

Configuration

Select the desired configuration from the drop-down list. Click **New** to create a new configuration based on the default settings. Click **Save As** to save the current configuration or **Delete** to delete the current configuration.

Master Reference

- **Position**

A location derived from measuring external reference points.

- **Depth**

The vertical distance downwards from the water surface.

- **Heading**

The direction in which a vessel is pointing, as opposed to the course made good.

- **Magnetic Variation**

If you are using a magnetic heading sensor, enter the local magnetic variation into the **Magnetic Variation** box to get true heading. This parameter can be changed while the Sonar Head is running.

- **Pitch/Roll**

Pitch is the up/down rotation of a vessel about its lateral axis. Roll is the tilting rotation of a vessel about its longitudinal axis.

- **Heave**

Heave is the linear vertical (up/down) motion of the vessel.

- **Sound Speed**

A sound speed sensor is required to accurately measure in-water speed near the Sonar Head. This parameter can be changed while the Sonar Head is running.

Note

*Select **IntegratedSVS** only if you are using a Sonar Head with an integrated sound speed sensor.*

Check the **Override Sound Speed** box if you want to replace the sound speed value in your recording with a fixed value during playback. This may be necessary, for example, if your recorded sound speed is not accurate. You can override the sound speed in .mmb files only.

- **Altitude**

Altitude is the vertical distance from the sensor to the seafloor. If you need the depth below the transducer, use the NMEA DBT datagram.

Related topics

[System Configuration dialog box - Sensors Setup page, page 150](#)

System Configuration dialog box - Mounting Offsets page

The mounting offsets are required to calibrate the position of the Sonar Head relative to the GPS antenna. If you have a rotator, you must calibrate the position of the rotator relative to the Sonar Head.


How to open

This dialog box is opened from the **Setup** menu.

Select the **Deployment**→**Mounting Offsets** tab.

Note


This page is not available while the Sonar Head is running.



Description

If you are mounting your M3 Sonar Head (on a Pole Mount for example), you will need to specify where the Sonar Head is positioned in three-dimensional space relative to the GPS antenna.

The reference point on the sonar is the centre of the long rectangular RX array.



Inaccurate mounting offsets will display your sonar data incorrectly in the 3D Point Cloud and sonar view.

Tip

*If you have recorded your sonar data using the wrong offsets, you can still fix the offsets using this dialog box. Check the **Override Mounting Parameters** box to apply the correct mounting offsets to your recording.*

Details

Mounting

- **X Offset**

X is defined as the Sonar Head relative to the GPS antenna across track. Port is negative and Starboard is positive.

- **Y Offset**

Y is defined as the Sonar Head relative to the GPS antenna along track. Aft is negative and Fore is positive.

- **Z Offset**

Z is defined as the Sonar Head relative to the GPS antenna's vertical distance. Down is negative and Up is positive.

- **Orientation**

This drop-down list allows you to select a number of pre-configured Sonar Head orientations. Observe the animation to make sure your Sonar Head is facing in the correct direction for the selected orientation. The orientation depends on how you are using the M3 Sonar. For example, a forward-facing orientation can be used for obstacle avoidance on a remotely operated vehicle (ROV). A downward-facing orientation can be used for bathymetric surveying. An orientation that rolls sideways can be used to scan vertical structures. An upward-facing orientation can be used for scientific research, such as gas-seep monitoring. If you wish to create your own orientation, select *Custom*, then enter in the precise pitch, roll, and yaw angles of the Sonar Head position.

Tip _____

If images appear on the wrong side of the sonar view (for example, objects on the right appear on the left), then select one of the "Inverted" orientations.

Rotators

Select the rotator you wish to configure from the Rotators list. You can see which axis has been assigned to each rotator.

- **Radius**

The radius offset is necessary if your Sonar Head is attached to the rotator with an arm. The length of the arm can be entered as the radius.

- **Angle**

Entering an angle is not necessary if the transducer face of the Sonar Head is aligned with the rotator. However, if the Sonar Head is installed at an angle to the rotator, then enter that value here.

Override Mounting Parameters

Enabling this option will apply the current offsets on this page during playback instead of the offsets recorded in your data file. The offset override affects what you see during playback in the 3D Point Cloud, not the sonar view.

Tip _____

If you apply the offset override, playback a file, then re-record a new file during playback, the offsets will not be applied to the new re-recorded file (the new file will use the original offsets). However, if you export data to a third-party application in playback mode, the offset override will be applied to the exported data.

Related topics

[System Configuration dialog box - Rotators Setup page, page 153](#)

Sonar Applications menu

The **Sonar Applications** menu lists various operating modes used for different applications. Each mode has its own pre-defined characteristics, such as differing ranges, angular resolutions, and pulse types.

Note

*You cannot select a sonar application until the Sonar Head is connected. All **Sonar Applications** menu items will be greyed out until the sonar is running.*

*The selection of sonar applications presented in the **Sonar Applications** menu depends on the current Sonar Head frequency. The M3 software will automatically detect the frequency of your Sonar Head and display only the applicable sonar applications.*

How to open

To open this menu, click the menu title.

The following sonar applications are available when using a 500-kHz Sonar Head transducer.

Description

- **EIQ**

This sonar application captures high-quality images. At short ranges the images are relatively insensitive to the motion of the sonar. At longer ranges the sonar should be relatively motionless.

Note

This application is less sensitive to motion than EIQ - Fine.

- **EIQ - Fine**

This sonar application captures very high-quality images. At short ranges the images are relatively insensitive to the motion of the sonar. At longer ranges the sonar should be relatively motionless.

- **EIQ - Ultra Fine**

This sonar application captures the highest quality images possible. At short ranges the images are relatively insensitive to the motion of the sonar. At longer ranges the sonar should be relatively motionless.

- **Ethernet Test - 1000Mbps**

You can test your 1000Mbps link to verify that the link throughput is available. The test uses 80 percent utilization and uses *EIQ - Ultra Fine*.

- **Ethernet Test - 100Mbps**

You can test your 100-Mbps link to make sure that the link throughput is available. The test uses 80 percent utilization and uses *EIQ*.


- **Ethernet Test - 10Mbps**

You can test your 10-Mbps link to make sure that the link throughput is available. The test uses 80 percent utilization and uses *Imaging 30*.

- **Imaging 15**

You can use this sonar application for navigation and obstacle avoidance. This application uses a 15-degree Tx vertical beamwidth.

- **Imaging 3**



Use this sonar application primarily for profiling using a 3-degree Tx vertical beamwidth. You may also use this application for shallow-water obstacle avoidance.

- **Imaging 30**

You can use this sonar application for navigation and obstacle avoidance. This application uses a 30-degree Tx vertical beamwidth.

- **Imaging 30 - Short Range**

You can use this sonar application for the support of manipulator operations, with the highest-speed short-range imaging. Speed and detail are more important than overall image quality.

- **Imaging 7**

You can use this sonar application to provide long-range obstacle avoidance and navigation into the work site. This application uses the highest pulse power. Pulse durations are used to get a reliable long-range detection. The trade-off is a reduction in the ping rate.

- **Profiling**

Use this sonar application for the automated point extraction of the sea bottom or structures to create a real-time 3D Point Cloud. The *Profiling* application has a slow ping repetition rate and is best suited for slow-moving ROVs, trenchers, and ploughs.

- **Profiling - Bathy**

This sonar application is ideal for Bathymetry Surveys.

- **Profiling - Dual Head Master**

You can use this profiling sonar application to generate an alternating sequence of pings and external trigger events. This sequence is used to implement alternate pinging in a dual-head profiling system.

- **Profiling - Dual Head Slave**

You can use this profiling sonar application to generate an alternating sequence of pings and external trigger events. This sequence is used to implement alternate pinging in a dual-head profiling system.

- **Profiling - Fast**

This sonar application performs using much higher ping rates than the normal *Profiling* application. This application is ideal for surface-vessel surveys.

- **ROV Navigation**

This sonar application automatically switches between *EIQ - Fine*, *EIQ*, and *Imaging 30* applications. *EIQ - Fine* is used to provide the highest-resolution images with a

good image update rate at short ranges. *EIQ* is used for medium ranges. *Imaging 30* is used for long ranges.

- **Rub Test**

Use this sonar application as part of a system test to make sure that the transducer is receiving a signal. Rub the transducer and make sure that bright streaks or rings appear in the sonar view.

- **Customize Apps**

Click to open the **Customize Apps** dialog box. You can select which sonar applications will appear in the **Sonar Apps** menu.

The following sonar applications are available only when using a high-frequency Sonar Head (such as a 700-kHz to 1400-kHz transducer, for example).

In addition, some of the sonar applications listed above are also available when using a high-frequency Sonar Head, but not all.

- **Imaging**

You can use this sonar application for navigation and obstacle avoidance. This application uses a 30-degree Tx vertical beamwidth.

- **Imaging Enhanced**

Use this sonar application for imaging or obstacle avoidance using one of the eIQ elements. This application uses a Time Delay FFT beamformer to produce a high-quality image.

- **Profiling - HiRes**

Use this sonar application if you have a high-frequency Sonar Head and require a higher horizontal beam resolution. This profiling mode uses the maximum number of beams (512) but has a slower ping rate as it uses more computational power. High-resolution profiling is ideal for applications such as pipeline inspections, fish behaviour studies, and gas plume detections.

Topics

[Enhanced Image Quality \(EIQ\), page 172](#)

[Imaging, page 172](#)

[Profiling, page 173](#)

[ROV Navigation, page 174](#)

Enhanced Image Quality (EIQ)

Enhanced Image Quality (EIQ) applications are intended for slower moving operations where the vehicle or vessel is moving slowly, or is stationary for at least a few seconds.

Description

The Fine EIQ applications overlap beams to improve image quality. *EIQ* uses four pings. *EIQ - Fine* uses eight pings. *EIQ - Ultra Fine* uses 12 pings. Note that the Fine EIQ applications have a slower sonar view refresh rate.

We recommend a maximum vessel speed of two knots for *EIQ* mode and 0.5 knots for *EIQ - Fine* mode.

Details

Sonar Application Names:	EIQ EIQ - Fine EIQ - Ultra Fine
Range:	0.4 m to 150 m
Angular Resolution:	0.95° x 30°
Pulse Type:	Continuous Wave and Linear FM (Chirp)

Imaging

Imaging applications provide long-range detection for monitoring and navigation.

Description

Imaging applications use the highest pulse power. They use pulse durations to get reliable long-range detection. The trade-off is a reduction in the ping rate, partially due to the long range, and partially to maintain power consumption within reasonable limits.

We recommend a maximum vessel speed of five knots for imaging applications.

Details

The following sonar applications are available when using a 500-kHz Sonar Head transducer.

Sonar Application Names:	Imaging 30 Imaging 15 Imaging 7 Imaging 3 Imaging 30 - Short Range
Range:	0.2 m to 150 m
Angular Resolution:	1.6° x 30° 1.6° x 15° 1.6° x 7° 1.6° x 3°
Pulse Type:	Continuous Wave and Linear FM (Chirp)

The following sonar applications are available only when using a high-frequency Sonar Head (such as a 700-kHz to 1400-kHz transducer, for example).

Sonar Application Names:	Imaging Imaging Enhanced
Range:	0.2 m to 100 m
Angular Resolution:	140°x30° (700 kHz) 140°x27° (950 kHz) 75°x21° (1200 kHz) 45°x18° (1400 kHz)
Pulse Type:	Continuous Wave and Linear FM (Chirp)

Profiling

Use this sonar application for the automated point extraction of the sea bottom or structures to create a real-time 3D Point Cloud.

Description

The *Profiling* application has a slow ping repetition rate and is best suited for slow-moving ROVs, trenchers, and ploughs. When recording data, the file size will be small. Use the *Profiling* application for very shallow depths. The *Profiling - Bathy* application is more versatile. This sonar application is ideal for Bathymetry Surveys. The *Profiling - Fast* application performs best at longer ranges (i.e. depths greater than 5 m). This sonar

application performs using much higher ping rates than the normal *Profiling* application. This application is ideal for surface-vessel surveys.

Details

Sonar Application Names:	Profiling Profiling - Bathy (500-kHz transducer only) Profiling - Fast (500-kHz transducer only) Profiling - Dual Head Master (500-kHz transducer only) Profiling - Dual Head Slave (500-kHz transducer only) Profiling - HiRes (700-kHz to 1400-kHz transducer only)
Range:	1 m to 150 m
Angular Resolution:	1.6° x 3° 1.8° x 1° 1.8° x 2° 1.4° x 0.75° 1.4° x 1.5° 1.1° x 0.6° 1.1° x 1.2° 0.9° x 0.5° 0.9° x 1°
Pulse Type:	Continuous Wave and Linear FM (Chirp)

ROV Navigation

This sonar application automatically switches between *EIQ - Fine*, *EIQ*, and *Imaging 30* applications.

Description

EIQ - Fine is used to provide the highest-resolution images with a good image update rate at short ranges. *EIQ* is used for medium ranges. *Imaging 30* is used for long ranges.

Details

Sonar Application Name:	ROV Navigation
Range:	0.4 m to 150 m
Angular Resolution:	1.6° x 30°
Pulse Type:	Continuous Wave and Linear FM (Chirp)

Advanced menu

The **Advanced** menu is intended for experienced users or for testing purposes and is not required for normal operation of the M3 Sonar. This menu requires a software license key, and will not appear if you do not have one.

How to open

To open this menu, click the menu title.

Description

- **Power User Settings**

Click to open the **Power User Settings** dialog box. The **Power User Settings** dialog box allows you to configure advanced controls. You can also override the beamlist or processing type during playback. The Ping Rate, Update Rate, and Mode ID are displayed for your information.

- **Program Head**

Click to open the **Program Head** dialog box. You can perform advanced tasks in the **Program Head** dialog box, such as configuring production settings, making head corrections, or changing transmit pulse definitions. This dialog box is only available when the Sonar Head is connected and paused.

- **Convert to Profile**

Click to open the **Profile Batch Conversion** dialog box. The **Profile Batch Conversion** dialog box allows you to convert many data files at once into another format. You can convert “.mmb”, “.imb”, and “.pmb” files.

- **Raw Data Frequency Spectrum**


Click to open the **Raw Data Spectrum** window. The **Raw Data Spectrum** window allows you to find and observe any noise in the data.

- **Enable Network Sniffer**

Click to open the **Network Sniffer** window. The **Network Sniffer** window allows you to monitor network traffic in real-time. When this feature is enabled, the menu option will change to **Disable Network Sniffer**.

Note

*To use this feature, you must run the M3 software as an administrator (right-click on the icon and select **Run as administrator**).*



Topics

[Power User Settings dialog box, page 177](#)

[Program Head dialog box - Production Config page, page 180](#)

[Program Head dialog box - Head Corrections page, page 182](#)

[Program Head dialog box - TX Pulse page, page 184](#)

[Profile Batch Conversion dialog box, page 185](#)

[Raw Data Spectrum window, page 187](#)

[Power User Settings XML file, page 188](#)

Power User Settings dialog box

The **Power User Settings** dialog box allows you to configure advanced controls. You can also override the beamlist or processing type during playback. The Ping Rate, Update Rate, and Mode ID are displayed for your information.

How to open

This dialog box is opened from the **Advanced** menu.

Description

Use the Advanced Controls to configure special processes used during beamforming. Use the Playback Controls to override the fields of recorded “.mmb” data during playback. You can also view detailed system information for the current sonar application.

Details

Advanced Controls

- **RX Amplitude and Phase Correction**


This feature allows you to make sure the RX Amplitude and Phase Correction has been successfully written to the Sonar Head during production configuration. Unchecking this box will not apply the correction stored in the Sonar Head to the raw data before beamforming.

- **Azimuth Processing**

This feature allows you to make sure the raw data is received properly and to make sure there are no faulty elements in the transducer. Unchecking this box will display the range-compressed raw data in the sonar view with a range vs. element number instead of a range vs. beam angle. The beamforming processing (either the time-domain beamformer or the FFT beamformer) will not be applied.

- **Range Processing**

This feature, when used together with Azimuth Processing, allows you to see the unprocessed raw data received directly from the transducer. If the transmit pulse is an LFM pulse, unchecking this box will not apply range compression to the raw data before the beamforming processing.



- **Sidelobe Reduction**

This feature allows you to reduce the sidelobe for very bright targets in imaging applications (this feature is not recommended for profiling applications). Sidelobe reduction is especially useful at short ranges when targets are very close.

Note

*If automatic sidelobe reduction is enabled in the **Display** menu, the slider will be greyed out and you can view the automatically-calculated sidelobe reduction ratio. If automatic sidelobe reduction is disabled in the **Display** menu, you can drag the slider to the right to manually increase sidelobe reduction. On the highest settings you may notice a black line appearing around the same range of the bright target.*

Playback Controls

Note

*You can also edit the **Playback Controls** settings in the “PowerUsersInfo.xml” file.*

- **Override Beamlist**

This feature allows you to replace the beamlist of a recorded “.mmb” file with a new beamlist XML file. The recorded raw data will be beamformed based on the new beamlist. Checking the **Override Beamlist** box will enable the **Beamlist File** field. You can type in the beamlist file’s address or click the folder icon to browse for it.

- **Override Processing Type**

This feature allows you to switch between the time-domain beamformer and the FFT beamformer for profiling applications. Select the *Profiling* option when playing back an “.mmb” file (recorded using the *Profiling - Fast* or *Profiling - Bathy* sonar applications) to use the time-domain beamformer. Leave this setting as *No* to use the original processing type for beamforming in post processing.

System Information

- **Ping Rate**

The ping rate is determined either by the current sonar application, or calculated based on the network link speed.

- **Update Rate**

The update rate is the number of times the sonar view is updated per second. The displayed ping rate may be different from the update rate because the system might be impacted by other processes.

- **Mode ID**

All sonar applications have their own unique mode number. The mode number displayed here corresponds to a PRI Sequence ID found in the M3 software database.

Related topics

[Power User Settings XML file, page 188](#)

Program Head dialog box - Production Config page

You can perform advanced tasks in the **Program Head** dialog box, such as configuring production settings, making head corrections, or changing transmit pulse definitions.


How to open

This dialog box is opened from the **Advanced** menu.

Note

*This dialog box is only available when the Sonar Head is connected and paused. To pause the Sonar Head, click **Setup**→**Connect**, then open the Menu Widget in the top-right corner of the sonar view. Click **Pause**.*

Select the **Production Config** tab.



Description

Use the **Production Config** page to view or change advanced Sonar Head parameters, such as the Serial Number or MAC Address. This page is primarily intended for use by production test engineers.

Details

Head

The **Head** table shows you the serial number and IP Address of the Sonar Head.

Configuration file

Click the folder icon to browse for the latest configuration file on your local drive. Click the **Load from file** button to populate the **Production Configuration** fields with values from your configuration file.

To save the current parameters, locate the field at the bottom of the dialog box and choose a filename or browse to replace an existing file. Click the **Save to file** button beside this field.

Production Configuration

This table lists all the advanced parameters and their values for the Sonar Head.

Write Config

Click this button to re-program the Sonar Head with the parameters displayed in the **Production Configuration** table.

Read Config

Click this button to populate the **Production Configuration** fields with the current parameter values (values are read from the Sonar Head).

Program Head dialog box - Head Corrections page

You can perform advanced tasks in the **Program Head** dialog box, such as configuring production settings, making head corrections, or changing transmit pulse definitions.


How to open

This dialog box is opened from the **Advanced** menu.

Note

*This dialog box is only available when the Sonar Head is connected and paused. To pause the Sonar Head, click **Setup**→**Connect**, then open the Menu Widget in the top-right corner of the sonar view. Click **Pause**.*

Select the **Head Corrections** tab.



Description

Use the **Head Corrections** page to write Phase/Amplitude Corrections or Range Reference Coefficients to the Sonar Head. This page is primarily intended for use by production test engineers.

Details

Head

The **Head** table shows you the serial number and IP Address of the Sonar Head.

Configuration type

Select the type of configuration you wish to apply.

Configuration file

Click the folder icon to browse for the latest configuration file on your local drive.

Click the **Write** button to apply the configuration parameters in your file to the Sonar Head. Click the **Read** button to save the current Sonar Head configuration to your configuration file.

Program Head dialog box - TX Pulse page

You can perform advanced tasks in the **Program Head** dialog box, such as configuring production settings, making head corrections, or changing transmit pulse definitions.


How to open

This dialog box is opened from the **Advanced** menu.

Note

*This dialog box is only available when the Sonar Head is connected and paused. To pause the Sonar Head, click **Setup**→**Connect**, then open the Menu Widget in the top-right corner of the sonar view. Click **Pause**.*

Select the **TX Pulse** tab.



Description

Use the **TX Pulse** page to apply a new TX pulse definition to the Sonar Head if a new TX pulse is designed for the M3 software database.

Details

Configuration file

Click the folder icon to browse for the latest configuration file on your local drive.


Click the **Write** button to apply the configuration parameters in your file to the Sonar Head. Select the box if you wish to load the transmit pulse definitions when connecting to the Sonar Head.

Profile Batch Conversion dialog box

The **Profile Batch Conversion** dialog box allows you to convert many data files at once into another format.

How to open

This dialog box is opened from the **Advanced** menu.



Description

You can convert “.mmb”, “.imb”, and “.pmb” files. The current profiling settings in the M3 software are used when converting to “.all” files. The source and destination folders

are saved in the “PowerUsersInfo.xml” file after the **Profile Batch Conversion** dialog box is closed.

After setting up the batch conversion, click the **Convert** button to start the conversion process. You can view the progress of both the current file and of all files in the batch.

Details

Input type

Select the type of source file that you wish to convert. Click the **Browse Source** button to select a valid source file or folder.

Export type

Select the file type for your destination file. Click the **Browse Destination** button to select a destination folder or enter a filename.

If your selected export type is “.pmb”, then you can check the *Water Column* box to export the “.pmb” file with water column data. When saving water column data, profile range and bearing data will also be saved. Split-beam profiling will include amplitude and phase in the water column data, but the default profiling mode will include amplitude only.

Convert Mode

Select *Folder* for batch conversion. If you check the *Sub Folder* box, then all files in all sub folders will be included in the batch conversion. To convert a single file, select *File*.

Related topics


[Power User Settings XML file, page 188](#)

Raw Data Spectrum window

The **Raw Data Spectrum** window allows you to find and observe any noise in the data.

How to open

This window is opened from the **Advanced** menu.



Description

This window displays the normalized, real-time raw data spectrum. The baseband sampling frequency range of the received signal is shown on the x-axis, and the normalized spectrum amplitude is shown on the y-axis (in dB). You can also view the carrier frequency of the raw data, the normalized transmitted signal frequency spectrum, and the maximum signal strength averaged across the elements.

Power User Settings XML file

The Power User Settings XML file allows you to change advanced M3 software parameters by editing the file with any text editor.

How to open

Note

Close the M3 software before editing the Power User Settings XML file.

Download and install a free XML file editor, such as Notepad++. Navigate to C:\KML\M3_V0254\BIN\SETTINGS. Open the “PowerUsersInfo.xml” file with your XML file editor.

```
<?xml version="1.0" encoding="UTF-8" ?>
<!--Remove blank lines!-->
<dataroot Software="M3" Version="0002">
  <User>
    <ID>0</ID>
    <Name>none</Name>
    <Password>none</Password>
    <Level>P</Level>
    <DeploymentFile></DeploymentFile>
    <Settings>
      <PlaybackOverrideBeamlists>No</PlaybackOverrideBeamlists>
      <OverrideBeamlistFile></OverrideBeamlistFile>
      <ProcessingTypeOverride>No</ProcessingTypeOverride>
      <BatchProfilingSrcFolder></BatchProfilingSrcFolder>
      <BatchProfilingDesFolder></BatchProfilingDesFolder>
      <Profile3DCloudPingToKeep>2000</Profile3DCloudPingToKeep>
      <ProfileSpikeFilter>0</ProfileSpikeFilter>
      <ProfileContinuousContour>0</ProfileContinuousContour>
      <ProfileSelectionFilterCoef>1.00</ProfileSelectionFilterCoef>
    </Settings>
  </User>
</dataroot>
```

Description

You need a software license key to apply the values in the “PowerUsersInfo.xml” XML file to the M3 software. If you do not have a software license, then the default values will be used. The new values will be applied after restarting a licensed copy of the M3 software.

Details

<PlaybackOverrideBeamlists>

This feature allows you to replace the beamlist of a recorded “.mmb” file with a new beamlist XML file. The recorded raw data will be beamformed based on the new beamlist. Enter a value of “Yes” or “No” in the XML tag.

<OverrideBeamlistFile>

Enter the beamlist file’s address into the XML tag.

<ProcessingTypeOverride>

Enter a value of “Yes” or “No” in the XML tag. This feature allows you to switch between the time-domain beamformer and the FFT beamformer for profiling applications. Select the *Profiling* option when playing back an “.mmb” file (recorded using the *Profiling - Fast* or *Profiling - Bathy* sonar applications) to use the time-domain beamformer. Leave this setting as *No* to use the original processing type for beamforming in post processing.

<BatchProfilingSrcFolder>

In the XML tag, enter the address of the folder for the files you wish to convert.

<BatchProfilingDesFolder>

In the XML tag, enter the address of the destination folder where your converted files will be saved.

<Profile3DCloudPingToKeep>

This parameter controls how many pings to keep in the memory when displaying a 3D point cloud. The maximum value depends on the amount of memory allocated to the point cloud. If the value you enter exceeds the maximum, then it will be reset to the default value of 2000.

<ProfileSpikeFilter>

This parameter removes noisy profiling points due to midwater objects, such as fish, and is useful when a clean bottom profile is needed. Enter a value between zero and 51 into the XML tag (zero disables the filter). The spike filter applies to profiling applications.

<ProfileContinuousContour>

This parameter interpolates the profiling result before it is displayed. Sometimes the bottom profile has missing points due to noise or midwater objects. Enabling this filter can replace these points. For example, this filter will fill out a hole in the middle of a bottom profile, but may produce artificial points at both edges.

<ProfileSelectionFilterCoef>

This parameter adjusts the smoothing filter before selecting the profiling algorithm.
Enter a value between one and ten in the XML tag.

Related topics

[Power User Settings dialog box, page 177](#)

[Profile Batch Conversion dialog box, page 185](#)

Help menu

The **Help** menu allows you to view hardware and software information in the **About M3** dialog box. You can also open the M3 Sonar *Reference Manual* from this menu.


How to open

To open this menu, click the menu title.

Description

About M3

The **About** dialog box identifies the current software version. The version described in this publication is 2.5.4.



User Manual


Click **User Manual** to open the M3 Sonar *Reference Manual* in PDF format. This manual is only applicable to the software version you are using. If you are using an older version of software, it will not be the latest version.

Tip

Contact your local dealer or distributor for the latest software versions, and download the latest manuals from <https://www.kongsbergdiscovery.net/>.

Tool bar description

The tool bar provides buttons for functions, filters, and sonar view overlays.



The tool bar provides access to useful functions, such as the ability to take a screenshot or change your TVG settings. In addition, several measuring tools are available.

A Arrow

Click to use the default arrow cursor. With the default cursor you can select and manipulate objects on the screen.

B Wiper

Removes items from the sonar view. When selected, click on each overlay you wish to delete.

C Zoom windows

You can open up to four true zoom windows when running a Sonar Head.

D Tape Measure

Measures distances on the sonar view. Also allows you to place a measurement overlay on the sonar view.

E Protractor

You can use the protractor to measure the angle between two lines, then place the resulting overlay in the sonar view.

F String Measure

You can use the string measure tool to define an area. The size and perimeter of the area will be calculated for you.

G Text Label

The text label tool allows you to place comments on the screen.

H Reference Cursor 1

I Reference Cursor 2

You can place one or two reference cursors as overlays on the sonar view. When you place two cursors, an additional overlay will appear with information about the cursors.

J Image Quality Analysis System

The Image Quality Analysis System (IQAS) analyzes the image quality of a point target, or can be used to measure a known point target against a specification.

K Y1

Horizontal line overlay that can be used to mark the depth of the natural seabed (for use when excavating).

L Y2

Horizontal line overlay that can be used to mark the depth of a trenching target (for use when excavating).

M Show Full Screen

Click **Full Screen** to make the sonar view full screen. Press the **Esc** key to exit full-screen mode.

N Save image with overlays

Click this button to save sonar view images, including any overlays you've placed in the sonar views.

O Save image without overlays

Click this button to save sonar view images, excluding any overlays you've placed in the sonar views.

P TVG Setup dialog box

TVG (Time Variable Gain) compensates for the loss of acoustic energy due to geometric spreading and absorption.

Q Average Filter

Clicking the "A" button will enable the Average Filter. This filter reduces noise. Slow-moving features persist on-screen.

R Background Removal

Clicking the "B" button will enable the Background Removal filter. This filter removes stationary parts of the background to enhance moving objects (such as fish, for example).

S Edge Enhancement

Clicking the "E" button will enable Edge Enhancement. This filter enhances the edge of moving features.

T No Filter

Disables any filters. The sonar view will display an unfiltered sonar image.

Topics

[Arrow, page 194](#)

[Wiper, page 194](#)

[Zoom windows, page 195](#)

[Tape Measure, page 196](#)

[Protractor, page 196](#)

[String Measure, page 196](#)

[Text Label, page 197](#)

[Reference cursors, page 197](#)

[Image Quality Analysis System, page 198](#)

[Save image with or without overlays, page 199](#)

[TVG Setup dialog box, page 200](#)

[Filters, page 203](#)

Arrow

Click to use the default arrow cursor. With the default cursor you can select and manipulate objects on the screen.

If you are currently using one of the tools, such as the **Tape Measure** for example, clicking the **Arrow** button will cancel the current tool.



To move overlays around in the sonar view, click the **Arrow** button, then click and hold the left mouse button on an overlay. Drag it to where you want it then release the mouse button.

Wiper

Removes items from the sonar view. When selected, click on each overlay you wish to delete.

If your sonar view becomes too cluttered with overlays, you may wish to remove some of them.



Click the **Wiper** button, then left-click on any overlay that has been placed in the sonar view (such as a **Reference Cursor**, for example) to remove it. Note that you cannot undo this action.

Zoom windows


You can open up to four true zoom windows when running a Sonar Head.

To open a zoom window, click the **Zoom windows** button in the tool bar, then click a target of interest in the sonar view.



The zoom area (A) in the sonar view is a fixed size and cannot be adjusted. However, you can move the zoom area to another location with the cursor. The images in the true zoom windows (B) are acquired separately using high-resolution sampling parameters and adequate transmit pulses.

If you record sonar data while the zoom windows are open, the zoom window data will also be recorded for replay. During playback, the zoom windows will open automatically.



Tip

Reference cursors can be used with a Zoom window. To make fine adjustments to the cursor position, drop a reference cursor into a Zoom window.

Tape Measure

Measures distances on the sonar view. Also allows you to place a measurement overlay on the sonar view.

To measure the distance between two targets, click the **Tape Measure** button. Click and hold the left mouse button on your first target, then drag the mouse to your second target. The length and bearing between the targets is displayed dynamically. The measurement line will not remain on the display when you release the mouse button.



To place a persistent measurement overlay, click and hold the right mouse button on your first target, then drag the mouse to your second target and release the mouse button. Click the left mouse button to place the overlay.

Tip

Once the measurement overlay is placed, you can use the default arrow cursor to drag the length and bearing label to a position on the screen where it is more legible.

Related topics

[Measuring distances, page 76](#)

Protractor

You can use the protractor to measure the angle between two lines, then place the resulting overlay in the sonar view.

The protractor tool measures the angle between a baseline and a second line that intersects the baseline.



In the sonar view, click the point where you want to start the baseline. Click the point where you want to end the baseline. Lock one end of the second line to the baseline. Choose where you want the second line to end.

Related topics

[Measuring angles, page 77](#)

String Measure

Defines and measures perimeters and areas. Allows you to place an area overlay on the sonar view.

To define an area, click the **String Measure** button. Click anywhere in the sonar view to start a point. Move to the second point, then click again. Click as many times as necessary to create the required area. Double-click on the last point to finish. The area will



automatically be closed, and a rectangular label will appear providing information about the area and perimeter. Move the label to a position on the screen where it is most legible, then click the left mouse button to place it.

Tip

*You can place multiple areas on the display. The areas will remain on the display until you delete them individually with the **Wiper** function.*

Related topics

[Defining an area, page 78](#)

Text Label

The text label tool allows you to place comments on the screen.

Click the **Text Label** button. In the sonar view, click the area of interest that you want to label. Click and hold the left mouse button on the label overlay and drag it to a place on the screen where the text is legible. Double-click on the label overlay to open an **Edit Text Box** dialog box.



Tip

If the text you entered does not fit within the text label overlay, you can resize the label by clicking on the label border, then dragging it to create a larger label.

Related topics

[Placing text labels, page 78](#)

Reference cursors

You can place one or two reference cursors as overlays on the sonar view. When you place two cursors, an additional overlay will appear with information about the cursors.

To mark a point of interest, you can place a cross-hair type marker on the sonar view. Click one of the **Reference Cursor** buttons. Choose where you want to place the cursor, then click the left mouse button to place it. The range and bearing of the cursor's position — relative to the Sonar Head — is shown in the bottom-left corner of the view.



When you place both cursor 1 and cursor 2 on the sonar display, the cursor range and bearing — relative to the Sonar Head— will be displayed. “Delta” shows the range and bearing from cursor 1 to cursor 2.

Cursor: 1	Cursor: 2	Delta:
154.5°	14.3°	357.9°
45.425 m	63.702 m	102.794 m

Related topics

[Placing reference cursors, page 79](#)

Image Quality Analysis System

The Image Quality Analysis System (IQAS) analyzes the image quality of a point target, or can be used to measure a known point target against a specification.


IQAS measures a known point target against a specification, such as resolution, Peak Side Lobe Ratio (PSLR), or Integrated Side Lobe Ratio (ISLR).



To enable IQAS, click the **IQAS** button on the tool bar.

Two IQAS dialog boxes will open. One dialog box shows the range (in metres), and the other shows the azimuth angle (in degrees).

Move the IQAS cursor to a target of interest in the sonar view, then click the left mouse button to place the cursor.



The following information will be displayed in the two IQAS dialog boxes.

Resolution, Impulse Response Width (IRW)

The IRW is measured 3 dB down from the top of the Main Lobe of the impulse response. In the range dialog box, the IRW is displayed in pixels and metres. In the azimuth angle dialog box, the IRW is displayed in pixels and degrees.

Peak Side Lobe Ratio (PSLR)

The PSLR is the Peak Side Lobe level in the Near Region relative to the level of the Main Lobe. The unit of measurement is dB.

Integrated Side Lobe Ratio (ISLR)

The ISLR is the ratio of the energy in the Near Region to the energy within the Main Lobe Region. The unit of measurement is dB.

Save image with or without overlays

With one click, you can capture an image of the sonar view — either with overlays or without overlays. Click this button to save sonar view images, including any overlays you've placed in the sonar views.

Click the **Save image with overlay** button to save the sonar view image, including any overlays (such as the Tape Measure or Text Labels for example) you've placed in the sonar view. If you want to save the sonar view without overlays, click the **Save image without overlay** button instead.



Your images will be saved under the folder “C:\KML\M3_V0254\Images” by default. You can change this save location through the **Preferences** dialog box.

A text file with information on the image capture sonar settings will also be created.

Tip _____

*Open the **Preferences** dialog box to change the default save location, choose your own filename, and add overlay text.*

TVG Setup dialog box

When an acoustic pulse is sent through the water, it will gradually lose its energy. The greater the distance between the transducer and the target(s), the greater the loss of energy. **TVG** (Time Variable Gain) compensates for the loss of acoustic energy due to geometric spreading and absorption.


How to open

Note

*Each sonar application has its own TVG profile. Before changing the TVG settings, start the sonar (click **Setup**→**Connect**), then select the sonar application you want to configure from the **Sonar applications list**.*

If you are using a high-frequency M3 Sonar, the TVG profiles will not be saved when closing the software — default values will apply when switching to a new frequency or when starting up the M3 software.

Click the **TVG** button. This button is located on the tool bar.



Description

When an acoustic pulse is sent through the water, it will gradually lose its energy. The greater the distance between the transducer and the target(s), the greater the loss of energy.

- **Geometric spread**

Once transmitted, the acoustic energy will spread out to form a circular beam. The width of this beam increases with the physical distance to the target(s).

- **Absorption loss**

Depending on the salinity and temperature, the water will absorb some of the energy from the acoustic transmission. The absorption loss increases as the physical distance to the target(s) increases.

Both the geometric spread and the absorption will also have an effect on the returned echo signal. That is why we normally refer to these factors as the two-way transmission loss.

The TVG (Time Variable Gain) compensation is designed to counteract the natural phenomena of geometric spread and absorption loss. In the M3 Sonar system, the TVG compensation is made using digital signal processing software. By means of algorithms, the time variable gain compensation converts the echo presentation as a function of range. This makes the targets with the same strength appear with the same intensity independent of their physical distance from the transducer.

Details

The TVG compensation is expressed as a logarithmic curve. You can choose from a selection of curves. Each curve has a different slope creating a different gain compensation. Four adjustable factors are used to set the gain curve.

A Factor

Represents spreading loss.

B Factor

Represents one-way absorption loss.

C Factor

Represents a base or starting gain level.

L Factor

Limits the maximum gain to reasonable levels.

To the left of the TVG curve display is a slider with a range from -30 to 130. This represents the system gain. Moving this slider down until the line intersects the green TVG curve will cause a Range-Gain pair of values to be displayed in the “Range-Gain” box. Adjust this slider to determine the gain at a particular range.

If you have a software license for advanced features, then an additional pane and slider bar will become available. When the Sonar Head is running, a graphic representation of the receive signal will appear at the bottom of the dialog box so that you can ensure that the signal is not being clipped. A slider is provided so that you can exclude the low end percent of the gain.

Related topics

[Adjusting the TVG \(Time Variable Gain\) setting, page 42](#)

Filters

You can apply an averaging, background removal, or an edge enhancement filter to the sonar view.



Note

*You can adjust the strength of these filters in the **Display Widget**.*

Average Filter

Clicking the “A” button will enable the Average Filter. This filter reduces noise. Slow-moving features persist on-screen.

This filter averages the image from ping to ping so that slow-moving features will persist, while reducing noise in the image. The Average Filter is especially useful when the image is constructed from multiple pings.

Background Removal

Clicking the “B” button will enable the Background Removal filter. This filter removes stationary parts of the background to enhance moving objects (such as fish, for example).

Edge Enhancement

Clicking the “E” button will enable Edge Enhancement. This filter enhances the edge of moving features.

This filter provides some persistence for the image. Edge Enhancement is especially useful when you wish to view a school of fish clearly, for example.

No Filter

Disables any filters. The sonar view will display an unfiltered sonar image.

No filtering is preferable if instantaneous readings are required, since this shortens the delay between updating the changes in sonar data, and the corresponding displayed information.

Related topics

[Applying filters, page 42](#)

Technical specifications

Topics

[Introduction to technical specifications, page 205](#)

[Interface specifications, page 206](#)

[Performance specifications, page 209](#)

[Mechanical specifications, page 213](#)

[Power requirements, page 215](#)

[Environmental requirements, page 216](#)

[Minimum computer requirements, page 217](#)

Introduction to technical specifications

These technical specifications summarize the main functional and operational characteristics of the M3 Sonar Multibeam sonar. They also provide information related to power requirements, physical properties and environmental conditions.

Note

At Kongsberg Discovery, we are continuously working to improve the quality and performance of our products. The technical specifications may be changed without prior notice.

Interface specifications

The M3 Sonar system will interface with peripheral systems and sensors using standard and/or proprietary datagram formats.

Supported datagram formats for GPS (position) information

The M3 Sonar system supports the following datagram formats for position information:

- **NMEA GGA**

The NMEA GGA datagram transfers time-, position- and fix-related data from a global positioning system (GPS).

- **NMEA GLL**

The NMEA GLL datagram transfers the latitude and longitude of vessel position, the time of the position fix and the current status from a global positioning system (GPS).

- **GGK**

This third party datagram format contains the vessel's current position with the assigned coordinated universal time (UTC) of position, as well as a selection of position quality factors.

Supported datagram formats for speed information

The M3 Sonar system supports the following datagram format for speed information:

- **NMEA VTG**

The NMEA VTG datagram contains the actual course and speed relative to the ground.

Supported datagram formats for heading information

The M3 Sonar system supports the following datagram formats for vessel heading and/or gyro information:

- **NMEA HDG**

The NMEA HDG datagram provides heading from a magnetic sensor. If this reading is corrected for deviation, it produces the magnetic heading. If it is offset by variation, it provides the true heading.

- **NMEA HDM**

The NMEA HDM datagram provides vessel heading in degrees magnetic. The datagram is no longer recommended for use in new designs. It is often replaced by the NMEA HDG telegram.

- **NMEA HDT**

The NMEA HDT datagram provides the true vessel heading. The information is normally provided by a course gyro.

- **EM Attitude 3000**

The Kongsberg EM Attitude 3000 is a proprietary datagram format created by Kongsberg Discovery for use with digital motion sensors. It holds roll, pitch, heave and heading information. The datagram contains a 10-byte message.

- **Octans STD1**

This is a third-party proprietary datagram format for heading, speed, and motion. It was created by iXSea (<http://www.ixblue.com>) for use with their Octans gyrocompass.

Supported datagram formats for motion information

The M3 Sonar system supports the following datagram formats from a motion sensor:

- **Teledyne TSS1**

Teledyne TSS1 is a proprietary datagram format for heave, roll and pitch compensation. When you select this protocol, the number of sensor variables is fixed, and there is no token associated with it.

- **EM Attitude 3000**

The Kongsberg EM Attitude 3000 is a proprietary datagram format created by Kongsberg Discovery for use with digital motion sensors. It holds roll, pitch, heave and heading information. The datagram contains a 10-byte message.

- **Octans STD1**

This is a third-party proprietary datagram format for heading, speed, and motion. It was created by iXSea (<http://www.ixblue.com>) for use with their Octans gyrocompass.

Supported datagram formats for sound speed sensors

The M3 Sonar supports the following datagram format from a sound speed sensor.

- **Valeport**

This is a third-party proprietary datagram format created by Valeport Ltd. for use with their sound velocity sensors. The file format is ASCII. There are three formats: standard format (millimetres per second), alternative format #2 (metres per second with two decimal places), and alternative format #3 (metres per second with three decimal places). For more information, see <http://www.valeport.co.uk>.

Note

If you are using a Sonar Head with an integrated AML sound speed sensor, you do not need to interface with a datagram as it is built into the sonar.

Supported datagram formats for depth information

The M3 Sonar system supports the following datagram formats for depth output:

- **NMEA DBT**

The NMEA DBT datagram provides the current depth under the transducer. In new designs, this datagram format is frequently used to replace the DBK and DBS formats.

- **NMEA DPT**

The NMEA DPT datagram provides the water depth relative to the transducer, and the offset of the measuring transducer.

Processed data formats

The following processed data output formats are available.

- **.mmb**

This is raw element data, not beamformed, in a 16-bit fixed-point complex format. This format allows great flexibility in how the data is processed and allows you to do your own beamforming or profile-point extraction. The data body size is determined by the number of elements and the number of samples.

- **.imb**

This format consists of beamformed data.

You can choose between a 32-bit floating point complex or 8-bit integer magnitude format. Select the 8-bit format only if you are interested in imaging pixel data and want a reduced data file size. The 8-bit format takes up a quarter of the 32-bit format's size.

Data body size is determined by the number of beams and samples. Different modes may form a different number of beams. Therefore, data body size may change depending upon the mode.

- **.ALL**

This is the proprietary Kongsberg EM series datagram format. The M3 software can output this data format to be compatible with third-party post-processing software.

Synchronization

- **PRI Sync**

PRI Sync (set with *Trigger Mode* on the **Sonar Setup** page of the **System Configuration** dialog box) provides ping synchronization with another Sonar Head or other acoustic source that supports synchronization (for example, EK60, Sidescan, DVL, etc.). PRI Sync is a level-sensitive method of synchronization. When the sync is held high, the sonar will not transmit. The PRI Sync INPUT must be held low for 25 μ s in order to trigger the Sonar Head. The Sonar Head will transmit a 100 μ s sync OUTPUT pulse when configured as **Master** on the **Sonar Setup** page. The sync OUTPUT is generated each time the Sonar Head transmits.

- **Host Time Sync Mode**

Host mode synchronizes the Sonar Head time with the computer time. This mode is critical for Bathymetry applications. *Host* mode only works if the computer is connected to an accurate time source, such as a GPS or network time server. When connecting to the Sonar Head, it takes two minutes to synchronize the time to within five milliseconds.

- **1PPS Time Sync Mode**

1PPS is a 0 to 5 VDC pulse, with a 50% duty cycle. The Sonar Head time can be synchronized to external 1PPS pulses.

The time is synchronized to the rising edge of the 1PPS pulses. When the rising edge of a 1PPS pulse is detected then the ns, us and ms counters are set to zero. The second counter is set to zero if the ms counter is < 500 and increased by 1 if the ms counter is >= 500.

1PPS synchronization requires ZDA input over UDP to the Sonar Head (not to the M3 software) on UDP port 31100 at 1Hz.

The 1PPS signal must be sent to the Sonar Head using the 1PPS input on one of the following cables.

- 10-pin SEA CON® MINK-10-CCPL cable used with M3 Sonar model 922-20220000.
- 4-pin SEA CON® MIND-4-FCR cable used with M3 Sonar model 922-20050000.

The Sonar Head must be upgraded to the latest firmware version (version 1.5 or later).

- **Computer Time Sync**

If ZDA is configured, the M3 software will use the time in the ZDA message to synchronize the computer clock automatically in the background. However, you may need to run the M3 software as an administrator (right-click on the icon and select **Run as administrator**) or Windows may not allow the software to change the system clock. Computer time sync can be useful when data is being logged on more than one computer and synchronized timing is required. This method is not recommended for Bathymetry applications as it is not accurate enough.

Note

Computer time sync requires both GGA and ZDA input.

Performance specifications

These performance specifications summarize the main functional and operational characteristics of the M3 Sonar system.

- **Slant range:** 0.2 to 150 m (depends on model)
- **Coverage:** up to 140°

- **Range resolution:** 1 cm
- **Frequency:** 500 kHz to 1400 kHz (depends on model)
- **Pulse types:** CW, LFM
- **Communication:** Ethernet
- **Data Rates:** 10/100/1000 Mbps

Synchronization

- **PRI Synchronization (master / slave operation):**
 - **Sync Input:** 0 to 5 VDC, hold-off when high
 - **Sync Output:** 0 to 5VDC active low pulse 100µs
- **1PPS Synchronization**

Note

*The selection of sonar applications presented in the **Sonar Applications** menu depends on the current Sonar Head frequency. The M3 software will automatically detect the frequency of your Sonar Head and display only the applicable sonar applications.*

Variable Vertical Beamwidth (Imaging) mode — 500 kHz

- **Horizontal Field of View:** 120°
- **Vertical Field of View:** 3°, 7°, 15°, 30°
- **Angular Resolution:** 1.6°
- **Update rate:** up to 40 Hz

EIQ mode — 500 kHz

- **Horizontal Field of View:** 140°
- **Vertical Field of View:** 30°
- **Angular Resolution:** 0.95°
- **Update rate:** up to 10 Hz

Bathymetry/Profiling mode — 500 kHz

- **Across track field of view:** 120°
- **Along track field of view:** 3°
- **Number of beams:** up to 256

- **Update rate:** up to 40 Hz
- **Beam spacing:** Equiangular

Imaging mode — 700 kHz

- **Horizontal Field of View:** 140°
- **Vertical Beamwidth:** 30°
- **Angular Resolution:** 1.0°
- **Update rate:** up to 40 Hz

Imaging mode — 950 kHz

- **Horizontal Field of View:** 140°
- **Vertical Beamwidth:** 27°
- **Angular Resolution:** 0.8°
- **Update rate:** up to 40 Hz

Imaging mode — 1200 kHz

- **Horizontal Field of View:** 75°
- **Vertical Beamwidth:** 21°
- **Angular Resolution:** 0.65°
- **Update rate:** up to 40 Hz

Imaging mode — 1400 kHz

- **Horizontal Field of View:** 45°
- **Vertical Beamwidth:** 18°
- **Angular Resolution:** 0.55°
- **Update rate:** up to 40 Hz

Profiling mode — 700 kHz

- **View angle:** 140°
- **Resolution:** 1.8° x 2.0°
- **Max Range:** 140 m
- **No. of Beams:** 256

Profiling mode — 950 kHz

- **View angle:** 140°

- **Resolution:** 1.4° x 1.5°
- **Max Range:** 100 m
- **No. of Beams:** 256

Profiling mode — 1200 kHz

- **View angle:** 75°
- **Resolution:** 1.1° x 1.2°
- **Max Range:** 70 m
- **No. of Beams:** 256

Profiling mode — 1400 kHz

- **View angle:** 45°
- **Resolution:** 0.9° x 1.0°
- **Max Range:** 50 m
- **No. of Beams:** 256

Profiling - HiRes mode — 700 kHz

- **View angle:** 140°
- **Resolution:** 1.8° x 1.0°
- **Max Range:** 140 m
- **No. of Beams:** 512

Profiling - HiRes mode — 950 kHz

- **View angle:** 140°
- **Resolution:** 1.4° x 0.75°
- **Max Range:** 100 m
- **No. of Beams:** 512

Profiling - HiRes mode — 1200 kHz

- **View angle:** 75°
- **Resolution:** 1.1° x 0.6°
- **Max Range:** 70 m
- **No. of Beams:** 512

Profiling - HiRes mode — 1400 kHz

- **View angle:** 45°
- **Resolution:** 0.9° x 0.5°
- **Max Range:** 50 m
- **No. of Beams:** 512

VDSL

Firmware version: 1.5

Part number: 320-27701000-0150 (Rx controller)

Important _____

Although VDSL sonar heads are pre-programmed at the factory with the correct firmware, you may need to upgrade your firmware if you do not have the latest version for your VDSL Sonar Head. For the best performance, firmware version 1.5 (or later) is required for applications using a long cable and VDSL telemetry. Note that you only need to upgrade the Sonar Head receive firmware file (.RXF) and the Sonar Head software file (.ASW). You do not need to upgrade the Sonar Head transmit firmware file (.TXF).

AML SVT Xchange sound speed sensor

A Sonar Head with an integrated AML sound speed sensor is available from Kongsberg Discovery.

- **Range:** 1375 - 1625 m/s
- **Resolution:** 0.001 m/s
- **Accuracy:** 0.025 m/s
- **Response time:** 20 ms
- **Precision:** 0.006 m/s

Mechanical specifications

These mechanical specifications summarize the physical properties of the M3 Sonar system.

Sonar Processor

The Sonar Processor uses a high-quality commercial-off-the-shelf laptop computer workstation. The weight and dimensions of the model may vary. Contact your Kongsberg

Discovery representative for information about the current model that is delivered with your M3 Sonar system.

500 m Sonar Head

- **Depth rating:** 500 m
- **Dimensions**
 - **Diameter:** 185 mm (7.28")
 - **Depth:** 126 mm (4.95")
- **Weight:** 4.4 kg (air), 1.8 kg (water)
- **Materials:** Anodized Aluminium, Stainless Steel 316, Elastomeric Polyurethane
- **Connector type:** SEA CON®
- **Connector model:** MINK-10-FCRL (Telemetry & Power)

4000 m Sonar Head

- **Depth rating:** 4000m
- **Dimensions**
 - **Diameter:** 185 mm (7.28")
 - **Depth:** 140 mm (5.50")
- **Weight:** 8.2 kg (air), 5.1 kg (water)
- **Materials:** Titanium, Stainless Steel 316, Elastomeric Polyurethane
- **Connector type:** SEA CON®
- **Connector model:** MINK-10-FCRL (Telemetry & Power)

Optional connector models

- **Synchronization:** SEA CON®, MIND-4-FCR
- **100BaseTX Ethernet and Power:** Alstom Seanet (4000 m M3 Sonar only)
- **100BaseTX Ethernet and Power:** SubConn MCBHRA6MSS (500 m M3 Sonar only)

High-frequency Sonar Head

- **Depth rating:** 4000 m
- **Dimensions**
 - **Width:** 218 mm (8.59")
 - **Height:** 144 mm (5.67")
- **Weight:** 7.8 kg (air), 5.0 kg (water)

- **Materials:** Titanium, Elastomeric Polyurethane
- **Connector type:** SEA CON®
- **Connector model:** MINK-10-FCRL (Telemetry & Power)

VDSL

Cable requirements: One twisted pair (100-ohm impedance)

Note

VDSL will work over two wires. Actual data rate will vary with the cable quality.

- **3 m (10 foot) cable:** Up to 100 Mbps
- **152 m (500 foot) cable:** Up to 100 Mbps
- **1000 m (3300 foot) cable:** 27 Mbps (measured on Belkin 1353A)

AML SVT Xchange sound speed sensor

A Sonar Head with an integrated AML sound speed sensor is available from Kongsberg Discovery.

- **Depth rating:** 11000 m
- **Weight:** 120 g
- **Material:** Titanium

Power requirements

These power characteristics summarize the supply power requirements for the M3 Sonar system.

Sonar Processor

- **Power adapter input voltage:** 120/240 VAC
- **Laptop input voltage:** 19.5 VDC @ 180W (max)

Sonar Head

- **Input voltage:** 12 to 36 VDC
- **Input power:** 22W (avg.), peak power < 60W, mode dependant
- **Maximum cable loop resistance for Sonar Head power:**
 - 0.1 Ω @ 12VDC

- 2 Ω @ 24VDC
- 6 Ω @ 36VDC

Note

These values were measured at +23°C.

Environmental requirements

These specifications summarize the temperature requirements and other environmental standards for the M3 Sonar system.

Sonar Processor

The Sonar Processor uses a high-quality commercial-off-the-shelf laptop computer workstation. This computer is intended to be installed inside in an area suitable for extended human habitation. Contact your Kongsberg Discovery representative for information about the current model that is delivered with your M3 Sonar system.

Sonar Head

- **Temperature:** -2° to + 38 °C (operation), -40 to +55 °C (storage)
- **Shock qualified:** +/-50gs, 3 Axes, 6 shocks per axis
- **Vibration qualified:** 4g, 30Hz 3 Axes, 2 hours per axis. No resonance below 800Hz

The stated operation temperature range is for the Sonar Head in water. The Sonar Head can be powered on and started at temperatures between -20° to +45° C. There is a built-in temperature monitor that will display a software warning message and automatically power down the Sonar Head before it overheats.

Caution

The Sonar Head must not be exposed to direct sunlight for prolonged periods of time. Prolonged exposure to ultra-violet rays and excessive heat may damage the surface of the polyurethane transducer face. Store the Sonar Head in a cool, dry location away from ozone sources (such as electric motors or welders).

AML SVT Xchange sound speed sensor

A Sonar Head with an integrated AML sound speed sensor is available from Kongsberg Discovery.

- **Storage temperature:** -20 to 60 °C
- **Operating temperature:** -5 to 45 °C

Minimum computer requirements

Although a computer can be ordered from Kongsberg Discovery as a part of the M3 Sonar system delivery, it is also possible to purchase one locally.

If you purchase a computer locally, make sure that the chosen model meets the functional and technical requirements.

It is important that the chosen computer model is relatively new with sufficient processing power, a high performance graphics adapter, and a high speed Ethernet adapter.

We recommend a computer with a CPU that has a PassMark Software benchmark score of 14,000 or more (passmark.com).

PassMark Software is a Windows computer performance benchmarking utility. Computers with a CPU score of 14,000 or higher have been tested with the M3 Sonar. Lower-scoring computers may not perform well, resulting in a slow GUI response, slower ping rates, or dropped pings.

When running two M3 Sonars, an average CPU Mark of 30,000 is recommended.

The computer must be able to facilitate the various interface requirements made by the M3 Sonar system, and you may need to add extra Ethernet and/or serial adapters.

Note

The computer design and construction must allow for maritime use. Easy access to connectors, parts and cables must be provided. Make sure that the installation method allows for the physical vibration, movements and forces normally experienced on a vessel.

The minimum technical requirements are:

- **Microprocessor:** 2.80 GHz, Intel quad core i7
- **Memory:** minimum 16 GB
- **Hard disk:** minimum 500 GB SSD (HDD not recommended as slower speed may impact software performance)
- **Graphics card RAM:** 256 MB
- **Network interface:** 100/1000 Mbps

- **Serial adapters:** One or more serial line interfaces are required. The number of serial lines depends on your interface requirements.
- **Operating system:** The M3 software has been designed for the Microsoft® 64-bit Windows 10 operating system. Windows 7 is supported for imaging applications only. Profiling applications will not work properly in Windows 7. Operating systems older than Windows 7 are not supported.

Display recommendations

A display is a required part of the M3 Sonar system. For best readability, the display must be protected from glare and have the correct height and angle. The design and construction must allow for marine use, and the display must be able to withstand the movements and vibrations normally experienced on a vessel.

- **Resolution:** We recommend that you use a large display with resolution 1920 x 1080. We do not recommend using a higher-resolution display, such as a 4K display, because it will use more processing power and may affect software performance.
- **Video interface:** The video interface must match the output format(s) provided by the computer.

The computer may offer video output on several formats. Investigate your options before you purchase a display.
- **Physical screen size:** The screen size depends on personal and/or operational preferences.

Index

- 1PPS Time Sync Mode
 - testing 30
- 3D Point Cloud
 - about 95
 - description 95
- 3D Point Cloud function
 - purpose 103, 123
- A**
- about
 - 3D Point Cloud 95
 - comments 8
 - constructive criticism 8
 - feedback 8
 - registered trademarks 7
 - software license 7
 - software version 7
 - sonar view 92
 - status bar 99
 - suggestions 8
 - target audience 7
 - this publication 7
- About dialog box
 - purpose 113, 191
- Add Device
 - System Configuration dialog box 152, 155
- adjust
 - sonar views 38
- Advanced menu
 - description 112, 176
 - how to open 112, 176
- Algorithm
 - Profiling Settings dialog box 130
- Angle
 - System Configuration dialog box 166
- angles
 - measuring 77
- Annotations
 - purpose 104, 124
- applying
 - filters 42
- areas
 - defining 78
- Arrow
 - description 194
- Auto
 - Convert to Video dialog box 119
- Autoconnect at program start
 - System Configuration dialog box 149
- Automatic IP address allocation
 - Head Network Setup dialog box 143
- Average Filter
 - description 203
- Azimuth Processing
 - Power User Settings dialog box 178
- B**
- Background Removal Filter
 - description 203
- basic procedures
 - introduction 19
- <BatchProfilingDesFolder>
 - Power User Settings XML file 189
- <BatchProfilingSrcFolder>
 - Power User Settings XML file 189
- Baud rate
 - Target Marker Export dialog box 125
- Baud Rate
 - System Configuration dialog box 152, 155
- button
 - Arrow 194
 - Average Filter 203
 - Background Removal Filter 203
 - Edge Enhancement 203
 - IQAS 198
 - No Filter 203
 - Protractor 196
 - Reference cursor 1 197
 - Reference cursor 2 197
 - Save image with overlay 199
 - Save image without overlay 199
 - String measure 196
 - Tape measure 196
 - Text label 197
 - Wiper 194
 - Zoom windows 195
- C**
- Calculator
 - Geo Projection dialog box 138
- changing
 - frequency 24
- changing IP Address
 - Sonar Head 85
- characteristics
 - mechanical 213
- choosing
 - sonar application 37
- Clutter Suppression
 - Profiling Settings dialog box 130
- comments
 - send us 8
- computer
 - minimum requirements 217
- concept
 - Time Variable Gain (TVG) 200
- Configuration
 - System Configuration dialog box 162
- Configuration file
 - Head Firmware Configuration dialog box 146
 - Program Head dialog box 182–183, 185
- Configuration type
 - Head Firmware Configuration dialog box 146
 - Program Head dialog box 183
- configuring
 - preferences 35
 - Sonar Processor 20

Connect			
Rotator Test dialog box	158		
Connect function			
purpose	106, 132		
connecting			
sonar head	34		
constructive criticism			
send us	8		
controlling			
rotator	49		
Convert			
Convert to Video dialog box	121		
Convert Mode			
Profile Batch Conversion dialog box	186		
Convert to Video dialog box			
Auto	119		
Convert	121		
Date/Time	119		
description	118		
details	119		
Display Filter	120		
Display Grid	119		
Display Mirror	120		
Display Overlay Text	120		
Display Position	120		
Display Sensor Data	120		
Folder Conversion	120		
Manual	119		
Match Ping Rate	119		
Max File Size	121		
One Frame per Ping	119		
Palette	119		
purpose	102, 115		
Quality	119		
Resolution	119		
Sidelobe Suppression	120		
Source File	121		
Source Folder	121		
Target File	121		
Target file naming convention	121		
Target Folder	121		
converting			
recordings	69–70		
Cropped Width			
Preferences dialog box	141		
Current Position			
Rotator Test dialog box	158		
custom sensor			
defining	46		
Customize Apps dialog box			
purpose	111, 171		
D			
Data bits			
Target Marker Export dialog box	125		
Data Bits			
System Configuration dialog box	152, 155		
Data Type			
Define Custom Sensor dialog box	135		
datagram formats			
depth information	208		
GPS (Global Positioning System)	206		
gyro compass	206		
heading sensor	206		
motion sensor	207		
positioning system	206		
sound speed	207		
speed log	206		
Date/Time			
Convert to Video dialog box	119		
Datum Parameters			
Geo Projection dialog box	138		
Define Custom Sensor dialog box			
Data Type	135		
defining	46		
Delimiter(s)	135		
description	134		
details	135		
Latitude / Longitude Format	135		
Message ID	135		
purpose	106, 132		
Sensor Format	135		
Sensor Name	136		
Termination	135		
Unit Scale Factor	135		
defining			
areas	78		
custom sensor	46		
IPAddress	23		
Defining the IP address on the network adapter	23		
Delete All Markers function			
purpose	103, 123		
Delimiter(s)			
Define Custom Sensor dialog box	135		
Depth			
System Configuration dialog box	162		
depth information			
datagram formats	208		
depth range			
choosing	36		
Depth Tracking			
Profiling Settings dialog box	131		
description			
3D Point Cloud	95		
Advanced menu	112, 176		
Arrow	194		
Average Filter	203		
Background Removal Filter	203		
basic procedures	19		
Convert to Video dialog box	118		
Define Custom Sensor dialog box	134		
Display menu	103, 123		
Edge Enhancement	203		
Exporting Format function	117		
File menu	102, 115		
Geo Projection dialog box	137		
Head Firmware Configuration dialog box	146		
Head Network Setup dialog box	143		
Help menu	113, 191		
IQAS	198		
menu system	91		
No Filter	203		
Playback Console	127		
Power User Settings dialog box	178		
Power User Settings XML file	188		
Preferences dialog box	139		
Profile Batch Conversion dialog box	185		
Profiling Settings dialog box	129		
Program Head dialog box	181, 183–184		

-
- Protractor 196
 - Raw Data Spectrum window 187
 - Recording Format function 116
 - Reference cursor 1 197
 - Reference cursor 2 197
 - Rotator Test dialog box 156
 - Save image with overlay 199
 - Save image without overlay 199
 - Setup menu 106, 132
 - Sonar Applications menu 108, 168, 172–174
 - sonar view 92
 - status bar 99
 - String measure 196
 - system 10
 - System Configuration dialog box 148, 151, 154, 161, 164
 - Tape measure 196
 - Target Marker function 125
 - Text label 197
 - tool bar 97, 192
 - Wiper 194
 - Zoom windows 195
 - details
 - Convert to Video dialog box 119
 - Define Custom Sensor dialog box 135
 - Geo Projection dialog box 138
 - Head Firmware Configuration dialog box 146
 - Head Network Setup dialog box 143
 - Power User Settings dialog box 178
 - Power User Settings XML file 189
 - Preferences dialog box 140
 - Profile Batch Conversion dialog box 186
 - Profiling Settings dialog box 129
 - Program Head dialog box 182–183, 185
 - Rotator Test dialog box 158
 - Sonar Applications menu 172, 174–175
 - System Configuration dialog box 148, 152, 155, 162, 165
 - Target Marker function 125
 - TVG 201
 - Device Axis
 - System Configuration dialog box 155
 - diagram
 - system 11
 - dialog box
 - Convert to Video dialog box description 118
 - Define Custom Sensor dialog box
 - description 134
 - Geo Projection dialog box description 137
 - Head Firmware Configuration dialog box
 - description 146
 - Head Network Setup dialog box description 143
 - Power User Settings dialog box description 178
 - Preferences dialog box description 139
 - Profile Batch Conversion dialog box
 - description 185
 - Profiling Settings dialog box description 129
 - Program Head dialog box
 - description 181, 183–184
 - Rotator Test dialog box description 156
 - System Configuration dialog box
 - description 148, 151, 154, 161, 164
 - Directional Move
 - Rotator Test dialog box 158
 - Disconnect
 - Rotator Test dialog box 158
 - Discover Sonar Heads
 - System Configuration dialog box 149
 - Display Coords In
 - Geo Projection dialog box 138
 - Display Filter
 - Convert to Video dialog box 120
 - Display Grid
 - Convert to Video dialog box 119
 - Display menu
 - description 103, 123
 - how to open 103, 123
 - Display Mirror
 - Convert to Video dialog box 120
 - display organisation
 - description 89
 - Display Overlay Text
 - Convert to Video dialog box 120
 - Display Position
 - Convert to Video dialog box 120
 - Display Sensor Data
 - Convert to Video dialog box 120
 - display views
 - description 89
 - Distance / Time
 - Preferences dialog box 141
 - distances
 - measuring 76
 - dual sonars
 - setting up 54
 - E**
 - echogram
 - choosing range 36
 - Edge Enhancement
 - description 203
 - EIQ
 - purpose 109, 169
 - EIQ - Fine
 - purpose 109, 169
 - EIQ - Ultra Fine
 - purpose 109, 169
 - Enable Target Marker function
 - purpose 103, 123
 - environmental
 - requirements 216
 - Ethernet adapter
 - Defining the IP address on the network
 - adapter 23
 - Ethernet Test - 1000Mbps
 - purpose 109, 169
 - Ethernet Test - 100Mbps
 - purpose 109, 169
 - Ethernet Test - 10Mbps
 - purpose 109, 169
 - Exit function
 - purpose 102, 115
 - Export to File
 - Preferences dialog box 141
 - Export type
 - Profile Batch Conversion dialog box 186
 - Exporting Format function
 - description 117
 - purpose 102, 115

external sensors		
setting up	43	
F		
feedback		
send us	8	
Feet		
Preferences dialog box	140	
File menu		
description	102, 115	
how to open	102, 115	
filters		
applying	42	
Folder Conversion		
Convert to Video dialog box	120	
Font Size function		
purpose	104, 124	
formats		
processed data	208	
frequency		
changing	24	
Full Screen function		
purpose	103, 123	
function		
Exporting Format function description	117	
Playback Console description	127	
Recording Format function description	116	
Target Marker function description	125	
TVG details	201	
G		
Geo Projection dialog box		
Calculator	138	
Datum Parameters	138	
description	137	
details	138	
Display Coords In	138	
Latitude / Longitude	138	
Latitude / Longitude Format	138	
Northing / Easting	138	
purpose	106, 132	
Zone	138	
Geographic		
Preferences dialog box	140	
GeoTiff files		
saving	72	
Get Default		
Head Network Setup dialog box	144	
System Configuration dialog box	149	
Global Positioning System (GPS)		
datagram formats	206	
GPS (Global Positioning System)		
datagram formats	206	
gyro compass		
datagram formats	206	
H		
Head		
Head Firmware Configuration dialog box	146	
Program Head dialog box	182–183	
Head Firmware Configuration dialog box		
Configuration file	146	
Configuration type	146	
description	146	
details	146	
Head	146	
purpose	106, 132	
Read	146	
Write	146	
Head Name		
Head Network Setup dialog box	143	
System Configuration dialog box	148	
Head Network Setup dialog box		
Automatic IP address allocation	143	
description	143	
details	143	
Get Default	144	
Head Name	143	
IP Address	144	
IP Default Gateway	144	
IP Port	144	
IP Subnet Mask	144	
purpose	106, 132	
Read from Head	144	
Serial Number	143	
VDSL Profile	143	
VDSL SNR Margin	144	
Write to Head	144	
Heading		
System Configuration dialog box	162	
Heading Overlay function		
purpose	104, 124	
heading sensor		
datagram formats	206	
Heave		
System Configuration dialog box	162	
Help menu		
description	113, 191	
how to open	113, 191	
how to		
adjust sonar views	38	
adjust the TVG	42	
apply filters	42	
change the frequency	24	
change the Sonar Head IP Address	85	
choose a sonar application	37	
choose range	36	
configure preferences	35	
configure the Sonar Processor	20	
connect to the sonar	34	
control the rotator	49	
convert recordings	69–70	
define areas	78	
define custom sensor	46	
Defining the IP address on the network		
adapter	23	
install the operational software	22	
interpret the sonar view	93	
measure angles	77	
measure distances	76	
place reference cursors	79	
place target markers	80	
place text labels	78	
play back a record file	68	
record sonar data	66	
restore USB driver functionality	21	
save and recall screen captures	65	

- save and retrieve images 66
 - save GeoTiff files 72
 - set up dual M3 Sonars 54
 - set up external sensors 43
 - test 1PPS Time Sync Mode 30
 - test the sonar and sensors 27
 - test the Sonar Head 24
 - turn the M3 Sonar system on and off 17
 - Turning off the M3 Sonar system 18
 - Turning on the M3 Sonar system 17
 - upgrade the Sonar Head 83
 - how to open
 - Advanced menu 112, 176
 - Display menu 103, 123
 - File menu 102, 115
 - Help menu 113, 191
 - Setup menu 106, 132
 - Sonar Applications menu 108, 168
- I**
- icon
 - Arrow 194
 - Average Filter 203
 - Background Removal Filter 203
 - Edge Enhancement 203
 - IQAS 198
 - No Filter 203
 - Protractor 196
 - Reference cursor 1 197
 - Reference cursor 2 197
 - Save image with overlay 199
 - Save image without overlay 199
 - String measure 196
 - Tape measure 196
 - Text label 197
 - Wiper 194
 - Zoom windows 195
 - Image
 - Profiling Settings dialog box 129
 - Image and Profile
 - Profiling Settings dialog box 129
 - images
 - saving and retrieving 66
 - Imaging
 - purpose 111, 171
 - Imaging 15
 - purpose 109, 169
 - Imaging 3
 - purpose 109, 169
 - Imaging 30
 - purpose 110, 170
 - Imaging 30 - Short Range
 - purpose 110, 170
 - Imaging 7
 - purpose 110, 170
 - Imaging Enhanced
 - purpose 111, 171
 - information
 - support 15
 - Input type
 - Profile Batch Conversion dialog box 186
 - installation
 - software 22
 - installation requirements
 - environmental 216
 - temperature 216
 - interface
 - specifications 206
 - Interface
 - System Configuration dialog box 152, 155
 - interpret
 - sonar view 93
 - introduction
 - basic procedures 19
 - power supply 13
 - Sonar Head 14
 - Sonar Processor 13
 - technical specifications 205
 - Introduction to technical specifications 205
 - IP Address
 - Head Network Setup dialog box 144
 - System Configuration dialog box 148
 - IP Default Gateway
 - Head Network Setup dialog box 144
 - System Configuration dialog box 148
 - IP Port
 - Head Network Setup dialog box 144
 - System Configuration dialog box 148
 - IP Subnet Mask
 - Head Network Setup dialog box 144
 - System Configuration dialog box 148
 - IPAddress
 - defining 23
 - IQAS
 - description 198
- K**
- Kongsberg Discovery
 - support 15
- L**
- Latitude / Longitude
 - Geo Projection dialog box 138
 - Latitude / Longitude Format
 - Define Custom Sensor dialog box 135
 - Geo Projection dialog box 138
 - license information
 - software 7
 - Load User Settings function
 - purpose 102, 115
 - Local Time
 - Preferences dialog box 140
- M**
- M3 Sonar
 - system diagram 11
 - Magnetic Variation
 - System Configuration dialog box 162
 - mains power
 - requirements 215
 - Manual
 - Convert to Video dialog box 119
 - Match Ping Rate
 - Convert to Video dialog box 119
 - Max Depth

Profiling Settings dialog box	130	Setup menu	106, 132
Max File Size		Sonar Applications menu	108, 168
Convert to Video dialog box	121	operational software	
Max Sector		installation	22
Profiling Settings dialog box	130	Orientation	
measuring		System Configuration dialog box	165
angles	77	Output Messages function	
distances	76	purpose	103, 123
mechanical		Overlay Text	
specifications	213	Preferences dialog box	140
menu		Override Beamlist	
Advanced menu description	112, 176	Power User Settings dialog box	179
Display	103, 123	Override Mounting Parameters function	
File menu description	102, 115	purpose	166
Help menu description	113, 191	Override Network Link Speed	
Setup	106, 132	System Configuration dialog box	149
Sonar Applications menu descrip- tion	108, 168, 172–174	Override Processing Type	
menu system		Power User Settings dialog box	179
description	91	<OverrideBeamlistFile>	
Message ID		Power User Settings XML file	189
Define Custom Sensor dialog box	135	overview	
Meters		power supply	13
Preferences dialog box	140	Sonar Head	14
Min Depth		Sonar Processor	13
Profiling Settings dialog box	130		
Min Sector		P	
Profiling Settings dialog box	130	Palette	
minimum requirements		Convert to Video dialog box	119
computer	217	Palette function	
Mode ID		purpose	104, 124
Power User Settings dialog box	179	Parity	
motion sensor		System Configuration dialog box	152, 155
datagram formats	207	Target Marker Export dialog box	125
		performance	
N		specifications	209
Name		peripheral systems	
Preferences dialog box	140	interface specifications	206
System Configuration dialog box	152, 155	Ping Rate	
network adapter		Power User Settings dialog box	179
Defining the IP address on the network adapter	23	Pitch Angle	
Network log level		System Configuration dialog box	165
System Configuration dialog box	149	Pitch/Roll	
Network Sniffer window		System Configuration dialog box	162
purpose	112, 176	placing	
No Filter		reference cursors	79
description	203	target markers	80
noise and interference		text labels	78
sonar view	94	Playback Console	
Northing / Easting		description	127
Geo Projection dialog box	138	Playback Console function	
		purpose	103, 123
O		Playback function	
office		purpose	102, 115
support	15	<PlaybackOverrideBeamlists>	
One Frame per Ping		Power User Settings XML file	189
Convert to Video dialog box	119	playing back	
open		record file	68
Advanced menu	112, 176	Point Selection	
Display menu	103, 123	Profiling Settings dialog box	130
File menu	102, 115	Point Size	
Help menu	113, 191	Profiling Settings dialog box	129
		Port	
		Target Marker Export dialog box	125
		Port for .ALL format	

- Preferences dialog box 141
- Port Location
 - System Configuration dialog box 152, 155
- Port#
 - System Configuration dialog box 152, 155
- Position
 - System Configuration dialog box 162
- Positioning
 - Rotator Test dialog box 159
- positioning system
 - datagram formats 206
- power
 - requirements 215
 - specifications 215
- power supply
 - introduction 13
 - overview 13
 - purpose 13
- Power User Settings dialog box
 - Azimuth Processing 178
 - description 178
 - details 178
 - Mode ID 179
 - Override Beamlist 179
 - Override Processing Type 179
 - Ping Rate 179
 - purpose 112, 176
 - Range Processing 178
 - RX Amplitude and Phase Correction 178
 - Sidelobe Reduction 178
 - Update Rate 179
- Power User Settings XML file
 - <BatchProfilingDesFolder> 189
 - <BatchProfilingSrcFolder> 189
 - description 188
 - details 189
 - <OverrideBeamlistFile> 189
 - <PlaybackOverrideBeamlists> 189
 - <ProcessingTypeOverride> 189
 - <Profile3DCloudPingToKeep> 189
 - <ProfileContinuousContour> 189
 - <ProfileSelectionFilterCoef> 189
 - <ProfileSpikeFilter> 189
- preferences
 - configuring 35
- Preferences dialog box
 - configuring 35
 - Cropped Width 141
 - description 139
 - details 140
 - Distance / Time 141
 - Export to File 141
 - Feet 140
 - Geographic 140
 - Local Time 140
 - Meters 140
 - Name 140
 - Overlay Text 140
 - Port for .ALL format 141
 - Prompt User for Filename 140
 - purpose 106, 132
 - Range / Bearing 140
 - Remote IP Address 141
 - Use default location 140
 - UTC Time 140
- X / Y 140
- presentation
 - description 89
- procedure
 - adjusting sonar views 38
 - adjusting the TVG 42
 - applying filters 42
 - changing the frequency 24
 - changing the Sonar Head IP Address 85
 - choosing a sonar application 37
 - choosing range 36
 - configuring preferences 35
 - configuring the Sonar Processor 20
 - connecting to the sonar 34
 - controlling the rotator 49
 - converting recordings 69–70
 - defining areas 78
 - defining custom sensor 46
 - Defining the IP address on the network
 - adapter 23
 - installing the operational software 22
 - interpreting the sonar view 93
 - measuring angles 77
 - measuring distances 76
 - placing reference cursors 79
 - placing target markers 80
 - placing text labels 78
 - playing back a record file 68
 - recording sonar data 66
 - restoring USB driver functionality 21
 - saving and retrieving images 66
 - saving GeoTiff files 72
 - Setting up dual M3 Sonars 54
 - setting up external sensors 43
 - testing 1PPS Time Sync Mode 30
 - testing the sonar and sensors 27
 - testing the Sonar Head 24
 - Turning off the M3 Sonar system 18
 - Turning on the M3 Sonar system 17
 - upgrading the Sonar Head 83
- procedures
 - saving and recalling screen captures 65
 - turning the M3 Sonar system on and off 17
- processed data
 - formats 208
- <ProcessingTypeOverride>
 - Power User Settings XML file 189
- Production Configuration
 - Program Head dialog box 182
- Profile Batch Conversion dialog box
 - Convert Mode 186
 - description 185
 - details 186
 - Export type 186
 - Input type 186
 - purpose 112, 176
- Profile Only
 - Profiling Settings dialog box 129
- <Profile3DCloudPingToKeep>
 - Power User Settings XML file 189
- <ProfileContinuousContour>
 - Power User Settings XML file 189
- <ProfileSelectionFilterCoef>
 - Power User Settings XML file 189
- <ProfileSpikeFilter>
 - Power User Settings XML file 189

Power User Settings XML file	189	Geo Projection dialog box	106, 132
Profiling		Head Firmware Configuration dialog box	106, 132
purpose	110, 170	Head Network Setup dialog box	106, 132
Profiling - Bathy		Heading Overlay function	104, 124
purpose	110, 170	Imaging	111, 171
Profiling - Dual Head Master		Imaging 15	109, 169
purpose	110, 170	Imaging 3	109, 169
Profiling - Dual Head Slave		Imaging 30	110, 170
purpose	110, 170	Imaging 30 - Short Range	110, 170
Profiling - Fast		Imaging 7	110, 170
purpose	110, 170	Imaging Enhanced	111, 171
Profiling - HiRes		Load User Settings function	102, 115
purpose	111, 171	Network Sniffer window	112, 176
Profiling Settings dialog box		Output Messages function	103, 123
Algorithm	130	Override Mounting Parameters function	166
Clutter Suppression	130	Palette function	104, 124
Depth Tracking	131	Playback Console function	103, 123
description	129	Playback function	102, 115
details	129	power supply	13
Image	129	Power User Settings dialog box	112, 176
Image and Profile	129	Preferences dialog box	106, 132
Max Depth	130	Profile Batch Conversion dialog box	112, 176
Max Sector	130	Profiling	110, 170
Min Depth	130	Profiling - Bathy	110, 170
Min Sector	130	Profiling - Dual Head Master	110, 170
Point Selection	130	Profiling - Dual Head Slave	110, 170
Point Size	129	Profiling - Fast	110, 170
Profile Only	129	Profiling - HiRes	111, 171
purpose	103, 123	Profiling Settings dialog box	103, 123
Program Head dialog box		Program Head dialog box	112, 176
Configuration file	182–183, 185	Raw Data Spectrum window	112, 176
Configuration type	183	Recording Format function	102, 115
description	181, 183–184	Reset to Default Layout function	104, 124
details	182–183, 185	Rotator Control dialog box	103, 123
Head	182–183	ROV Navigation	110, 170
Production Configuration	182	Rub Test	111, 171
purpose	112, 176	Sector Orientation function	104, 124
Read Config	182	Sidelobe Reduction function	104, 124
Write Config	182	Sonar Head	14
Prompt User for Filename		Sonar Processor	13
Preferences dialog box	140	Speckle Filter function	104, 124
Protocol		Stop Playback function	102, 115
System Configuration dialog box	152	System Configuration dialog box	106, 132
Protractor		this publication	7
description	196	tool bar	104, 124
purpose		User Manual function	113, 191
3D Point Cloud function	103, 123		
About dialog box	113, 191		
Annotations	104, 124		
Connect function	106, 132		
Convert to Video dialog box	102, 115		
Customize Apps dialog box	111, 171		
Define Custom Sensor dialog box	106, 132		
Delete All Markers function	103, 123		
EIQ	109, 169		
EIQ - Fine	109, 169		
EIQ - Ultra Fine	109, 169		
Enable Target Marker function	103, 123		
Ethernet Test - 1000Mbps	109, 169		
Ethernet Test - 100Mbps	109, 169		
Ethernet Test - 10Mbps	109, 169		
Exit function	102, 115		
Exporting Format function	102, 115		
Font Size function	104, 124		
Full Screen function	103, 123		

Q

Quality	
Convert to Video dialog box	119

R

Radius	
System Configuration dialog box	166
range	
choosing	36
Range / Bearing	
Preferences dialog box	140
Range Processing	
Power User Settings dialog box	178
Raw Data Spectrum window	

- description 187
- purpose 112, 176
- Read
 - Head Firmware Configuration dialog box 146
- Read Config
 - Program Head dialog box 182
- Read from Head
 - Head Network Setup dialog box 144
- record file
 - playing back 68
- recording
 - sonar data 66
- Recording Format function
 - description 116
 - purpose 102, 115
- recordings
 - converting 69–70
- Reference cursor 1
 - description 197
- Reference cursor 2
 - description 197
- reference cursors
 - placing 79
- registered trademarks 7
- Remote IP Address
 - Preferences dialog box 141
- Remove Device
 - System Configuration dialog box 152, 155
- requirements
 - computer 217
 - environmental 216
 - mains power 215
 - power 215
 - supply power 215
 - temperature 216
- Reset to Default Layout function
 - purpose 104, 124
- Resolution
 - Convert to Video dialog box 119
- restoring
 - USB driver functionality 21
- Roll Angle
 - System Configuration dialog box 165
- rotator
 - controlling 49
- Rotator Control dialog box
 - purpose 103, 123
- Rotator Control Dialog Type
 - Rotator Test dialog box 160
- Rotator Test dialog box
 - Connect 158
 - Current Position 158
 - description 156
 - details 158
 - Directional Move 158
 - Disconnect 158
 - Positioning 159
 - Rotator Control Dialog Type 160
 - Soft Stops 159
- ROV Navigation
 - purpose 110, 170
- Rub Test
 - purpose 111, 171
- RX Amplitude and Phase Correction
 - Power User Settings dialog box 178
- S**
- Save image with overlay
 - description 199
- Save image without overlay
 - description 199
- saving
 - GeoTiff files 72
- saving and retrieving
 - images 66
- Sector Orientation function
 - purpose 104, 124
- Sensor Format
 - Define Custom Sensor dialog box 135
- Sensor Name
 - Define Custom Sensor dialog box 136
- sensors
 - interface specifications 206
 - setting up 43
- Serial Number
 - Head Network Setup dialog box 143
 - System Configuration dialog box 148
- setting up
 - dual sonars 54
 - external sensors 43
 - sensors 43
- Setup menu
 - description 106, 132
 - how to open 106, 132
- Sidelobe Reduction
 - Power User Settings dialog box 178
- Sidelobe Reduction function
 - purpose 104, 124
- Sidelobe Suppression
 - Convert to Video dialog box 120
- Soft Stops
 - Rotator Test dialog box 159
- software
 - installation 22
- software license
 - about 7
- software version
 - about 7
- sonar and sensors
 - testing 27
- sonar application
 - choosing 37
- Sonar Applications menu
 - description 108, 168, 172–174
 - details 172, 174–175
 - how to open 108, 168
- sonar data
 - recording 66
- sonar head
 - connecting 34
- Sonar Head
 - changing IP Address 85
 - introduction 14
 - overview 14
 - purpose 14
 - testing 24
 - upgrading 83
- sonar presentation
 - description 89
- Sonar Processor

configuring.....	20	Depth.....	162
introduction.....	13	description.....	148, 151, 154, 161, 164
overview.....	13	details.....	148, 152, 155, 162, 165
purpose.....	13	Device Axis.....	155
Sonar Setup dialog box		Discover Sonar Heads.....	149
connecting to the sonar.....	34	Get Default.....	149
sonar view		Head Name.....	148
about.....	92	Heading.....	162
description.....	92	Heave.....	162
interpreting.....	93	Interface.....	152, 155
noise and interference.....	94	IP Address.....	148
sonar views		IP Default Gateway.....	148
adjust.....	38	IP Port.....	148
sound speed		IP Subnet Mask.....	148
datagram formats.....	207	Magnetic Variation.....	162
Sound Speed		Name.....	152, 155
System Configuration dialog box.....	162	Network log level.....	149
Source File		Orientation.....	165
Convert to Video dialog box.....	121	Override Network Link Speed.....	149
Source Folder		Parity.....	152, 155
Convert to Video dialog box.....	121	Pitch Angle.....	165
specification		Pitch/Roll.....	162
synchronization.....	208	Port Location.....	152, 155
specifications		Port#.....	152, 155
interface capabilities.....	206	Position.....	162
mechanical.....	213	Protocol.....	152
performance.....	209	purpose.....	106, 132
power.....	215	Radius.....	166
Speckle Filter function		Remove Device.....	152, 155
purpose.....	104, 124	Roll Angle.....	165
speed log		Serial Number.....	148
datagram formats.....	206	setting up external sensors.....	43
status bar		Sound Speed.....	162
description.....	99	Stop Bits.....	152, 155
Stop bits		Test Device.....	152, 155
Target Marker Export dialog box.....	125	testing 1PPS Time Sync Mode.....	30
Stop Bits		Time Sync Mode.....	148
System Configuration dialog box.....	152, 155	Trigger Mode.....	148
Stop Playback function		Unit.....	155
purpose.....	102, 115	Use Discovered Head.....	149
String measure		X Offset.....	165
description.....	196	Y Offset.....	165
suggestions		Yaw Angle.....	165
send us.....	8	Z Offset.....	165
supply power		system software	
requirements.....	215	installation.....	22
support information.....	15		
Supported datagram formats for sound speed		T	
sensors.....	207	Tape measure	
SW		description.....	196
software version.....	7	target audience	
SW license		this publication.....	7
about.....	7	Target File	
synchronization		Convert to Video dialog box.....	121
specification.....	208	Target file naming convention	
system		Convert to Video dialog box.....	121
description.....	10	Target Folder	
diagram.....	11	Convert to Video dialog box.....	121
System Configuration dialog box		Target Marker Export dialog box	
Add Device.....	152, 155	Baud rate.....	125
Angle.....	166	Data bits.....	125
Autoconnect at program start.....	149	Parity.....	125
Baud Rate.....	152, 155	Port.....	125
Configuration.....	162	Stop bits.....	125
Data Bits.....	152, 155		

-
- Target Marker function
 - description 125
 - details 125
 - target markers
 - placing 80
 - technical requirements
 - computer 217
 - mains power 215
 - power 215
 - supply power 215
 - technical specifications
 - interface specifications 206
 - introduction 205
 - performance 209
 - temperature
 - requirements 216
 - Termination
 - Define Custom Sensor dialog box 135
 - Test Device
 - System Configuration dialog box 152, 155
 - testing
 - 1PPS Time Sync Mode 30
 - sonar and sensors 27
 - Sonar Head 24
 - Text label
 - description 197
 - text labels
 - placing 78
 - this publication
 - about 7
 - purpose 7
 - target audience 7
 - this user manual
 - about 7
 - purpose 7
 - target audience 7
 - Time Sync Mode
 - System Configuration dialog box 148
 - time variable gain
 - adjusting 42
 - Time Variable Gain
 - details 201
 - Time Variable Gain (TVG)
 - concept 200
 - tool bar
 - Arrow description 194
 - Average Filter description 203
 - Background Removal Filter description 203
 - description 97, 192
 - Edge Enhancement description 203
 - IQAS description 198
 - No Filter description 203
 - Protractor description 196
 - purpose 104, 124
 - Reference cursor 1 description 197
 - Reference cursor 2 description 197
 - Save image with overlay description 199
 - Save image without overlay description 199
 - String measure description 196
 - Tape measure description 196
 - Text label description 197
 - Wiper description 194
 - Zoom windows description 195
 - Trigger Mode
 - System Configuration dialog box 148
 - Turning off the M3 Sonar system 18
 - Turning on the M3 Sonar system 17
 - TVG
 - adjusting 42
 - details 201
 - TVG (Time Variable Gain)
 - concept 200
- U**
- Unit
 - System Configuration dialog box 155
 - Unit Scale Factor
 - Define Custom Sensor dialog box 135
 - Update Rate
 - Power User Settings dialog box 179
 - upgrading
 - Sonar Head 83
 - USB driver functionality
 - restoring 21
 - Use default location
 - Preferences dialog box 140
 - Use Discovered Head
 - System Configuration dialog box 149
 - user interface
 - description 89
 - User Manual function
 - purpose 113, 191
 - UTC Time
 - Preferences dialog box 140
- V**
- VDSL Profile
 - Head Network Setup dialog box 143
 - VDSL SNR Margin
 - Head Network Setup dialog box 144
 - view
 - 3D Point Cloud description 95
 - sonar view description 92
- W**
- window
 - Raw Data Spectrum window description 187
 - Wiper
 - description 194
 - Write
 - Head Firmware Configuration dialog box 146
 - Write Config
 - Program Head dialog box 182
 - Write to Head
 - Head Network Setup dialog box 144
- X**
- X / Y
 - Preferences dialog box 140
 - X Offset
 - System Configuration dialog box 165

Y

Y Offset
System Configuration dialog box..... 165

Yaw Angle
System Configuration dialog box..... 165

Z

Z Offset
System Configuration dialog box..... 165

Zone
Geo Projection dialog box 138

Zoom windows
description 195

©2024 Kongsberg Discovery Canada Limited